Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GVC19018

Geepas Canister Vacuum Cleaner GVC19018 Instruction Manual

Model: GVC19018 | Brand: Geepas

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Geepas Canister Vacuum Cleaner, model GVC19018. Please read these instructions carefully before using the appliance and retain them for future reference.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance, including the following:

- Read all instructions before using this vacuum cleaner.
- Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.

- Use extra care when cleaning on stairs.

Package Contents

Upon unpacking, please ensure all items listed below are present and in good condition:

- Geepas Canister Vacuum Cleaner Unit
- Flexible Hose
- Telescopic Metal Tube
- Floor Brush/Nozzle
- Crevice Tool
- Small Brush Nozzle
- Dust Bag (pre-installed or separate)
- Instruction Manual



Image: Included accessories for the Geepas GVC19018 vacuum cleaner.

Product Overview

The Geepas GVC19018 is a powerful 2300W canister vacuum cleaner with a 21-liter dust bag capacity, designed for efficient cleaning of various surfaces. It features a dry and blow function, easy-glide wheels, and a high-performance motor.



Image: Front view of the Geepas GVC19018 Canister Vacuum Cleaner.

Key Features:

- **21-Liter Dust Bag Capacity:** Large capacity for extended cleaning sessions.
- **Dry & Blow Function:** Versatile for both vacuuming and blowing dust from hard-to-reach areas.
- **Easy Parking Nozzle:** Convenient storage and accessibility for the floor brush.
- **High-Performance 2300W Motor:** Provides strong suction power for effective cleaning.
- **4x Castor Wheels:** Ensures easy mobility and maneuverability.

Setup and Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Flexible Hose:** Insert the larger end of the flexible hose into the suction inlet on the main unit until it clicks securely into place. For the blow function, attach it to the blow outlet.
3. **Assemble Extension Tubes:** Connect the telescopic metal tube to the handle end of the flexible hose. Adjust the length of the telescopic tube as needed by pressing the release button and extending or retracting.
4. **Attach Floor Brush:** Connect the desired cleaning nozzle (e.g., floor brush) to the end of the telescopic tube. Ensure it is firmly attached.
5. **Check Dust Bag:** Open the latches on the main unit and lift the motor head. Verify that the dust bag is correctly installed inside the canister. Close the motor head and secure the latches.

Operating Instructions

Vacuuming:

1. Ensure the vacuum cleaner is fully assembled and the dust bag is correctly installed.
2. Plug the power cord into a suitable electrical outlet.
3. Press the power switch to turn on the vacuum cleaner.
4. Guide the floor brush or appropriate attachment over the surface to be cleaned.
5. When finished, turn off the power switch and unplug the appliance.



Image: Vacuum cleaner in operation on a hard floor.

Using the Blow Function:

1. Unplug the flexible hose from the suction inlet.
2. Locate the blow outlet on the main unit (usually opposite the suction inlet) and firmly insert the flexible hose into it.
3. Plug in the power cord and turn on the appliance. Air will now be expelled from the hose, allowing you to blow dust and debris from hard-to-reach areas.
4. When finished, turn off the power switch, unplug the appliance, and return the hose to the suction inlet for vacuuming.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

Emptying and Cleaning the Dust Bag:

- Always unplug the vacuum cleaner before performing any maintenance.
- When the dust bag full indicator shows, or suction power decreases, it's time to empty the dust bag.
- Open the latches on the main unit and lift the motor head.
- Carefully remove the dust bag. Dispose of collected debris.
- If the dust bag is reusable, shake out dust thoroughly. If it's disposable, replace it with a new one.
- Reinsert the dust bag correctly and close the motor head, securing the latches.

Cleaning Filters:

- Check filters regularly for blockages or excessive dirt.
- Depending on the filter type, they may be washable or require replacement. Refer to the specific filter instructions.
- Ensure filters are completely dry before reinserting them into the vacuum cleaner.

General Cleaning:

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners.
- Check the hose and attachments for any blockages and clear them if necessary.

Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Not plugged in; power outlet faulty; power switch off.	Check power cord connection; test outlet with another appliance; ensure power switch is ON.
Low suction power.	Dust bag full; filters clogged; hose/attachments blocked.	Empty/replace dust bag; clean/replace filters; check and clear blockages in hose/attachments.
Unusual noise during operation.	Foreign object in hose/brush; motor issue.	Turn off and unplug, then check hose/brush for obstructions. If noise persists, contact service.
Overheating.	Clogged filters or dust bag; prolonged use.	Turn off and unplug, allow to cool. Empty dust bag and clean filters. Avoid continuous long operation.

Specifications

Feature	Detail
Brand	Geepas
Model Number	GVC19018
Color	Maroon
Power / Wattage	2300 watts
Voltage	240 Volts (AC)
Capacity	21 Liters (Dust Bag)
Material	Plastic

Feature	Detail
Noise Level	80 Decibels
Product Dimensions	33 x 33 x 39 cm
Item Weight	9.4 Kilograms
Special Features	Compact, Lightweight, Portable, Wheels
Filter Type	Bag
Surface Recommendation	Carpet, Hard Floor
Power Source	Corded Electric
Cordless	No

Warranty and Support

The Geepas Canister Vacuum Cleaner GVC19018 comes with a**2-year manufacturer's warranty**. For warranty claims, technical support, or service inquiries, please contact your retailer or the authorized Geepas service center in your region. Keep your purchase receipt as proof of purchase.
For additional support, you may visit the official Geepas website or refer to the contact information provided in your product packaging.

© 2023 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6QSQ9TV

More documents and user manuals: **https://manuals.plus/**