Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

kensen B0C6TMWVHZ

Kensen Body Hair Trimmer (Model B0C6TMWVHZ) User Manual

Comprehensive instructions for safe and effective use.

1. Introduction

Thank you for choosing the Kensen Body Hair Trimmer. This manual provides essential information for the safe operation, maintenance, and care of your new grooming device. Please read these instructions thoroughly before first use and retain them for future reference.

2. Safety Information

General Safety Precautions:

- Ensure the device is fully charged before use to maintain optimal performance.
- Do not use the trimmer if the blades are damaged or bent, as this may cause injury.
- Keep the device out of reach of children.
- Avoid dropping the trimmer, as this can damage internal components.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- This appliance is intended for body hair trimming only. Do not use for other purposes.
- Always ensure the charging port is dry before connecting the charging cable.

3. Package Contents

Verify that all items are present in your package:

- Kensen Body Hair Trimmer
- 2 Guide Combs (e.g., 3.0mm, 6.0mm)
- USB Type-C Charging Cable
- Cleaning Brush
- Travel Case
- User Manual



Image: Kensen Body Hair Trimmer with included accessories.

4. Product Features

- **Advanced Ceramic Blades:** Designed for smooth and precise cutting, featuring R-angle ceramic blades to minimize skin irritation and hair pulling.
- **Integrated LED Light:** Provides illumination for improved visibility during trimming, especially in low-light conditions.
- **IPX7 Waterproof Rating:** Allows for wet or dry use, including in the shower, and facilitates easy cleaning under running water.
- **High-Power, Low-Noise Motor:** Equipped with a 6400 RPM motor for efficient trimming without pulling hair, operating at less than 60dB.
- **Rechargeable Battery:** Offers up to 90 minutes of runtime on a full charge, with convenient Type-C charging.
- **Compact and Cordless Design:** Ideal for home use, business trips, and personal travel.



Image: Detail of the trimmer's R-shaped ceramic blade and LED light.



Image: Internal view highlighting the high-power motor.

5. Setup

5.1 Charging the Trimmer

1. Ensure the trimmer is dry before charging.
2. Connect the USB Type-C charging cable to the trimmer's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., wall adapter, computer, power bank).
4. The LED indicator on the trimmer will show charging status. A full charge typically takes approximately 90 minutes and provides up to 90 minutes of runtime.



Image: Trimmer connected to a Type-C charging cable.



Image: Trimmer charging via a USB interface.

6. Operating Instructions

6.1 Attaching/Removing Guide Combs

- To attach a guide comb, align the comb with the trimmer head and push it firmly until it clicks into place.
- To remove, gently pull the comb away from the trimmer head.

6.2 General Trimming

1. Ensure the trimmer is fully charged.
2. Select the desired guide comb for your preferred hair length. For closer trims, you may use the trimmer without a comb.
3. Press the power button to turn on the trimmer. The LED light will illuminate.
4. Hold the trimmer close to the skin and move it slowly and steadily against the direction of hair growth.

5. For optimal results and to prevent irritation, stretch the skin taut with your free hand, especially in sensitive areas.
6. The trimmer can be used wet or dry, including in the shower.



Image: Demonstrating trimmer use on various body parts.

6.3 Trimming Sensitive Areas (e.g., Groin)

When trimming sensitive areas, exercise extra caution:

- **Always install a guide comb** when trimming sensitive areas to prevent direct contact of the blade with loose skin.
- Gently pull the skin taut with one hand to create a flat surface.
- Move the trimmer slowly and steadily, applying minimal pressure.
- Trim against the direction of hair growth for a closer cut.
- Avoid rapid movements or pressing too hard, which can cause nicks or irritation.



Image: Correct and incorrect trimming techniques for sensitive skin.

7. Maintenance and Cleaning

7.1 Cleaning the Trimmer

1. Turn off the trimmer before cleaning.
2. **Detaching the Blade:** Push the top of the blade assembly forward to detach it from the trimmer body.
3. Use the included cleaning brush to remove any loose hairs from the blade and the trimmer body.
4. Rinse the blade head and the trimmer body under running water. The IPX7 waterproof design allows for full body washing.
5. Shake off excess water and allow all parts to air dry completely before reattaching the blade or storing the trimmer.
6. **Reattaching the Blade:** Align the bottom of the blade with the trimmer, then press the top of the blade into the trimmer until it clicks.



Image: Trimmer being cleaned under running water, highlighting detachable blade.

7.2 Blade Oiling (Optional)

For optimal performance and longevity, you may apply a small drop of clipper oil to the blades periodically. Turn on the trimmer for a few seconds to distribute the oil, then wipe off any excess.

8. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Low battery or no charge.	Charge the trimmer fully using the provided Type-C cable.
Trimmer pulls hair or cuts poorly.	Blades are dull, dirty, or not properly oiled. Hair buildup.	Clean the blades thoroughly. Apply a drop of clipper oil. Ensure you are trimming against the direction of hair growth.
Trimmer makes unusual noise.	Hair caught in the motor or blade mechanism.	Turn off and clean the trimmer thoroughly. If the noise persists, contact customer support.
Charging indicator not working.	Cable or power source issue. Trimmer already fully charged.	Try a different USB cable or power source. If the trimmer is fully charged, the indicator may turn off or change color.

9. Specifications

- **Brand:** Kensen
- **Model:** B0C6TMWVHZ
- **Color:** Green
- **Power Source:** Battery Powered (Rechargeable)
- **Blade Material:** Ceramic
- **Special Features:** Cordless, Rechargeable, Wet/Dry Use, LED Light
- **Motor Speed:** 6400 RPM
- **Noise Level:** <60dB
- **Waterproof Rating:** IPX7 (Whole body washable)
- **Battery Runtime:** Up to 90 minutes
- **Charging Time:** Approximately 90 minutes
- **Dimensions:** 17.4 x 8.7 x 5.4 cm
- **Weight:** 230 g

10. Warranty and Support

The Kensen Body Hair Trimmer comes with a**ONE Year Free Warranty**. If you encounter any issues or have questions regarding your Kensen trimmer, please do not hesitate to contact our customer service team. We are committed to providing support and resolving any concerns you may have.
For assistance, please refer to the contact information provided with your purchase or visit the official Kensen brand store online.
Kensen Promise: Our after-sales service team aims to address your inquiries within 12 hours until you are satisfied.

© 2023 Kensen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6TMWVHZ

More documents and user manuals: **https://manuals.plus/**