Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard 680988248337

Billboard Water-Resistant Bluetooth Speaker

Model: 680988248337

Introduction

Thank you for purchasing the Billboard Water-Resistant Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Ensure all ports are securely closed before exposing the speaker to water to maintain its water-resistant properties.
- Do not attempt to disassemble or modify the speaker. This will void the warranty and may cause damage.
- Keep the speaker away from strong magnetic fields.
- Use only the provided charging cable or a certified equivalent.

Package Contents

- Billboard Water-Resistant Bluetooth Speaker
- USB Charging Cable (not explicitly listed but implied for charging)
- 3.5 mm Aux Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your Billboard Water-Resistant Bluetooth Speaker.



Image: The Billboard Water-Resistant Bluetooth Speaker, featuring a blue cylindrical design with a perforated grille for sound output and solid blue caps on each end. The Billboard logo is subtly visible on one end cap.

Controls and Ports:

- **Power Button:** Turns the speaker on/off.
- **Volume Up/Next Track Button:** Increases volume or skips to the next song.
- **Volume Down/Previous Track Button:** Decreases volume or goes to the previous song.
- **Play/Pause/Call Button:** Plays/pauses music, answers/ends calls.
- **Mode Button:** Switches between Bluetooth, FM, and Aux modes.
- **Charging Port:** For connecting the USB charging cable.
- **Aux-in Port:** For connecting external audio devices via 3.5mm cable.
- **SD/TF Card Slot:** For playing music directly from a memory card.

Setup

Charging the Speaker:

1. Connect the small end of the USB charging cable to the speaker's charging port.
2. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color once fully charged.
4. A full charge provides approximately 7 hours of battery life.

Bluetooth Pairing:

1. Ensure the speaker is fully charged.
2. Press and hold the Power button to turn on the speaker. A voice prompt or indicator light will confirm it's in Bluetooth pairing mode.
3. On your smartphone, tablet, or laptop, enable Bluetooth and search for available devices.
4. Select "Billboard Speaker" (or similar name) from the list of devices.
5. Once paired, the speaker will emit a confirmation sound. The wireless range is approximately 33 feet (10 meters).

Operating Instructions

Playing Music:

- **Bluetooth Mode:** After pairing, play music from your connected device. Use the speaker's Play/Pause, Volume Up/Down, and Next/Previous Track buttons to control playback.

- **Aux-in Mode:** Connect one end of the 3.5mm aux cable to the speaker's Aux-in port and the other end to your audio device's headphone jack. The speaker will automatically switch to Aux mode or you may need to press the Mode button.
- **FM Radio Mode:** Press the Mode button to switch to FM radio. Use the Play/Pause button to auto-scan for stations. Use the Next/Previous Track buttons to switch between saved stations.
- **SD/TF Card Mode:** Insert a memory card with MP3 files into the SD/TF card slot. The speaker will automatically switch to this mode and begin playing.

Hands-Free Speakerphone:

- When a call comes in while connected via Bluetooth, the speaker will ring.
- Press the Play/Pause/Call button to answer the call.
- Press the Play/Pause/Call button again to end the call.
- Press and hold the Play/Pause/Call button to reject an incoming call.

Maintenance

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure all port covers are sealed when not in use, especially before exposure to water.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Charge the battery at least once every three months to maintain battery health if not used regularly.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device too far; Bluetooth off on device.	Ensure speaker is in pairing mode; move device closer; enable Bluetooth on your device.
No sound.	Volume too low; incorrect mode; device not playing.	Increase volume; check speaker mode (Bluetooth, Aux, FM); ensure audio is playing on connected device.
Poor FM reception.	Weak signal.	Relocate the speaker to an area with better signal.

Specifications

- **Model Name:** Billboard
- **Speaker Type:** Bluetooth
- **Connectivity Technology:** Bluetooth
- **Wireless Range:** 33 Feet (10 meters)
- **Battery Life:** 7 Hours
- **Power Source:** Battery Powered
- **Water Resistance Level:** Waterproof
- **Product Dimensions:** 5.75"D x 5.75"W x 4.5"H

- **Item Weight:** 12.8 ounces
- **Speaker Maximum Output Power:** 10 Watts
- **Audio Output Mode:** Stereo
- **Included Components:** 3.5 mm aux cable, SD/TP memory card slot
- **Control Method:** Touch/Button
- **Number of Microphones:** 1 (for speakerphone)

Warranty and Support

This Billboard Water-Resistant Bluetooth Speaker comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact the manufacturer, ESI CASES & ACCESSORIES, through their official support channels. Contact information can typically be found on the product packaging or their official website.
Manufacturer: ESI CASES & ACCESSORIES

© 2023 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6WV35GV

More documents and user manuals: **https://manuals.plus/**