Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ReplacementScrews RSAZN4907442

ReplacementScrews M4x14mm TV Stand Screw Installation Guide for Samsung TVs

Model: RSAZN4907442

1. Introduction

This manual provides detailed instructions for the proper installation of ReplacementScrews M4x14mm TV stand screws. This kit includes both machine screws and self-tapping screws, designed for compatibility with various Samsung TV models requiring M4x14mm screws for their original factory stands. It is crucial to identify the correct screw type for your specific TV stand to ensure secure attachment and prevent damage.

2. Package Contents

Your ReplacementScrews M4x14mm kit contains the following:

- 4 x M4x14mm Machine Screws (black, fine thread)
- 4 x M4x14mm Self-Tapping Screws (black, coarse thread)
- Total of 8 screws



Image 1: Contents of the M4x14mm screw kit, showing both machine and self-tapping screws.

3. Setup and Installation

Before beginning installation, ensure your TV is powered off and disconnected from all power sources. Place the TV screen-down on a soft, clean surface to prevent scratches.

3.1. Identify Correct Screw Type

Samsung TV stands may use either machine screws or self-tapping screws for attachment. Refer to your TV's original instruction manual or quick start guide to confirm the required screw type (M4x14mm). If the manual does not specify, you will need to determine this by inspecting the screw holes on your TV and stand.

- **Machine Screws:** These have fine, uniform threads and are designed for pre-threaded metal holes or inserts.
- **Self-Tapping Screws:** These have coarser, often uneven threads and are designed to create their own threads in plastic or softer materials.



Image 2: Comparison of self-tapping (left) and machine (right) screw threads.

3.2. Attaching the TV Stand

1. Carefully align the TV stand (legs or base) with the corresponding screw holes on the back or bottom of your Samsung TV.
2. Insert the correct type of M4x14mm screw into each designated hole.
3. Using a Phillips head screwdriver, gently tighten each screw. Do not overtighten, as this can strip the threads or damage the TV casing. Tighten until the stand is firmly secured and there is no wobble.
4. Once all screws are securely fastened, carefully lift the TV and place it in its desired location. Ensure the stand is stable on a flat surface before reconnecting power and other cables.

Important: These screws are designed exclusively for attaching original factory TV stands. They are not suitable for universal stands or wall mounting applications, which typically require different screw specifications.

4. Usage Guidelines and Compatibility

These M4x14mm screws are specifically manufactured to match the original equipment manufacturer (OEM) specifications for many Samsung TVs. The "M4" refers to a 4mm diameter, and "14mm" (or L14) refers to the length of the threaded part of the screw. The head of the screw is not included in this length measurement.
Always verify the required screw size and type in your TV's manual before installation. Using incorrect screws can lead to an unstable TV stand or damage to the TV's internal components.

5. Maintenance

ReplacementScrews are designed for durability and do not require regular maintenance. However, it is recommended to periodically check the tightness of the screws securing your TV stand, especially if the TV is moved or subjected to vibrations. If any screw feels loose, gently tighten it with a Phillips head screwdriver, being careful not to overtighten. Store any unused screws in a dry place to prevent corrosion.

6. Troubleshooting

Problem	Possible Cause	Solution
Screw does not fit or tighten	Incorrect screw type (machine vs. self-tapping) or incorrect size.	Verify the required screw type and size in your TV manual. Ensure you are using the correct screw from the kit (machine for pre-threaded holes, self-tapping for plastic). Do not force screws.
TV stand feels wobbly after installation	Screws are not fully tightened or incorrect screws were used.	Gently re-tighten all screws. If wobbling persists, re-check screw type and ensure the stand is correctly seated.
Damage to TV or stand during installation	Overtightening screws or using incorrect tools.	Always use appropriate tools and avoid excessive force. If damage occurs, consult a professional for repair.

7. Specifications

- **Model Number:** RSAZN4907442
- **Screw Type:** M4x14mm (Machine and Self-Tapping)
- **Material:** Carbon Steel
- **Head Style:** Pan Head
- **Exterior Finish:** Black Oxide
- **Product Dimensions:** 6.5 x 3.75 x 0.5 inches (packaging)
- **Item Weight:** 0.32 ounces
- **Compatibility:** Designed for many Samsung TVs requiring M4x14mm screws for original factory stands.

8. Warranty and Support

For questions regarding compatibility, installation, or product support, please contact ReplacementScrews directly. While specific warranty details are not provided, ReplacementScrews aims to provide high-quality replacement parts. Please retain your purchase receipt for any inquiries.
You can typically find contact information for ReplacementScrews through the retailer where the product was purchased or by visiting the official ReplacementScrews brand store online.

© 2025 ReplacementScrews. All rights reserved.
This manual is for informational purposes only. Always exercise caution when handling electronic equipment.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C79JKQY8

More documents and user manuals: **https://manuals.plus/**