**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## VOLPAM SP06

A quick start and safety guide for the VOLPAM SP06 Electric Scooter, covering setup, riding instructions, maintenance tips, and essential safety guidelines. Learn to unfold, charge, ride, and care for your scooter.

# VOLPAM Electric Scooter SP06 User Manual

Model: SP06 | Brand: VOLPAM

## 1. Introduction

Thank you for choosing the VOLPAM Electric Scooter SP06. This foldable e-scooter is designed for adult riders, offering a convenient and efficient solution for urban commuting, short trips, and last-mile transportation. Its sturdy aluminum frame, powerful motor, and compact folding mechanism make it an ideal choice for daily use and easy storage.




The VOLPAM Electric Scooter SP06, showcasing its sleek design and accompanying mobile app interface.

## 2. Safety Information

Always prioritize safety when operating your electric scooter. Read and understand all safety warnings and instructions before use.

- Always wear a helmet and appropriate safety gear (knee pads, elbow pads) when riding.
- Do not ride in wet conditions, heavy rain, or through puddles.
- Ensure all bolts and quick-release mechanisms are securely fastened before each ride.

- Adhere to local traffic laws and regulations regarding electric scooter usage.
- Avoid riding on uneven surfaces, steep inclines, or over obstacles.
- Do not exceed the maximum weight limit of 264 pounds (120 kg).
- Maintain a safe distance from pedestrians and other vehicles.
- Familiarize yourself with the braking system before riding at higher speeds.




The scooter features a comprehensive lighting system for enhanced visibility and safety, including a bright LED headlight, taillight, and direction indicators.

## 3. Package Contents

Verify that all items are present in your package:

- VOLPAM Electric Scooter SP06 (Main Unit)

- Power Adapter/Charger
- User Manual (this document)
- Assembly Tools (if required)

# 4. Setup

## 4.1 Unfolding the Scooter

1. Place the scooter on a flat surface.
2. Locate the folding mechanism latch near the base of the handlebar stem.
3. Carefully release the latch and lift the handlebar stem until it locks into the upright position. Ensure it clicks securely.
4. Adjust the handlebar height if necessary by loosening the quick-release clamp, extending the stem, and re-tightening.

## 4.2 Charging the Battery

1. Before first use, fully charge the scooter's battery.
2. Locate the charging port, usually covered by a rubber flap, on the side of the deck.
3. Connect the power adapter to the charging port, then plug the adapter into a standard wall outlet.
4. The indicator light on the charger will change (e.g., from red to green) when charging is complete. Charging typically takes 4 hours.
5. Disconnect the charger once fully charged to prolong battery life.




The scooter's foldable design allows for easy storage and transport, fitting conveniently into car trunks.

## 5. Operating Instructions

### 5.1 Power On/Off

- To power on: Press and hold the power button on the display for a few seconds until the screen illuminates.
- To power off: Press and hold the power button again until the display turns off.

### 5.2 Riding the Scooter

1. Place one foot firmly on the deck.
2. Use your other foot to push off the ground, gaining initial momentum (kick-to-start feature).
3. Once moving, gently press the throttle lever (usually on the right handlebar) to engage the motor.

4. Place your second foot on the deck once the scooter is moving steadily.
5. To adjust speed, vary pressure on the throttle.

### 5.3 Braking

- To slow down or stop, release the throttle and gently squeeze the brake lever (usually on the left handlebar).
- The scooter features a front braking system for effective stopping.

### 5.4 Smart LED Display

The integrated LED display shows important information such as current speed, battery level, and riding mode.




The clear Smart LED Display provides real-time information for a safe and informed ride.

## 6. Maintenance

- **Cleaning:** Wipe the scooter with a damp cloth. Do not use high-pressure water or immerse the scooter in water.
- **Tires:** The scooter is equipped with 8.5-inch solid rubber wheels, which do not require air pressure checks. Regularly inspect them for wear and tear.
- **Battery Care:** Charge the battery regularly, even if not in use, to maintain its health. Avoid completely draining the battery. Store in a cool, dry place.
- **Storage:** Store the scooter indoors in a dry environment when not in use.
- **Brakes:** Periodically check the brake system for proper function and adjust if necessary.



Proper battery care is essential for maximizing the scooter's range and lifespan.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Scooter does not power on | Low battery; Power button not pressed correctly | Charge the battery; Press and hold the power button firmly. |
| Motor not engaging | No initial kick-off; Throttle not pressed; Loose connection | Ensure you kick-off to gain momentum; Press throttle fully; Check connections (if accessible). |
| Brakes not effective | Brake cable loose; Worn brake pads | Adjust brake cable tension; Replace brake pads (consult professional if unsure). |
| Unusual noises during operation | Loose components; Debris in wheel | Inspect and tighten all visible bolts; Clear any debris from wheels and motor area. |

## 8. Specifications

| Feature | Detail |
|---|---|
| Brand | VOLPAM |

| Feature | Detail |
| --- | --- |
| Model Name | SP06 |
| Color | Gray |
| Age Range (Description) | Adult |
| Special Feature | Digital Display |
| Weight Limit | 264 Pounds |
| Product Dimensions | 43"L x 16.5"W x 42"H |
| Number of Wheels | 2 |
| Wheel Material | Rubber |
| Frame Material | Aluminum |
| Item Weight | 28.5 Pounds |
| Handlebar Type | T-bar |
| Handle Height | 42.5 Inches |
| Wheel Size | 8.5 Inches |
| Wheel Type | Solid |
| Suspension Type | Spring Suspension |
| Brake Style | Front Braking |
| Charging Time | 4 Hours |
| Maximum Distance Range | 15.5 Miles |

## 9. Warranty and Support

VOLPAM offers a one-year warranty for the Electric Scooter SP06. This warranty covers manufacturing defects and material faults under normal use conditions. Please retain your proof of purchase for warranty claims.
For technical support, warranty claims, or any inquiries, please visit the official VOLPAM website or contact their customer service through the details provided on the product packaging or their brand store on Amazon:

**Visit the VOLPAM Store on Amazon**

© 2023 VOLPAM. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0C7QWJPZ5**

More documents and user manuals: **https://manuals.plus/**