Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HARPRA B0C7Z5291C

HARPRA Adjustable Watch Case Back Opener Wrench

Model: B0C7Z5291C

Introduction

This manual provides instructions for the proper use and maintenance of your HARPRA Adjustable Watch Case Back Opener Wrench. This tool is designed for safely opening most screw-back watch cases, allowing access for battery replacement or internal repairs. Please read this manual thoroughly before use to ensure safe and effective operation.

Safety Information

- Always handle the tool with care to prevent injury.
- Ensure the watch is securely held before attempting to open the case back.
- Do not apply excessive force, as this may damage the watch or the tool.
- Keep out of reach of children.
- Store the tool in a dry place to prevent rust.

Product Overview

The HARPRA Adjustable Watch Case Back Opener Wrench is a compact and versatile tool. It features an adjustable jaw mechanism controlled by a knurled screw, allowing it to adapt to various watch case diameters.



Figure 1: Main view of the HARPRA Watch Case Back Opener. This image shows the blue metal body, the central knurled adjustment screw, and the two adjustable pins used to grip the watch case back.



Figure 2: Top view of the HARPRA Watch Case Back Opener. This perspective highlights the knurled adjustment screw and the precise alignment of the two pins.



Figure 3: Side view of the HARPRA Watch Case Back Opener. This view shows the slim profile of the tool and the robust construction of the metal body.

Setup

Before using the tool, ensure your workspace is clean and well-lit. Gather any other necessary tools, such as a watch holder or a soft cloth to protect the watch surface.

1. Unpack the watch case opener from its box.
2. Inspect the tool for any visible damage or defects.
3. Familiarize yourself with the adjustment mechanism by turning the knurled screw to observe the movement of the pins.

Operating Instructions

Follow these steps to safely open a screw-back watch case:

1. **Prepare the Watch:** Place the watch face down on a soft, clean surface or secure it in a watch holder to prevent movement and scratches.
2. **Adjust the Tool:** Identify the notches or grooves on the watch case back. Turn the knurled screw on the HARPRA opener to adjust the distance between the two pins so they align perfectly with two opposing notches on the watch case back.
3. **Position the Tool:** Carefully place the pins of the opener into the corresponding notches on the watch case back. Ensure a snug fit to prevent slipping.
4. **Apply Pressure and Turn:** While applying gentle downward pressure to keep the pins engaged, slowly turn the HARPRA opener counter-clockwise. The case back should begin to unscrew.
5. **Remove Case Back:** Once the case back is loose, you can usually unscrew it completely by hand.



Figure 4: The HARPRA Watch Case Back Opener being used to open a watch. This image demonstrates how the tool's pins engage with the watch case back for rotation.

To close the watch case back, reverse the process, turning the opener clockwise until the case back is securely

tightened. Do not overtighten.

Maintenance

- **Cleaning:** After each use, wipe the tool with a clean, dry cloth to remove any dust or debris.
- **Storage:** Store the opener in its original box or a protective case in a dry environment to prevent corrosion and damage.
- **Inspection:** Periodically check the pins and adjustment mechanism for wear or damage. Replace the tool if any critical components are compromised.

Troubleshooting

Problem	Possible Cause	Solution
Tool slips off the case back.	Pins not properly aligned or insufficient downward pressure.	Ensure pins are perfectly seated in the notches. Apply firm, steady downward pressure while turning.
Case back does not turn.	Case back is too tight, rusted, or tool is not adjusted correctly.	Double-check pin alignment. For very tight cases, consider professional assistance to avoid damage. Do not force.
Pins are bent or damaged.	Excessive force or improper storage.	The tool may need to be replaced. Ensure proper handling and storage.

Specifications

Brand: HARPRA

Model: B0C7Z5291C

Color: Blue

Material: Metal

Dimensions (L x W x T): Approximately 6.6 cm x 2.6 cm x 1 cm (2.6 in x 1.02 in x 0.39 in)

Adjustable Jaw Distance: 1 cm to 5 cm (0.39 in to 1.97 in)

Purpose: Opening most screw-back watch cases

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any support inquiries, please refer to the seller or retailer from whom you purchased the product. Keep your purchase receipt as proof of purchase.

© 2024 HARPRA. All rights reserved.
This manual is for informational purposes only. HARPRA is not responsible for any damage to watches or injury caused by improper use of this tool.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7Z5291C

More documents and user manuals: **https://manuals.plus/**