Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 60-R4200CS

Braun Series 6 Rechargeable Shaver 60-R4200CS User Manual

1. Introduction

Thank you for choosing the Braun Series 6 Rechargeable Shaver, model 60-R4200CS. This electric shaver is designed to provide a gentle yet deep shave, featuring Braun's unique S-shaped close-contact shaving head. Please read this manual thoroughly before first use to ensure safe and optimal performance of your device. Keep this manual for future reference.

2. Safety Information

To reduce the risk of electric shock, injury, or damage to the product, please observe the following safety precautions:

- **Do not use the shaver while it is charging.** Always disconnect the shaver from the power source before use.
- This appliance is suitable for cleaning under running tap water.
- Do not open the appliance. The built-in rechargeable battery can only be replaced by an authorized Braun Service Centre.
- Do not use the shaver if the foil or trimmer is damaged, as this may cause skin injury.
- Keep the appliance dry.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

3. Product Overview

The Braun Series 6 60-R4200CS is a high-performance electric shaver designed for comfort and efficiency. It features a flexible shaving head that adapts to your facial contours for a close and gentle shave. This model supports both wet and dry shaving.



Image 1: Braun Series 6 Shaver 60-R4200CS. This image shows the main unit of the Braun Series 6 electric shaver, highlighting its ergonomic design and shaving head.

Key Features:

- **S-shaped Close-Contact Shaving Head:** Designed for optimal skin contact and a gentle, deep shave.
- **Wet & Dry Functionality:** Suitable for use in the shower or with foam/gel for a refreshing shave.
- **Rechargeable Battery:** Provides up to 50 minutes of cordless shaving on a full charge.
- **Foil Shaver System:** Efficiently captures hairs for a smooth finish.

4. Setup

4.1 Initial Charging

1. Ensure the shaver is turned off.
2. Connect the shaver to the power cord and plug it into an electrical outlet.
3. The charging indicator light will illuminate, indicating that the shaver is charging.
4. Allow the shaver to charge for approximately 1 hour for a full charge, which provides up to 50 minutes of shaving time. For a quick shave, a 5-minute charge is sufficient for one shave.
5. Once fully charged, disconnect the shaver from the power source.

4.2 Attaching/Detaching Shaving Head

Your shaver comes with a pre-attached shaving head. If you need to remove or attach it:

- To detach: Press the release buttons on the sides of the shaving head and pull it upwards.
- To attach: Align the shaving head with the shaver body and press it down until it clicks into place.

5. Operating Instructions

5.1 General Shaving Tips

- Ensure your shaver is fully charged before use.
- For best results, shave before washing your face.

- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin and shave against the direction of hair growth.
- Apply gentle pressure; do not press too hard.

5.2 Dry Shaving

For a quick and convenient shave, use the shaver on dry skin. Ensure your skin is clean and free of oils or lotions.

5.3 Wet Shaving (with foam/gel or in the shower)

The Braun Series 6 is 100% waterproof and can be used with shaving foam or gel, or in the shower for a refreshing and comfortable shave.

- Apply shaving foam or gel to your face.
- Shave as usual, rinsing the shaver head under running water frequently to prevent clogging.
- After shaving, rinse your face thoroughly and clean the shaver as described in the "Cleaning and Maintenance" section.

6. Cleaning and Maintenance

Regular cleaning ensures optimal shaving performance and extends the life of your shaver.

6.1 Quick Cleaning (Daily)

- After each shave, turn off the shaver.
- Rinse the shaver head under hot running tap water until all residue is removed. You can use liquid soap if desired.
- Shake off excess water and let the shaver air dry with the shaving head open.

6.2 Thorough Cleaning (Weekly)

- Turn off the shaver and detach the shaving head.
- Tap out any loose hairs.
- Rinse the shaving head and the inner cutting elements thoroughly under running water.
- Allow all parts to dry completely before reattaching the shaving head.
- Do not use abrasive cleaners or harsh chemicals.

6.3 Replacing Shaving Parts

To maintain 100% shaving performance, replace the shaver head (foil and cutter block) every 18 months, or when worn. The replacement part number can be found on the shaver head itself or in the product packaging.

7. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes.
Shaver does not shave effectively.	Shaving head is dirty or worn.	Clean the shaving head thoroughly. Replace the shaving head if it is older than 18 months or visibly damaged.

Problem	Possible Cause	Solution
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure you are shaving against the grain with gentle pressure. Consider using a shaving foam/gel for sensitive skin. Allow skin to adapt to the new shaver.

If the problem persists, please contact Braun customer service.

8. Specifications

Model: 60-R4200CS

Brand: Braun

Type: Rechargeable Electric Foil Shaver

Color: Red

Power Source: Battery-powered (Rechargeable)

Battery Life: Up to 50 minutes (on full charge)

Charging Time: Approx. 1 hour for full charge, 5 minutes for one shave.

Features: Wet & Dry use, S-shaped close-contact shaving head

Dimensions (approx.): 25.6 x 13.7 x 6.7 cm

Weight (approx.): 540 g

Blade Material: Metal

9. Warranty and Support

This Braun product comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Braun website. For technical support, replacement parts, or service, please contact your local Braun service center or authorized dealer. Keep your purchase receipt as proof of purchase.

You can find more information and support on the official Braun website:www.braun.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9S5XBLL

More documents and user manuals: **https://manuals.plus/**