Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ARZOPA P101W

ARZOPA Frameo Digital Picture Frame User Manual

Model: P101W
Brand: ARZOPA

1. Introduction

The ARZOPA Frameo Digital Picture Frame is a smart WiFi-enabled device designed to display and share photos and videos with ease. Featuring a 10.1-inch IPS touch screen with 1280x800 resolution, it offers a vibrant display for your cherished memories. With 32GB of built-in storage and support for SD cards up to 128GB, you can store a vast collection of media. The frame supports auto-rotate and slideshow functions, making it versatile for various placements and viewing experiences. It is an ideal way to keep families connected by sharing moments instantly from anywhere using the Frameo app.



Figure 1.1: The ARZOPA Frameo Digital Picture Frame and its companion mobile application.

2. Safety Information

- Ensure the device is placed on a stable, flat surface to prevent accidental falls.
- Keep the device away from water, moisture, and extreme temperatures.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Use only the provided power adapter to prevent damage.
- Avoid blocking ventilation openings to prevent overheating.
- Keep out of reach of children and pets.
- Clean the screen with a soft, dry cloth. Avoid abrasive cleaners.

3. Package Contents

Please check the package contents upon unboxing:

- ARZOPA Frameo Digital Picture Frame (P101W)
- Power Adapter
- User Manual
- Stand (pre-attached or separate)

4. Product Overview

Familiarize yourself with the components of your digital picture frame.



Figure 4.1: Rear view of the ARZOPA Digital Picture Frame, highlighting the speaker, wall hole, power button, Reset USB-C Port, SD Card Slot, DC Power Port, and Stand.

- **Speaker:** For audio playback of videos.
- **Wall Hole:** For mounting the frame on a wall.
- **Power Button:** To turn the frame on/off or put it to sleep.
- **Reset USB-C Port:** For resetting the device or connecting to a computer (functionality may vary).
- **SD Card Slot:** To insert an SD card for expanded storage (max. 128GB, not included).
- **DC Power Port:** For connecting the power adapter.
- **Stand:** Adjustable stand for horizontal or vertical placement.
- **Touch Screen:** The main display for interacting with the frame.

5. Setup

Follow these steps for the initial setup of your ARZOPA digital picture frame.

1. **Power On:** Connect the power adapter to the DC Power Port and plug it into a wall outlet. The frame will automatically power on.
2. **Initial Configuration:** Follow the on-screen prompts to select your language, time zone, and connect to a Wi-Fi network. The frame requires a 2.4GHz Wi-Fi connection for sharing features.
3. **Download Frameo App:** On your smartphone (Android or iOS), download the free "Frameo" app from the Google Play Store or Apple App Store.



Figure 5.1: Visual guide for downloading the Frameo app and connecting to the digital frame.

4. **Connect Frame to App:** Open the Frameo app on your phone. On the digital frame, navigate to "Add friend" or "Connect to app" to generate a unique code. Enter this code into the Frameo app on your smartphone. This code is valid for 12 hours.
5. **Start Sharing:** Once connected, you can begin sending photos and videos to your frame.

6. Operating Instructions

6.1 Sharing Photos and Videos

The primary function of the ARZOPA digital frame is to receive and display media shared from the Frameo app.

1. Open the Frameo app on your smartphone.
2. Select the photos or videos you wish to send. Note: Videos are limited to 15 seconds, and it is recommended not to transfer more than 10 pictures at a time for optimal performance.
3. Choose the recipient frame(s) from your connected devices.
4. Add an optional caption to your media.
5. Confirm and send. The media will appear on your digital frame.



Figure 6.1: Illustration of instant wireless sharing from multiple users to the digital frame.

6.2 Auto-Rotate and Slideshow

The frame automatically adjusts the orientation of photos and videos based on its physical placement (portrait or landscape). The dynamic slideshow feature cycles through your stored media.



Figure 6.2: Examples of multiple placement methods, including landscape, portrait, and wall-mounted, with auto-rotate functionality.

Note: This model does not include a motion sensor feature.

6.3 Using the Touch Screen

Navigate the frame's interface directly using the touch screen, similar to a smartphone. Swipe to browse photos, tap to select options, and pinch to zoom (if supported by the software version).

7. Maintenance

- **Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Do not spray cleaners directly onto the screen.
- **Storage:** If storing the frame for an extended period, power it off and disconnect it from the power source. Store in a cool, dry place.
- **Software Updates:** Periodically check for software updates through the frame's settings menu to ensure optimal performance and new features.

8. Troubleshooting

Problem	Possible Cause	Solution
Frame does not power on.	No power, faulty adapter, or internal issue.	Ensure power adapter is securely connected to the frame and wall outlet. Try a different outlet. If problem persists, contact support.
Cannot connect to Wi-Fi.	Incorrect password, out of range, or router issue.	Double-check Wi-Fi password. Move frame closer to router. Restart router. Ensure it's a 2.4GHz network.
Photos/Videos not appearing on frame.	Frame not connected to app, app not sending, or network issue.	Verify frame is online and connected to the Frameo app. Check your phone's internet connection. Ensure you are not sending more than 10 pictures at once or videos longer than 15 seconds.
Screen is unresponsive.	Temporary software glitch.	Restart the frame by holding the power button until it turns off, then power it back on. If unresponsive, use the reset button (if available, refer to Product Overview).

9. Specifications

Feature	Detail
Model Number	P101W
Screen Size	10.1 Inches
Resolution	1280x800
Internal Memory	32GB
External Storage	Supports SD card (max. 128GB, not included)
Connectivity	Wi-Fi (2.4GHz)
Compatible Devices	Android, iOS, Smartphone (via Frameo app)
Product Dimensions	10.35 x 7.17 x 0.99 inches
Item Weight	1.14 pounds



Figure 9.1: Key specifications of the ARZOPA 10.1 inch Digital Photo Frame.



Figure 9.2: Illustration of the 178° HD Anti-glare Screen and wide viewing angle.

10. Warranty and Support

Information regarding product warranty and customer support was not available in the provided product data. Please refer to the product packaging or the manufacturer's official website for detailed warranty terms and contact information for support.

© 2024 ARZOPA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I factory reset my ARZOPA P101W digital picture frame?

To reset your ARZOPA P101W digital picture frame, you can use the physical reset port or the software settings menu. Please note that a factory reset will typically remove all photos, friends, and settings...

Read full answer

Open the live page

https://manuals.plus/asin/B0CBKDP5DM

More documents and user manuals: **https://manuals.plus/**