Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEGA VHTH-38

Vega Power Lite Beard Trimmer VHTH-38 Instruction Manual

Model: VHTH-38 | Brand: VEGA

1. Product Overview

The Vega Power Lite Beard Trimmer VHTH-38 is designed for precise and effortless beard grooming. It features durable stainless steel blades, a long-lasting battery, and multiple length settings to achieve your desired style. This trimmer offers both corded and cordless operation for convenience.



Image 1.1: The Vega Power Lite Beard Trimmer with its two comb attachments.

Key Features:

- **Stainless Steel Blades:** High-quality blades for durability and precision.
- **40 Length Settings:** Adjustable trimming range from 0.5mm to 20mm with two comb attachments.
- **90 Minutes Runtime:** Provides up to 90 minutes of cordless operation on a single charge.
- **Corded & Cordless Use:** Offers flexibility for use with or without the power cord.
- **USB Type-C Charging:** Convenient charging via a Type-C USB cable.
- **Washable Blades:** Easy to clean for hygienic maintenance.
- **Travel Lock:** Prevents accidental power-ups during travel.
- **Lightweight & Ergonomic Design:** Ensures comfortable handling and precise control.

2. Safety Information

Please read and understand all safety instructions before using the trimmer to prevent injury or damage.

- Do not use the trimmer while charging.
- Keep the trimmer away from water and moisture to avoid electric shock.
- Do not use the trimmer on irritated or damaged skin.
- Keep out of reach of children.
- Use only the provided charger and accessories.
- Unplug the trimmer before cleaning.

3. Setup and Charging

3.1 Initial Charge

Before first use, fully charge the trimmer. Connect the USB Type-C cable to the trimmer and a compatible USB power adapter (not included). The charging indicator light will illuminate. A full charge takes approximately 90 minutes and provides up to 90 minutes of runtime.



Image 3.1: The trimmer features a convenient USB Type-C charging port.

3.2 Attaching Comb Attachments

The trimmer comes with two comb attachments to achieve different beard lengths. To attach a comb, align its grooves with the trimmer head and slide it on until it clicks into place. To remove, gently push the comb upwards and away from the trimmer head.



Image 3.2: The two comb attachments allow for 40 length settings from 0.5mm to 20mm.

4. Operating Instructions

4.1 Powering On/Off

Press the power button once to turn the trimmer on. Press it again to turn it off.

4.2 Adjusting Length Settings

With a comb attachment in place, rotate the length adjustment dial on the trimmer body to select your desired trimming length. The settings range from 0.5mm to 20mm.

4.3 Trimming Technique

For best results, ensure your beard is clean and dry. Hold the trimmer with the blades facing upwards and move it against the direction of hair growth. Use light, even strokes. For detailed styling or edging, remove the comb attachment and use the bare blades carefully.



Image 4.1: The trimmer is designed for comfortable and precise beard grooming.

4.4 Travel Lock Function

To activate the travel lock, press and hold the power button for 3 seconds. The trimmer will lock, preventing accidental activation. To unlock, press and hold the power button for another 3 seconds.



Image 4.2: The travel lock feature ensures safe transport of the trimmer.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your trimmer.

5.1 Cleaning the Blades

1. Ensure the trimmer is turned off and unplugged from any power source.
2. Remove the comb attachment.
3. The blades are washable. Carefully rinse the blade head under running water to remove hair clippings. Do not immerse the entire trimmer in water.
4. Allow the blades to air dry completely before reattaching or storing the trimmer.



Image 5.1: The washable blades simplify the cleaning process.

5.2 Oiling the Blades

Periodically apply a small drop of lubricating oil (if provided, or a suitable light machine oil) to the blades to maintain their sharpness and smooth operation. Turn the trimmer on for a few seconds to distribute the oil evenly.

6. Troubleshooting

If you encounter issues with your trimmer, refer to the following common solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted or travel lock is active.	Charge the trimmer. Deactivate travel lock by pressing and holding the power button for 3 seconds.

Problem	Possible Cause	Solution
Poor trimming performance.	Blades are dull, dirty, or not oiled.	Clean the blades thoroughly. Apply lubricating oil. Consider blade replacement if performance does not improve.
Trimmer pulls hair.	Blades are dirty, not oiled, or comb attachment is incorrectly fitted.	Clean and oil the blades. Ensure the comb attachment is securely in place.

7. Specifications

Feature	Detail
Model Number	VHTH-38
Blade Material	Stainless Steel
Length Settings	40 (0.5mm - 20mm)
Comb Attachments	2
Runtime	Up to 90 minutes
Charging Time	Approx. 90 minutes
Charging Type	USB Type-C
Power Source	Battery Powered
Item Weight	102 g
Product Dimensions	16.7 x 3.7 x 3.4 cm
Included Components	1 Trimmer, 2 Combs with USB charging
Country of Origin	India

8. Warranty and Support

The Vega Power Lite Beard Trimmer VHTH-38 comes with a**1-year warranty** from the date of purchase.

For customer support, service, or warranty claims, please contact:

- **Manufacturer:** RISE APPLIANCES PRIVATE LIMITED
- **Address:** PLOT NO. 31, SECTOR-155, 3RD FLOOR, NOIDA-201310, U.P. (INDIA)
- **Customer Care:** +91 08069496949

© 2023 VEGA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBMTG6D5

More documents and user manuals: **https://manuals.plus/**