VIDCASTIVE BC10

VIDCASTIVE BC10 1080P HD Body Camera User Manual

Model: BC10 | Brand: VIDCASTIVE

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your VIDCASTIVE BC10 1080P HD Body Camera. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize its performance. This body camera is designed for reliable video recording, photo capture, and audio recording in various scenarios, featuring a 180° rotatable lens and enhanced night vision capabilities.

2. Product Overview

2.1 Package Contents

- VIDCASTIVE BC10 1080P Body Camera
- 64GB MicroSD Card
- USB Card Reader
- USB Cable
- Reset Pin
- User Manual (this document)

2.2 Device Components

Familiarize yourself with the various parts of your body camera:

Image 1: Front and side view of the VIDCASTIVE BC10 Body Camera, showing the rotatable lens, display screen, and control buttons.

- **180° Rotatable Lens:** Allows flexible adjustment of the recording angle.
- **1.3-inch Color Display Screen:** For real-time preview, playback, and menu navigation.
- **Control Buttons:** Power, OK, Up, Down, Return for device operation.
- **Microphone:** For audio recording.
- **USB Port:** For charging and data transfer.
- **MicroSD Card Slot:** For storage.
- **Reset Hole:** For device reset.
- **Clip:** For attaching the camera to clothing or gear.

Image 2: Detailed view of the VIDCASTIVE BC10 Body Camera's control buttons, including Power, OK, Up, Down, and Return buttons.

3. Setup

3.1 Charging the Battery

Before first use, fully charge the camera's built-in 1200mAh battery. Connect the camera to a power source (e.g., computer USB port or USB wall adapter) using the provided USB cable. The charging indicator will show the charging status. A full charge typically takes approximately 3 hours.

Image 3: The VIDCASTIVE BC10 Body Camera connected via USB cable to a laptop for charging, illustrating the charging process.

3.2 Inserting the MicroSD Card

The camera comes with a 64GB MicroSD card pre-installed or included separately. If inserting or replacing, ensure the camera is powered off. Locate the MicroSD card slot and gently insert the card with the gold contacts facing down until it clicks into place. The camera supports up to a 128GB TF card.

3.3 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen illuminates.
- **To Power Off:** Press and hold the Power button until the screen turns off.

4. Operating Instructions

4.1 Video Recording

From the main interface, select the video recording mode. Press the OK button to start recording. A recording indicator (e.g., a red dot or flashing icon) will appear on the screen. Press OK again to stop recording. Videos are saved automatically to the MicroSD card in 1080P resolution.

Image 4: The VIDCASTIVE BC10 Body Camera displaying a recording, highlighting its 6-hour continuous recording capability and various functions like video, photo, and audio recording.

4.2 Photo Capture

From the main interface, select the photo capture mode. Press the OK button to take a photo. Photos are saved to the MicroSD card.

4.3 180° Rotatable Lens

The camera's lens can be manually rotated 180 degrees to capture footage from various angles. Adjust the lens to your desired orientation before recording or taking photos.

Image 5: Illustrations of the VIDCASTIVE BC10 Body Camera's 180° rotatable lens, showing its flexibility for different mounting positions and recording angles (0°, 90°, 180°).

4.4 Night Vision

The camera features enhanced night vision with a high-performance CMOS sensor and 5 spotlights. In low-light conditions, the camera automatically adjusts to provide clear video footage. Manual activation of night vision may be available through the menu settings.

Image 6: Comparison image showing the VIDCASTIVE BC10 Body Camera's 1080P HD resolution performance in both well-lit (Day) and low-light (Night) conditions, demonstrating its night vision capabilities.

4.5 Playback Mode

Navigate to the playback mode using the Up/Down buttons. Select a recorded file (video or photo) using the Up/Down buttons and press OK to view it on the 1.3-inch display screen.

4.6 USB Mode / PC Camera Functionality

When connected to a computer via USB, the camera can function in two modes:

- **Mass Storage:** Access recorded files on the MicroSD card directly from your computer.
- **PC Camera (Webcam):** Use the body camera as a webcam for video calls or streaming. Select this option on the camera's screen when prompted after connecting to a PC.

The camera also supports recording while charging when connected via USB.

Image 7: The VIDCASTIVE BC10 Body Camera connected to a laptop via USB, illustrating its USB mode for memory access, charging while recording, and PC camera functionality.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera body and lens. Avoid abrasive cleaners or solvents.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the camera regularly, even if not in use for extended periods.
- **Firmware Updates:** Check the manufacturer's website periodically for any available firmware updates to improve performance or add features.

6. Troubleshooting

- **Camera not turning on:**

  Ensure the battery is charged. Connect the camera to a power source and try again. If unresponsive, use the provided reset pin to press the reset hole.

- **Recording issues (e.g., not saving, corrupted files):**

  Check if the MicroSD card is properly inserted and has sufficient free space. Format the MicroSD card (this will erase all data) through the camera's settings or on a computer. Ensure the card is not faulty.

- **Poor video/photo quality:**

  Ensure the lens is clean and free from smudges. Check lighting conditions; while the camera has night vision, extreme darkness may still affect quality. Ensure the camera's resolution settings are set to 1080P.

- **Camera freezes or becomes unresponsive:**

  Use the provided reset pin to press the reset hole. This will restart the device without losing data.

- **Computer not recognizing the camera in USB mode:**

  Try a different USB port or cable. Ensure the camera is powered on and the correct USB mode (Mass Storage or PC Camera) is selected on the camera's screen.

7. Specifications

Feature	Specification
Model Number	BC10
Video Resolution	1080P HD
Lens Rotation	180°
Display Screen	1.3 inches (color)
Battery Capacity	1200mAh Lithium Ion
Recording Time	6-8 hours (continuous)
Charging Time	Approx. 3 hours
Memory Card Included	64GB MicroSD
Max Memory Card Support	128GB TF Card
Night Vision	Yes, with 5 spotlights
Connectivity	Wired (USB)
Item Weight	1.9 ounces
Package Dimensions	4.8 x 3.54 x 1.69 inches

8. Warranty and Support

Your VIDCASTIVE BC10 Body Camera comes with a**1-year warranty** from the date of purchase. Additionally, VIDCASTIVE provides **lifetime technical support** for this product. If you encounter any issues or have questions not covered in this manual, please contact VIDCASTIVE customer support

through the official website or your purchase platform for assistance.
For further information or support, please visit the VIDCASTIVE Store on Amazon.