ANIMAT3D MSPSNOWMI

ANIMAT3D Inflatable Mr. Chill Animated Snowman Instruction Manual

Model: MSPSNOWMI

Introduction

Thank you for choosing the ANIMAT3D Inflatable Mr. Chill Animated Snowman. This product features a built-in projector and speaker to display animated content, enhancing your outdoor holiday decorations. This manual provides essential information for safe and proper setup, operation, and maintenance of your inflatable snowman.

Image: ANIMAT3D Brand Logo

Safety Information

Please read and understand all safety instructions before operating this product. Failure to follow these instructions may result in injury or damage to the product.

- **Adult Supervision:** Adult supervision is recommended during setup and operation, especially if children are present.
- **Placement:** Do not place the inflatable near sharp objects, open flames, or heat sources. Ensure the area is clear of debris.
- **Securing the Product:** Always properly secure the inflatable snowman using the provided stakes and tethers to prevent it from being blown away by wind.
- **Electrical Safety:** Use only the provided power cord and adapter. Ensure all electrical connections are dry and

protected from moisture. Do not operate with damaged cords or plugs.

- **Weather Resistance:** While designed for outdoor use, avoid prolonged exposure to extreme weather conditions such as heavy rain, snowstorms, or strong winds. Disconnect and store the product during severe weather.
- **Ventilation:** Ensure the fan intake is not obstructed to allow for proper inflation and operation.

Package Contents

Verify that all components are present before beginning setup:

- ANIMAT3D Inflatable Mr. Chill Snowman with built-in projector and speaker
- Power cord and adapter
- Stakes and tethers for securing
- Instruction Manual (this document)

Image: The product box for the Inflatable Mr. Chill, showing the snowman design and key features.

Setup Instructions

1. **Unpack:** Carefully remove the inflatable snowman and all accessories from the packaging.
2. **Placement:** Choose a flat, clear outdoor location for the inflatable. Ensure there are no sharp objects or obstructions that could damage the material or block the fan.
3. **Positioning:** Unfold the inflatable snowman and position it upright. Ensure the fan intake at the base is clear and unobstructed.
4. **Connect Power:** Connect the power cord to the inflatable and then plug the adapter into a standard outdoor-rated electrical outlet. The inflatable will begin to self-inflate immediately.
5. **Secure:** Once fully inflated (this may take a few minutes), use the provided stakes and tethers to secure the inflatable to the ground. Attach tethers to the loops on the inflatable and stake them firmly into the ground at an angle. This prevents the inflatable from moving or falling over in windy conditions.

Image: The ANIMAT3D Inflatable Mr. Chill snowman, approximately 6 feet tall, set up in an outdoor yard, demonstrating its size and appearance.

Image: A close-up of the Inflatable Mr. Chill, highlighting its "Plug and Play" and "Self Inflating" features, with the encapsulated projector visible.

Operating Instructions

The ANIMAT3D Inflatable Mr. Chill is designed for simple operation.

- **Power On:** Once plugged in, the inflatable will automatically inflate, and the internal projector and speaker will activate, beginning the animated content playback.
- **Content Playback:** The unit includes approximately 30 minutes of pre-loaded animated content with audio. This content will play sequentially.
- **Volume Control:** Locate the volume control buttons on the unit (refer to the product diagram if available, typically near the base or control panel). Use these buttons to adjust the audio output level.
- **Skip Content:** A "Skip" button is available to advance to the next animation in the sequence.
- **Automatic Loop:** The content is designed to play for approximately 30 minutes. After this duration, the unit will stop playback. To restart the content, you will need to manually press the play/skip button again or cycle the power.
- **Optimal Viewing:** For best projection visibility, operate the inflatable in low-light conditions, such as dusk or night.

Image: Three ANIMAT3D Inflatable Mr. Chill snowmen, illustrating the product's animated capabilities and the "30 Total Minutes of Animation" feature.

Image: A close-up view of the Inflatable Mr. Chill's face at night, showing the animated projection clearly visible on its surface.

Maintenance

- **Cleaning:** To clean the inflatable, wipe it gently with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the unit is completely dry before storing.
- **Storage:** When not in use, deflate the snowman by unplugging it. Once deflated, fold it neatly and store it in a cool, dry place, away from direct sunlight and pests.
- **Inspection:** Periodically inspect the inflatable for any tears, punctures, or damage to the fabric, fan, or electrical components. Repair small tears with an appropriate patch kit (not included) to prevent further damage or air leakage.

Troubleshooting

Problem	Possible Cause	Solution
Inflatable does not inflate.	◦ Not plugged in or power issue. ◦ Fan intake blocked. ◦ Tear in fabric.	◦ Ensure power cord is securely plugged into a working outlet. ◦ Check that the fan intake at the base is clear of obstructions. ◦ Inspect for tears and patch if necessary.

Problem	Possible Cause	Solution
Projector image is dim or unclear.	◦ Too much ambient light. ◦ Projector lens obstructed or dirty.	◦ Operate in darker conditions (dusk or night). ◦ Gently clean the projector lens if accessible and dirty.
No sound or low volume.	◦ Volume set too low. ◦ Speaker obstructed.	◦ Adjust volume using the control buttons. ◦ Ensure the speaker output is not covered.
Content stops after 30 minutes.	◦ Normal operation.	◦ This is by design. Press the play/skip button to restart the content or cycle power.

Specifications

Brand	ANIMAT3D
Model Number	MSPSNOWMI
Theme	Cartoon (Snowman)
Color	White
Occasion	Christmas
Material	Vinyl
Item Dimensions (L x W x H)	Approximately 73 inches (6 feet) tall. (Note: Product specifications list 1 x 1 x 1 inches, which is likely a packaging or internal component dimension. The product is designed to be over 6 feet tall when inflated.)
Light Color	Bright White
Special Features	Self Inflating, Weather Resistant, Built-in Projector, Built-in Speaker, 30 Minutes of Animated Content
Item Weight	3.1 Pounds
UPC	603625574590
Manufacturer	Mindscope

Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official ANIMAT3D or Mindscope website. It is recommended to retain your proof of purchase for any warranty claims.

© 2025 ANIMAT3D. All rights reserved.