Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy 2SKSK1849B0L2

Skullcandy Barrel Bluetooth Boombox Speaker User Manual

Model: 2SKSK1849B0L2
Brand: Skullcandy

1. Getting Started

1.1 What's in the Box

- SKDY Barrel™ Wireless Speaker
- 1 x Wall Charger
- 1 x User Manual
- 1 x Nylon Carry Strap

1.2 Product Overview

The Skullcandy Barrel Bluetooth Boombox Speaker is a portable, water-resistant audio device designed for robust sound and versatile use. It features an integrated handle and includes a nylon carry strap for easy transport. The speaker incorporates an LED light bar and intuitive controls on its top panel.



Figure 1: Front view of the Skullcandy Barrel speaker, showcasing the main body and LED light bar.



Figure 2: Detailed view of the control panel and LED light bar on the Skullcandy Barrel speaker.



Figure 3: Close-up of the USB-C, USB-A, and AUX IN ports located on the speaker.

2. Setup

2.1 Charging the Speaker

Before initial use, fully charge your Skullcandy Barrel speaker. Use the provided wall charger and USB-C cable to connect the speaker to a power outlet. The battery indicator lights on the control panel will show charging progress. A full charge provides up to 12 hours of playback time.

2.2 Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Press and hold the Bluetooth button on the control panel until the LED light bar flashes, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Skullcandy Barrel" from the list of devices.
5. Once connected, the LED light bar will show a solid color, and a confirmation tone will sound.

3. Operating Instructions

3.1 Power On/Off

- To power on, press the Power button.
- To power off, press and hold the Power button until the speaker shuts down.

3.2 Volume Control

- To increase volume, press the '+' button.
- To decrease volume, press the '-' button.

3.3 Playback Control

- To play or pause audio, press the Play/Pause button.
- To skip to the next track, double-press the Play/Pause button.
- To go to the previous track, triple-press the Play/Pause button.

3.4 LED Lightshow Mode

The speaker features an integrated LED light bar that syncs with the music. Press the Light Mode button to cycle through different light patterns and colors.

3.5 Multi-Link Feature

The Multi-Link feature allows you to connect up to 99 Skullcandy Bluetooth speakers for a synchronized audio experience. To activate:

1. Ensure all speakers are powered on and not connected to any device.
2. On the primary speaker, press and hold the Multi-Link button until a confirmation tone sounds.
3. On secondary speakers, press the Multi-Link button briefly. They will automatically connect to the primary speaker.



Figure 4: Illustration of the Multi-Link feature connecting multiple Skullcandy speakers.

3.6 USB-C & USB-A Output Charging

The Skullcandy Barrel speaker can also function as a power bank to charge your mobile devices. Connect your device to the USB-C or USB-A output port on the speaker using a compatible cable.

3.7 Bass Boost Mode

Activate Bass Boost mode for enhanced low-frequency sound. Refer to the specific button on the control panel (often indicated by a bass icon) to toggle this feature on or off.

4. Maintenance

4.1 Water Resistance (IPX5)

The Skullcandy Barrel speaker is IPX5 water-resistant, meaning it can withstand splashes and light rain. It is not designed for submersion. Ensure all port covers are securely closed before exposing the speaker to water.



Figure 5: Visual representation of the speaker's IPX5 water resistance rating.

4.2 Cleaning

To clean the speaker, use a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish or internal components.

4.3 Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to maintain battery health.

5. Troubleshooting

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
Speaker does not power on	Low battery; Power button not pressed correctly	Charge the speaker; Press and hold the Power button for 3 seconds
Cannot pair via Bluetooth	Speaker not in pairing mode; Device Bluetooth off; Too far from device	Ensure speaker is in pairing mode (flashing LED); Turn device Bluetooth on/off; Move device closer to speaker
Poor sound quality	Low battery; Device volume too low/high; Obstructions between devices	Charge the speaker; Adjust volume on both speaker and device; Remove obstructions or move closer
LED lights not working	Light mode off; Malfunction	Press the Light Mode button to activate; Contact customer support if issue persists
Multi-Link not connecting	Speakers not in Multi-Link mode; Too many speakers; Distance issue	Ensure all speakers are in Multi-Link mode; Check compatibility; Reduce distance between speakers

6. Specifications

Feature	Detail
Model Name	2SKSK1849
Speaker Type	Stereo
Wireless Technology	Bluetooth 5.3
Water Resistance	IPX5 (Splash-proof)
Battery Life	Up to 12 hours
Charging Output	USB-C & USB-A
Product Dimensions (D x W x H)	9.6" x 22.05" x 11.81"
Item Weight	14.33 Pounds
Power Source	Battery Powered (1 Lithium Ion battery included)
Speaker Maximum Output Power	10 Watts
Frequency Response	30 Hz

7. Warranty and Support

7.1 Limited Warranty

The Skullcandy Barrel Bluetooth Boombox Speaker comes with a limited warranty. Please refer to the warranty card included in your product packaging or visit the official Skullcandy website for detailed terms and conditions.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Skullcandy customer support through their official website or the contact information provided in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCQP5C3V

More documents and user manuals: **https://manuals.plus/**