Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirs46rqnf0g5b

Dpofirs 4K Digital Camera User Manual

Model: Dpofirs46rqnf0g5b

Introduction

This manual provides comprehensive instructions for the operation, setup, maintenance, and troubleshooting of your Dpofirs 4K Digital Camera. Please read this manual carefully before using the camera to ensure proper and safe operation.
The Dpofirs 4K Digital Camera is a versatile device featuring 64MP resolution, 4K video recording, HD night vision, 16X digital zoom, and a 3-inch color display. It is designed for portability and includes a fill light for enhanced photography in various conditions.

Package Contents

Upon unpacking, please verify that all items listed below are present:

- 1 x Dpofirs 4K Digital Camera
- 1 x Camera Manual
- 1 x Fill Light
- 1 x Microphone
- 1 x Microphone Cable
- 1 x Microphone Manual
- 1 x Folding Handle
- 1 x Hot Shoe Expansion Mount
- 1 x Hot Shoe Expansion Mount Fixing Screw
- 1 x Handle Fixing Camera Screw
- 1 x Macro Lens
- 1 x Lens Cap
- 1 x Lens Lanyard
- 1 x Hex Wrench
- 1 x Camera Lanyard
- 1 x Charging Cable

Product Overview

Familiarize yourself with the main components of the Dpofirs 4K Digital Camera.



Figure 1: Front view of the Dpofirs 4K Digital Camera, showcasing the lens and main body.



Figure 2: Rear view of the camera, highlighting the 3-inch color display and control buttons.



Figure 3: The camera with the external microphone mounted on the hot shoe, demonstrating accessory compatibility.





Figure 4: The camera assembled with the fill light and folding handle, illustrating a complete setup for enhanced shooting.

Setup

1. Battery Installation

The camera comes with a built-in 4800mAh Li-Ion battery. Ensure it is fully charged before first use. Use the provided charging cable to connect the camera to a USB power source.
For the external fill light, install 2 x AA batteries (not included) into the battery compartment, observing polarity markings.

2. Memory Card Installation

The camera supports storage cards up to 128GB. Insert a compatible SD card into the designated slot until it clicks into place. Ensure the card is formatted within the camera settings before first use to prevent data corruption.

3. Attaching Accessories

Microphone: Slide the microphone's hot shoe mount onto the camera's hot shoe. Secure it by tightening the locking mechanism. Connect the microphone cable to the camera's microphone input jack.
Fill Light: Attach the fill light to the hot shoe expansion mount. Then, attach the expansion mount to the camera's hot shoe or the folding handle's hot shoe mount using the provided fixing screw.
Folding Handle: Attach the folding handle to the bottom of the camera using the handle fixing camera screw. This provides a stable grip for shooting.
Macro Lens: The 62mm macro lens can be attached to the front of the camera's main lens for close-up photography. Ensure it is securely threaded.

Operating Instructions

1. Powering On/Off

Press and hold the power button located on the top of the camera to turn it on or off. The 3-inch display will illuminate upon power-on.

2. Basic Photography

Taking Photos: Frame your shot using the display. Press the shutter button halfway to focus, then press fully to capture the image.
Video Recording: Switch to video mode using the mode dial or menu. Press the record button to start and stop recording. The camera supports 4K, 1080FHD, 1080P, 720P, WVGA, and VGA video resolutions.

3. Advanced Features

Night Vision: The camera features HD night vision. When the lens senses changes in light, the IR CUT will switch automatically to enhance visibility in dim environments.
Digital Zoom: Use the zoom controls to adjust the 16X digital zoom. Note that digital zoom may reduce image quality compared to optical zoom.
Anti-Shake Optimization: The camera includes an anti-shake function to help stabilize images and videos, especially when zooming or in low light.
Filter Functions: Access various filter functions through the camera's menu to enhance your photos. The beauty filter and front/rear dual camera modes facilitate easier selfies.
Macro Photography: Attach the macro lens for detailed close-up shots of small subjects.
Wi-Fi Connectivity: The camera supports Wi-Fi connectivity. Refer to the camera's on-screen menu for instructions on connecting to a Wi-Fi network and transferring files.

4. Playback and File Management

Enter playback mode to review your photos and videos. Use the navigation buttons to browse through files. You can delete unwanted files directly from the camera.
To transfer files to a computer, connect the camera using the provided USB charging cable or remove the SD card and insert it into a card reader.

Maintenance

- Keep the camera and accessories clean. Use a soft, lint-free cloth to wipe the body and display.
- For the lens, use a specialized lens cleaning cloth and solution. Avoid touching the lens surface with bare fingers.
- Store the camera in a dry, cool place away from direct sunlight and extreme temperatures.
- Ensure the lens cap is on when the camera is not in use to protect the lens from dust and scratches.
- Regularly back up your photos and videos to an external storage device or cloud service.
- Periodically check for firmware updates on the Dpofirs official website to ensure optimal performance.

Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or not charged.	Charge the camera battery using the provided cable. Ensure the charging indicator is active.
Cannot take photos/record videos.	Memory card is full, not inserted, or corrupted.	Insert a memory card, free up space, or format the card (*note: formatting deletes all data*).
Images are blurry.	Lens is dirty, insufficient light, or camera shake.	Clean the lens. Use the fill light in low light conditions. Utilize the anti-shake function or a stable surface.
Microphone not recording audio.	Microphone not connected properly or settings incorrect.	Ensure microphone cable is fully inserted. Check camera audio input settings.

If the problem persists, please contact Dpofirs customer support.

Specifications

Item Type: Digital Camera
Product Material: ABS, Metal
Display Size: 3 inches (480x852 resolution)
Lens: F=2.7 2.95mm
Resolution: 64MP (Interpolated), 4K (Interpolated)
Video Resolution: 4K, 1080FHD, 1080P, 720P, WVGA, VGA
Storage Card Support: Up to 128GB (not included)
IR Night Vision: Supported
Digital Zoom: 16X
Lens Angle: 120 Degree Wide Angle
Camera Battery: Built-in Li-Ion Battery 4800mAh

Fill Light Battery: 2 x AA batteries (not included)

Weight: 898g / 31.68oz

Model Number: Dpofirs46rqnf0g5b

Warranty and Support

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Dpofirs website. Keep your purchase receipt as proof of purchase.
For technical assistance or inquiries, please contact Dpofirs customer service through their official channels.

© 2023 Dpofirs. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCRLZ2FV

More documents and user manuals: **https://manuals.plus/**