Timex TW2V64400QY

Timex Expedition Tide-Temp-Compass 43mm Watch User Manual

Model: TW2V64400QY

INTRODUCTION

Welcome to your Timex Expedition Tide-Temp-Compass 43mm Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure optimal performance and longevity. Please read this manual thoroughly before using your watch.

Image: The Timex Expedition Tide-Temp-Compass watch worn on a wrist, showcasing its design and functionality in an outdoor setting.

Product Features

- **Tide-Temp-Compass Function:** The central bidirectional hand can be configured to display local tide conditions, air or water temperature, or serve as an analog compass.
- **Durable Construction:** Features a 43mm round stainless steel case and a dark brown leather strap.
- **Water Resistance:** Water resistant up to 100 meters (330 feet), suitable for snorkeling and swimming, but not for diving.
- **Analog Display:** Clear black analog dial with easy-to-read markers.
- **Date Window:** A dedicated date display located at the 6 o'clock position.
- **INDIGLO Night-Light:** Electroluminescent backlight for visibility in low-light conditions.

Setup

1. Setting the Time

1. Pull the crown (A) out to the furthest position.
2. Turn the crown (A) clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown (A) back in to its original position to start the watch.

Image: Side view of the watch, highlighting the crown (A) and pushers for setting functions.

2. Setting the Date

1. Pull the crown (A) out to the middle position.
2. Turn the crown (A) clockwise or counter-clockwise to adjust the date in the date window (located at 6 o'clock).
3. Once the correct date is displayed, push the crown (A) back in to its original position.
4. *Note:* Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.

3. Battery Information

Your watch is powered by one product-specific battery, which is included and pre-installed. When the battery needs replacement, it is recommended to have it replaced by a qualified watch technician to ensure water resistance is maintained.

Operating the Tide-Temp-Compass Function

The central bidirectional hand is a multi-functional indicator for tide, temperature, and compass readings.

1. Compass Mode

1. To activate the compass, press the upper pusher (B). The central hand will point North.
2. Hold the watch horizontally and rotate your body until the central hand aligns with the 'N' on the dial.
3. The other cardinal points (E, S, W) will then indicate their respective directions.
4. To exit compass mode, press the upper pusher (B) again, or it will automatically return to time display after a short period.
5. *Calibration:* For accurate readings, calibrate the compass periodically, especially after significant travel or exposure to strong magnetic fields. Refer to the full manual for detailed calibration steps.

2. Temperature Mode

1. To activate the thermometer, press the lower pusher (C). The central hand will indicate the temperature on the outer scale.
2. Ensure the watch is off your wrist for at least 5-10 minutes for an accurate air temperature reading, as body heat can affect the sensor.
3. To exit temperature mode, press the lower pusher (C) again, or it will automatically return to time display.

3. Tide Mode

1. To activate the tide tracker, press and hold the lower pusher (C) for a few seconds. The central hand will indicate the tide level.
2. This function requires initial setup based on local tide charts. Consult local tide information to set the hand to the current tide level (high, low, or in-between).
3. Once set, the watch will track the approximate tide cycle.
4. To exit tide mode, press and hold the lower pusher (C) again, or it will automatically return to time display.

4. INDIGLO Night-Light

Press the crown (A) firmly to activate the INDIGLO night-light, illuminating the entire dial for easy reading in the dark. The light will remain on as long as the crown is pressed.

Maintenance

1. Water Resistance

- Your watch is water resistant to 100 meters. This means it is suitable for showering, swimming, and snorkeling.
- **Do not operate the crown or pushers while the watch is wet or submerged.**This can compromise the water seal.
- Avoid exposing the watch to extreme temperature changes (e.g., hot showers followed by cold water), as this can affect the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

Image: Rear view of the watch case, displaying the 'WR 100M' water resistance engraving and 'Expedition North Timex' branding.

2. Cleaning Your Watch

- Wipe the watch case and crystal with a soft, damp cloth.
- For the leather strap, avoid excessive moisture. If it gets wet, allow it to air dry naturally. Do not use harsh chemicals or abrasive materials.

3. Battery Replacement

When the watch stops or the INDIGLO light dims significantly, the battery may need replacement. It is highly recommended to take your watch to an authorized Timex service center or a reputable watch repair shop for battery

replacement to ensure proper sealing and function.

Troubleshooting

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect time/date:** Follow the "Setting the Time" and "Setting the Date" instructions in the Setup section.
- **Compass not accurate:** The compass may need recalibration. Strong magnetic fields (e.g., from electronics, speakers) can affect accuracy. Move away from such sources and attempt recalibration.
- **Water inside the watch:** If condensation or water appears inside the watch, immediately take it to a service center. This indicates a compromised water seal.

Specifications

Model Name	Expedition North Tide-Temp-Compass
Model Number	TW2V64400QY
Case Diameter	43 mm
Case Thickness	13 mm
Band Width	22 mm
Case Material	Stainless Steel
Band Material	Leather
Dial Color	Black
Band Color	Dark Brown
Movement Type	Quartz
Display Type	Analog
Water Resistance	100 Meters (330 Feet)
Special Features	Compass, Tide Tracker, Thermometer, INDIGLO Night-Light
Power Source	Battery
Weight	90.53 Grams
Crystal	Sapphire

Warranty Information

Timex watches are manufactured to high-quality standards and are warranted against manufacturing defects for a period typically specified by your region's consumer laws, usually one year from the date of purchase. This warranty does not cover normal wear and tear, battery life, crystal, watch case, strap, loss, or theft. Damage resulting from improper handling, lack of care, accidents, or unauthorized repairs is also not covered. Please retain your proof of purchase for warranty claims.
For specific warranty details and service, please refer to the official Timex website or contact their customer support.

Support

Should you require further assistance or have questions not covered in this manual, please visit the official Timex support website or contact their customer service department.

- **Official Timex Website:** www.timex.com
- **Customer Service:** Refer to the contact information provided on the Timex website for your specific region.

© 2023 Timex. All rights reserved. Information in this manual is subject to change without notice.