Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Magic Wand HIT60

Magic Wand Micro HIT60 Personal Massager User Manual

Introduction

This manual provides essential information for the safe and effective use of your Magic Wand Micro HIT60 personal massager. Please read it thoroughly before first use and retain it for future reference.

Safety Information

For external use only. Keep out of reach of children. If irritation occurs, discontinue use.

Product Overview

The Magic Wand Micro HIT60 is a compact, cordless personal massager designed for targeted muscle relaxation. It features a powerful brushless motor, multiple speed settings, and a soft silicone head with a flexible neck.

Key Features:

- Ultra-compact design for portability.
- Rechargeable battery with up to 3 hours of cordless run time.
- 6,500 RPM brushless motor for deep, rumbly vibrations.
- Three intensity levels and four vibration patterns.
- Soft silicone head and flexible neck for comfortable application.
- Intuitive controls for easy operation.



Figure 1: Magic Wand Micro HIT60 Personal Massager.



Figure 2: Key features of the Magic Wand Micro HIT60.

Setup

Initial Charging:

1. Before first use, fully charge the device.
2. Locate the charging port, typically at the base of the handle.
3. Connect the provided USB-C cable to the device and a suitable USB power source (e.g., wall adapter, computer USB port).
4. The indicator light will show charging status and turn solid when fully charged.



Figure 3: Compact size of the Magic Wand Micro HIT60.

Operating Instructions

1. **Power On/Off:** Press the power button (usually the top button) to turn on the device. Press and hold to turn off.
2. **Adjusting Speed:** Use the speed adjustment buttons (often marked with '+' and '-') to cycle through the three intensity levels.
3. **Changing Vibration Patterns:** Use the pattern selection button (if available, often marked 'M' or a wave icon) to switch between the four vibration patterns.
4. **Application:** Apply the flexible tip of the massager to the desired area.
5. **Recharging:** When the battery is low, recharge the device as needed.

Official Product Videos:

▶ **Watch video online**

Magic Wand Micro - HIT60

Video 1: Official overview of the Magic Wand Micro HIT60, demonstrating its features and compact design. This video is provided by

Vibratex, Inc., the official vendor.

▶ **Watch video online**
Magic Wand Micro | Hitachi Magic Wand | Hitachi Wand

Video 2: A brief demonstration of the Magic Wand Micro, highlighting its portability and power. This video is provided by Always Shipping, a seller of the product.

Maintenance & Care

- **Cleaning:** After each use, clean the silicone head with mild soap and water or a specialized toy cleaner. Ensure the device is completely dry before storage.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Charging:** To prolong battery life, avoid overcharging and store with a partial charge if not used for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully.
Weak vibrations.	Low battery or incorrect setting.	Recharge the device. Adjust to a higher intensity setting.
Device stops unexpectedly.	Battery depleted.	Recharge the device.

Specifications

- **Model Name:** Magic Wand Micro
- **Item Model Number:** AH364
- **Product Dimensions:** 4.5 x 1.3 x 4.5 inches
- **Weight:** 5 ounces
- **Material:** Silicone
- **Color:** Micro (White/Blue)
- **Motor:** 6,500 RPM Brushless Motor
- **Speeds:** 3 Intensity Levels
- **Patterns:** 4 Vibration Patterns
- **Power Source:** Rechargeable Battery (USB-C)
- **Run Time:** Up to 3 hours on a full charge

Warranty & Support

The Magic Wand Micro HIT60 includes a full 1-year warranty. For support or warranty claims, please contact the manufacturer, Magic Wand, through their official channels or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF6Z1N3Q

More documents and user manuals: **https://manuals.plus/**