Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lexibook HPBT015DP

Lexibook Disney Princesses 2-in-1 Wireless and Wired Headphones

Model: HPBT015DP - User Manual

1. Introduction

Thank you for choosing the Lexibook Disney Princesses 2-in-1 Wireless and Wired Headphones. These versatile headphones are designed for young users, offering both Bluetooth 5.3 wireless connectivity and a traditional wired connection. Featuring a detachable princess crown with captivating light effects and a sound limit of 85 dB for hearing protection, they provide a safe and enjoyable audio experience. This manual provides essential information for the proper setup, operation, and maintenance of your headphones.





Image: The Lexibook Disney Princesses headphones in pink, featuring a golden crown accessory on the headband and light-up earcups.

2. Safety Warnings

- **Hearing Protection:** The headphones are designed with a maximum volume limit of 85 dB to protect young ears. Prolonged listening at high volumes can still cause hearing damage.
- **Choking Hazard:** This product contains small parts (e.g., detachable crown components). Not suitable for children under 3 years due to potential choking hazards. Adult supervision is recommended.
- **Battery Safety:** The headphones contain a rechargeable Lithium 600 mAh battery. Do not attempt to replace the battery. Do not expose to extreme temperatures, direct sunlight, or fire. Dispose of batteries responsibly according to local regulations.
- **Water Exposure:** Do not expose the headphones to water or excessive moisture. This product is not waterproof.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use liquid cleaners or aerosols.
- **Power Output:** The maximum average power output is less than 20mW.

3. Package Contents

Please check the package contents to ensure all items are present:

- 1 x Lexibook Disney Princesses Headphones
- 1 x 3.5mm Jack Audio Cable (detachable)
- 1 x USB-C Charging Cable
- 1 x User Manual (this document)



Image: The Lexibook Disney Princesses headphones displayed within their retail packaging, showing the product and included cables.

4. Product Features

- **2-in-1 Connectivity:** Seamlessly switch between Bluetooth 5.3 wireless mode and a traditional wired connection using the included 3.5mm jack cable.
- **Princess Crown Design:** Features a beautiful detachable golden crown accessory on the headband.
- **Captivating Light Effects:** The earcups illuminate with vibrant light effects, adding a magical touch to the listening experience.
- **Safe Listening:** Equipped with a built-in sound limiter, ensuring the volume does not exceed 85 dB to protect sensitive hearing.
- **Integrated Micro SD Card Reader:** Play music directly from a Micro SD card without needing a connected device.
- **Built-in Microphone:** Allows for hands-free calls when connected via Bluetooth.
- **Foldable and Adjustable Design:** The headphones are lightweight, foldable for easy portability, and feature an adjustable headband for a comfortable fit for various head sizes.
- **Long Battery Life:** Offers up to 100 hours of autonomy in wireless mode. Unlimited listening in wired mode.
- **USB-C Rechargeable:** Convenient and fast charging via the included USB-C cable.
- **High-Quality Sound:** 40mm drivers deliver clear and immersive audio.



Image: A row of six Lexibook Disney Princesses headphones, each displaying a different light color on their earcups, highlighting the light effects feature.

5. Setup Guide

5.1. Charging the Headphones

1. Locate the USB-C charging port on the headphones.
2. Connect the small end of the provided USB-C cable to the headphone's charging port.
3. Connect the larger USB-A end of the cable to a USB power adapter (not included) or a computer's USB port.

4. The LED indicator on the headphones will illuminate during charging and turn off or change color when fully charged.
5. A full charge typically takes approximately 2-3 hours.

5.2. Bluetooth Pairing

1. Ensure the headphones are charged.
2. Press and hold the Power button on the headphones until the LED indicator flashes rapidly (usually blue/red), indicating pairing mode.
3. On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for available devices. The headphones will appear as "LEXIBOOK HPBT015DP" or similar.
5. Select the headphones from the list to connect. Once paired, the LED indicator will usually turn solid blue or flash slowly.
6. The headphones will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.



Image: The Lexibook Disney Princesses headphones shown with icons representing compatible devices: smartphone, tablet, laptop, and computer, indicating broad Bluetooth compatibility.

5.3. Wired Connection

For a wired connection, or when the battery is depleted, use the included 3.5mm jack audio cable:

1. Insert one end of the 3.5mm jack cable into the audio input port on the headphones.
2. Insert the other end into the 3.5mm audio output jack of your device (e.g., smartphone, tablet, computer).
3. The headphones will automatically switch to wired mode. The light effects and Bluetooth functions will be disabled in wired mode.

5.4. Micro SD Card Usage

The headphones feature an integrated Micro SD card reader for direct music playback:

1. Ensure your Micro SD card contains audio files (e.g., MP3 format).
2. Carefully insert the Micro SD card into the designated slot on the headphones until it clicks into place.
3. The headphones should automatically detect the card and begin playing music. Use the control buttons on the headphones to manage playback.

6. Operating Instructions

Familiarize yourself with the control buttons located on the headphones (exact button layout may vary slightly, refer to product diagrams if available):

6.1. Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power button for approximately 3-5 seconds until the LED indicator turns off.

6.2. Volume Control

- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- *Note: The headphones have a built-in 85 dB volume limit for safety.*

6.3. Music Playback (Bluetooth & Micro SD)

- **Play/Pause:** Press the Multi-function button (often the Power button or a dedicated Play/Pause button) once.
- **Next Track:** Press and hold the "+" button (or a dedicated "Next" button).
- **Previous Track:** Press and hold the "-" button (or a dedicated "Previous" button).

6.4. Call Management (Bluetooth Only)

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

6.5. Light Effects

- The light effects on the earcups typically activate automatically when the headphones are powered on in wireless mode.
- Refer to the specific product packaging or quick start guide for details on how to toggle or change light modes, if applicable.

- *Note: Light effects are generally not active in wired mode to conserve battery.*

7. Maintenance

7.1. Cleaning

- Always power off the headphones before cleaning.
- Use a soft, dry, lint-free cloth to wipe the surfaces of the headphones.
- Do not use abrasive cleaners, alcohol, benzene, or other chemical solvents, as these may damage the finish or internal components.
- Avoid getting moisture into any openings.

7.2. Storage

- When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures.
- The foldable design allows for compact storage. Gently fold the earcups inwards to minimize space.
- If storing for an extended period, charge the headphones periodically (e.g., every 3 months) to maintain battery health.



Image: The Lexibook Disney Princesses headphones shown in their folded position, demonstrating their compact design for easy storage and portability.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Headphones do not power on.	Battery is depleted.	Charge the headphones using the provided USB-C cable.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device; interference.	Ensure headphones are in pairing mode (flashing LED). Turn Bluetooth on your device. Move headphones closer to the device. Turn off other Bluetooth devices nearby. Try forgetting the device on your phone and re-pairing.
No sound in wireless mode.	Volume too low; headphones not connected; incorrect audio output selected on device.	Increase volume on both headphones and connected device. Ensure headphones are successfully paired. Check audio output settings on your device.
No sound in wired mode.	Cable not fully inserted; cable is faulty; device audio jack issue.	Ensure the 3.5mm jack cable is fully inserted into both the headphones and the device. Try a different 3.5mm cable if available. Test with another device.
Micro SD card not playing.	Card not inserted correctly; unsupported file format; corrupted card.	Re-insert the Micro SD card firmly. Ensure audio files are in a supported format (e.g., MP3). Try a different Micro SD card.
Light effects not working.	Headphones in wired mode; battery low.	Ensure headphones are in wireless mode. Charge the headphones.

9. Specifications

Feature	Detail
Model Number	HPBT015DP
Connectivity	Bluetooth 5.3, 3.5mm Jack
Battery Type	Lithium 600 mAh (included)
Wireless Autonomy	Up to 100 hours
Charging Port	USB-C
Speaker Drivers	40mm
Impedance	32 ohms
Sound Limit	85 dB
Material	Plastic
Dimensions (L x W x H)	16.6 x 8 x 24 cm
Weight	310 grams

Feature	Detail
Recommended Age	3 years and up
Compatible Devices	Mobile phones, tablets, laptops, smart speakers, TVs, media players

10. Warranty and Support

For detailed warranty information and customer support, please refer to the warranty card included with your product or visit the official Lexibook website. Keep your proof of purchase for any warranty claims.
Online Support: www.lexibook.com/en/support/

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF9M99NX

More documents and user manuals: **https://manuals.plus/**