Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 6046cs

Braun Series 6 6046cs Electric Razor User Manual

Model: 6046cs | Brand: Braun

INTRODUCTION



Image: The Braun Series 6 6046cs Electric Razor, its packaging, and included travel case.

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your Braun Series 6 electric shaver. Designed for both wet and dry use, this shaver features a dermatologically tested SensoFlex swivel head and SensoFoil blades for a close shave that remains sensitive on your skin. Please read this manual thoroughly before first use and keep it for future reference.

Important Safety Information

WARNING: This product is intended for external use only. Avoid contact with eyes and broken skin. Do not use on irritated or inflamed skin. Always hold the shaver away from the face when turning it on or off. After each use, clean the shaver thoroughly and dry it completely to prevent bacterial growth. Do not use the shaver while it is charging or near water.

- Ensure the appliance is disconnected from the power supply before cleaning.
- Do not immerse the charging stand or power cord in water or other liquids.
- Keep the appliance out of reach of children.
- Only use the provided smart plug for charging.
- Do not disassemble the shaver. Refer all servicing to qualified personnel.

What's in the Box

Your Braun Series 6 Electric Razor package includes the following components:



Image: All components included in the Braun Series 6 Electric Razor package.

- 1x Braun Series 6 Electric Razor (Black)
- 1x Body Groomer attachment
- 1x Precision Trimmer attachment
- 1x Stubble Trimmer attachment
- 1x Travel Case
- 1x Smart Plug (for automatic 100-240 voltage adjustment)
- 1x Cleaning Brush
- 1x User Manual (this document)

Product Features

The Braun Series 6 electric shaver is engineered with advanced features for an optimal shaving experience:

- **SensoFlex Swivel Head:** Dermatologically tested, this flexible head minimizes pressure on sensitive skin while adapting to facial contours.

- **SensoFoil Blades:** Designed for closeness and skin comfort.
- **AutoSense Technology:** Automatically reads and adapts power to your beard density, capturing and cutting more hair in every stroke.
- **Li-Ion Battery:** Provides up to 50 minutes of cordless shaving, equivalent to approximately 3 weeks of typical use. A 5-minute quick charge provides enough power for one full shave.
- **100% Waterproof:** Suitable for both wet and dry use, including in the shower.
- **EasyClick System:** Allows for quick and easy attachment changes for versatile grooming.
- **Durability:** Made in Germany and designed to last up to 7 years. The shaver head should be replaced every 18 months for optimal performance.



Image: Overview of Braun Series 6 key features for a close and sensitive shave.



Image: The SensoFlex tilting head adjusts to minimize skin pressure.



Image: The Li-Ion battery provides 50 minutes of runtime.



Image: The Braun shaver is designed to last up to 7 years.

Setup

1. Charging the Shaver

1. Ensure the shaver is dry before charging.
2. Connect the smart plug to the shaver and then plug it into an electrical outlet.
3. The battery indicator lights will illuminate, indicating charging is in progress.
4. A full charge takes approximately 1 hour and provides up to 50 minutes of shaving time.
5. For a quick shave, a 5-minute quick charge is sufficient for one full shave.

2. Attaching and Detaching EasyClick Attachments

The Braun Series 6 features the EasyClick system for quick and convenient attachment changes.



Image: Easily upgrade your shaver with various EasyClick attachments.

1. To remove the shaver head, gently pull it upwards from the shaver body.
2. To attach an EasyClick attachment (e.g., Precision Trimmer, Stubble Trimmer, Body Groomer), align it with the shaver body and press it down until it clicks into place.
3. Ensure the attachment is securely fastened before use.

Operating Instructions

1. General Shaving Tips

- For best results, shave before washing your face.
- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin and shave against the direction of beard growth.
- Apply gentle, even pressure. The SensoFlex head will adapt to your contours.

2. Wet & Dry Use

- Your Braun Series 6 shaver is 100% waterproof and can be used for dry shaving, with foam or gel, or even in the shower.
- For wet shaving, apply shaving foam or gel to your face before use.
- Rinse the shaver head under running water during and after wet shaving for optimal performance.

3. Using Attachments

- **Precision Trimmer:** Ideal for shaping sideburns, moustaches, or detailing beard lines. Attach the precision trimmer head and use short, controlled strokes.
- **Stubble Trimmer:** Use this attachment to maintain a specific stubble length. Experiment with different lengths to find your preferred style.
- **Body Groomer:** Designed for grooming body hair. Use on dry skin for best results.

Maintenance

1. Cleaning the Shaver

- **Daily Cleaning:** After each use, switch off the shaver and rinse the shaver head under hot running water. You can also use the included cleaning brush to remove stubborn hair particles.
- **Deep Cleaning:** Periodically, remove the shaver head and clean the inner parts with the cleaning brush. Ensure all hair clippings are removed.
- **Drying:** Allow the shaver to air dry completely before storing or recharging.

2. Replacing the Shaver Head

For continued optimal shaving performance, it is recommended to replace the shaver head (foil and cutter block) every 18 months. A worn shaver head can reduce shaving efficiency and comfort.



Image: Replacement shaver head for Braun Series 5/6 (Part 53B).

Replacement heads can be purchased from authorized Braun retailers or online. Look for Braun Series 5/6 replacement shaver head, part number 53B.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes or until fully charged.

Problem	Possible Cause	Solution
Poor shaving performance / Does not cut hair effectively.	Shaver head is dirty or worn out. / Hair is too long.	Clean the shaver head thoroughly. Replace the shaver head if it has been used for more than 18 months. For longer hair, pre-trim with a stubble trimmer attachment before shaving.
Skin irritation after shaving.	Incorrect shaving technique. / Shavers head is worn. / Sensitive skin.	Ensure you are shaving against the grain with gentle pressure. Replace the shaver head. Consider using the shaver with shaving foam/gel or in the shower for increased comfort.
Shaver makes unusual noise.	Shaver head is not properly attached or is damaged.	Ensure the shaver head is securely attached. Inspect the shaver head for any visible damage and replace if necessary.

Specifications

Model: 6046cs

Power Source: Battery Powered (Li-Ion)

Battery Life: Up to 50 minutes runtime (approx. 3 weeks of shaving)

Quick Charge: 5 minutes for one shave

Waterproof: 100% Wet & Dry use

Item Dimensions (LxWxH): 9.96 x 5.35 x 2.56 inches

Item Weight: 1.25 Pounds

Manufacturer: Procter & Gamble

UPC: 069055141311

GTIN: 069055141311

Warranty and Support

The Braun Series 6 electric razor is engineered in Germany and designed for long-lasting performance, with the shaver itself built to last up to 7 years. The shaver head is designed for optimal performance for up to 18 months before replacement is recommended.
For warranty claims, technical support, or to purchase replacement parts and accessories, please visit the official Braun website or contact their customer service. Keep your proof of purchase for any warranty-related inquiries.
You can find more information and support at theBraun Store on Amazon.

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFCBSHKQ

More documents and user manuals: **https://manuals.plus/**