Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun FP 0132 White

Braun Food Processor 8-in-1 System User Manual

Model: FP 0132 White

Important Safety Instructions

Please read these instructions carefully and completely before using the appliance. Keep this manual for future reference.

- Always unplug the appliance from the power supply before assembling, disassembling, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the processing bowl while operating to prevent injury.
- Ensure all parts are correctly assembled and the lid is securely locked before operating.
- Avoid contact with moving parts. Blades are sharp; handle with extreme care.
- This appliance is for household use only. Do not use outdoors.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The appliance features a safety lock mechanism. It will not operate unless correctly assembled.

Product Overview

The Braun Food Processor 8-in-1 System is designed for versatile food preparation, offering chopping, slicing, grating, whisking, and pureeing functions. It includes a main processing bowl and a blender jug.



Figure 1: Overview of the Braun Food Processor 8-in-1 System with its main unit, blender, and various attachments including chopping blade, whisking disc, slicing disc, and grating disc.

Main Components:

- **Motor Unit:** The base of the appliance containing the 750-watt motor and control dial.
- **Processing Bowl (2.1 L capacity):** The main bowl for chopping, slicing, grating, and pureeing.
- **Blender Jug (1.8 L capacity):** For blending liquids, smoothies, and purees.
- **Lid with Feeder Tube:** Covers the processing bowl or blender jug, with an opening for adding ingredients.
- **Pusher:** Used to push ingredients through the feeder tube.

Attachments:

- **Chopping Blade:** A sharp S-shaped blade for chopping and mincing.



Figure 2: The two-pronged chopping blade, essential for mincing and chopping various ingredients.

- **Whisking Disc:** For whipping cream, egg whites, and light batters.



Figure 3: The whisking disc, designed for aerating liquids and creating light, fluffy textures.

- **Slicing Disc:** For uniform slicing of vegetables and fruits.



Figure 4: The slicing disc, used for creating consistent slices of various foods.

- **Grating Disc:** For grating cheese, vegetables, and other ingredients.



Figure 5: The grating disc, ideal for finely or coarsely grating ingredients.

Setup and Assembly

Before first use, wash all removable parts in warm soapy water, rinse thoroughly, and dry. Ensure the motor unit is unplugged.

Assembling the Food Processor:

1. Place the motor unit on a stable, flat surface.
2. Fit the processing bowl onto the motor unit, aligning the handle with the safety lock mechanism. Turn clockwise until it clicks into place.
3. Insert the desired attachment (e.g., chopping blade, whisking disc, or disc holder with slicing/grating disc) onto the central spindle inside the bowl.
4. Place the lid onto the processing bowl, aligning the tab on the lid with the slot on the bowl handle. Turn clockwise until it locks securely.
5. Insert the pusher into the feeder tube of the lid.

Assembling the Blender:

1. Ensure the blender blade assembly is securely attached to the bottom of the blender jug.
2. Place the blender jug onto the motor unit, aligning it correctly. Turn clockwise until it clicks into place.
3. Place the lid onto the blender jug and secure it.

Operating Instructions

The appliance features a control dial with two speeds (1 and 2) and a pulse function (P).



Figure 6: The control dial for selecting speed settings (1, 2) and the pulse function (P).

Using the Food Processor:

1. Assemble the food processor with the desired attachment.
2. Add ingredients to the processing bowl. For chopping, ensure ingredients are cut into manageable pieces. For slicing/grating, use the feeder tube and pusher.
3. Plug in the appliance.
4. Turn the control dial to speed 1 (low) or 2 (high) for continuous operation, or to P (pulse) for short bursts.



Figure 7: The food processor in action, demonstrating its chopping capability for ingredients like meat.

5. Once processing is complete, turn the dial to 'O' (off) and unplug the appliance.
6. Carefully disassemble and remove processed food.

Using the Blender:

1. Assemble the blender jug onto the motor unit.
2. Add ingredients to the blender jug. Do not exceed the maximum fill line.
3. Secure the lid.
4. Plug in the appliance.
5. Turn the control dial to speed 1 or 2 for continuous blending, or to P for pulse blending.



Figure 8: The blender in use, preparing a green beverage, showcasing its liquid processing capabilities.

6. Once blending is complete, turn the dial to 'O' (off) and unplug the appliance.
7. Carefully remove the jug and pour out the contents.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your appliance.

- **Always unplug the appliance before cleaning.**
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse in water or rinse under running water.
- **Processing Bowl, Blender Jug, Lids, and Attachments:** These parts are dishwasher safe (top rack only) or can be washed by hand in warm soapy water. Rinse thoroughly and dry immediately.
- **Blades and Discs:** Handle with extreme care as they are very sharp. Use a brush to remove food residue if necessary.
- **Storage:** Store the appliance and its attachments in a dry place, out of reach of children.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; safety lock not engaged; power outage.	Ensure plug is firmly in outlet; check that bowl/jug and lid are correctly assembled and locked; check power supply.
Motor stops during operation.	Overload protection activated; ingredients too large/hard.	Turn off, unplug, remove some ingredients, wait 15 minutes for motor to cool, then restart. Cut ingredients into smaller pieces.

Problem	Possible Cause	Solution
Loud noise or vibration.	Improper assembly; uneven load.	Check that all parts are securely assembled. Distribute ingredients evenly.
Food not processed evenly.	Too much food; incorrect speed.	Process smaller batches. Adjust speed or use pulse function for better control.

Specifications

Brand: Braun

Model: FP 0132 White (FB 0132 WH)

Power: 750 Watts

Processing Bowl Capacity: 2.1 Liters

Blender Jug Capacity: 1.8 Liters

Speeds: 2 speeds + Pulse function

Material: Plastic

Voltage: 220 Volts (DC)

Dimensions: Approximately 46 x 40.5 x 37.5 cm (Product Dimensions from specs)

Item Weight: 3.94 Kilograms

Special Features: Safety Lock

Warranty and Support

The Braun Food Processor FP 0132 comes with a **1-year warranty** from the date of purchase.
For warranty claims, technical support, or spare parts, please contact Braun customer service or the authorized service center in your region. Keep your proof of purchase for warranty validation.
For more information, you may visit the official Braun website or refer to the contact details provided with your purchase documentation.

© 2024 Braun. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFJZL4W2

More documents and user manuals: **https://manuals.plus/**