Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 43234

LEGO Disney Princess Elsa's Ice Cream Stand (Model 43234) Instruction Manual

Official Guide for Assembly and Play

1. Introduction

This instruction manual provides detailed guidance for assembling and enjoying your LEGO Disney Princess Elsa's Ice Cream Stand set (Model 43234). Designed for children aged 5 and up, this set allows for creative play with an ice cream truck, the Elsa mini-doll, and a mini snowman figure.

2. Safety Information

WARNING: CHOKING HAZARD - Small Parts.
This product is not suitable for children under 36 months due to small parts which may present a choking hazard. Adult supervision is recommended during assembly and play for younger children within the recommended age range.

3. What's in the Box

Your LEGO Disney Princess Elsa's Ice Cream Stand set (43234) includes:

- LEGO Disney Frozen Elsa's Ice Cream Stand building bricks.
- One Princess Elsa mini-doll figure.
- One mini snowman figure.
- Two collectible rings with interchangeable decorations.
- Instruction booklet for assembly.

The set contains 82 pieces in total.

4. Setup and Assembly

Follow the step-by-step instructions provided in the included booklet to assemble your LEGO set. The building process is designed to be intuitive and engaging for the recommended age group.

1. **Unpack Components:** Carefully open the box and empty all LEGO bricks onto a clean, flat surface. Ensure all pieces are present by comparing them with the parts list in the instruction booklet.
2. **Follow Instructions:** Refer to the printed instruction booklet for a detailed, visual guide to construction. Each step illustrates which pieces to use and where to place them.
3. **Digital Instructions (Optional):** For an enhanced building experience, download the LEGO Builder app. This app offers digital 3D model views, allowing you to zoom in, rotate, save sets, and track your building progress.



Image: The LEGO Disney Princess Elsa's Ice Cream Stand set, showing the product box and the fully assembled ice cream cart with Elsa and the mini snowman figures.



Image: A close-up view of the assembled LEGO ice cream stand, featuring the Elsa mini-doll holding an ice pop and the mini snowman beside the cart.

5. Operating and Play Features

Once assembled, the LEGO Disney Princess Elsa's Ice Cream Stand offers various interactive elements for imaginative play:

- **Ice Cream Cart:** The cart features an ice cream maker, two ice cream cones, two ice lollies, and a snow globe. Push the cart around to simulate selling treats.
- **Elsa Mini-Doll:** Position the Elsa mini-doll to serve ice cream, interact with the snowman, or push the cart.
- **Mini Snowman:** The mini snowman figure can accompany Elsa and the ice cream stand, adding to the Frozen theme.
- **Collectible Rings:** The set includes two rings with interchangeable decorations, allowing for personalization and additional play.



Image: A detailed view of the ice cream stand's counter, displaying two ice cream cones, two popsicles, and a snow globe, ready for play.



Image: The LEGO Elsa mini-doll playfully interacting with the mini snowman, demonstrating character interaction within the set.



Image: A close-up of the two collectible rings included in the set, highlighting their changeable decorative tops.

6. Maintenance

To ensure the longevity and cleanliness of your LEGO set:

- **Cleaning:** Clean LEGO bricks with mild soap and water (up to 40°C / 104°F). Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store the set in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or damage to the plastic.
- **Handling:** Handle bricks gently to avoid scratching or breaking them.

7. Troubleshooting

If you encounter any issues with your LEGO set, consider the following:

- **Missing Pieces:** If you find a piece missing, first double-check all packaging and the building area. If still missing,

contact LEGO Customer Service for assistance.

- **Assembly Difficulties:** Review the instruction booklet carefully. Ensure you are using the correct pieces for each step. The LEGO Builder app can also provide clearer 3D views.
- **Damaged Pieces:** If any pieces are damaged upon opening the box, contact LEGO Customer Service for replacements.

8. Specifications

Feature	Detail
Model Number	43234
Brand	LEGO
Product Dimensions	5.55 x 4.8 x 2.4 inches (Ice Cream Truck: 11 cm high, 9 cm long, 4 cm wide)
Item Weight	4.2 ounces
Number of Pieces	82
Recommended Age	5 years and up
Release Date	January 1, 2024

9. Warranty and Support

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or general support, please visit the official LEGO customer service website or contact their support team directly. You can typically find support information and contact details on the official LEGO website:www.lego.com/service

© 2024 LEGO Group. All rights reserved. LEGO and the LEGO logo are trademarks of the LEGO Group.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFVXFJCM

More documents and user manuals: **https://manuals.plus/**