Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MN60WP-M

Minolta Digital Camera MN60WP User Manual

Model: MN60WP-M

Introduction

Thank you for purchasing the Minolta MN60WP Waterproof Digital Camera. This compact and rugged point-and-shoot camera is designed for capturing high-quality photos and videos in various environments, including underwater. This manual provides essential information for setting up, operating, and maintaining your camera to ensure optimal performance and longevity.

Safety Information

- **Waterproof Integrity:** Ensure the battery and memory card compartment door is securely closed and latched before exposing the camera to water. Failure to do so will compromise its waterproof capabilities and may damage the device.
- **Operating Temperature:** Avoid using the camera in extreme temperatures. Refer to the specifications section for recommended operating ranges.
- **Battery Safety:** Use only the specified Lithium-Ion battery. Do not expose batteries to excessive heat or dispose of them in fire.
- **Cleaning:** Use a soft, dry cloth for cleaning. For waterproof use, rinse with fresh water after saltwater exposure and allow to air dry.
- **Disassembly:** Do not attempt to disassemble or modify the camera. This will void the warranty and may cause damage.

Package Contents

Verify that all items are present in your camera kit:

- Minolta MN60WP Camera
- Lithium-Ion Battery
- Memory Card (32GB)
- AC Adaptor
- USB Cable
- Carrying Pouch
- Wrist Strap

Camera Overview



Figure 1: Front view of the Minolta MN60WP Digital Camera in magenta, highlighting the lens and the front display screen.



Figure 2: Rear view of the Minolta MN60WP Digital Camera, displaying the main LCD screen and the various control buttons on the right side.

Key Components:

- **Front LCD Screen:** 1.8-inch display for selfies and group shots.
- **Rear LCD Screen:** 2.7-inch main display for framing, reviewing, and menu navigation.
- **Lens:** High-resolution lens for capturing 48MP photos and 4K video.
- **Shutter Button:** Activates photo capture or video recording.
- **Zoom Lever:** Controls the 16X digital zoom.
- **Mode Button:** Switches between different shooting modes.
- **Navigation Buttons:** Used for menu navigation and settings adjustment.
- **Battery/Memory Card Compartment:** Located on the side/bottom, secured by a waterproof latch.

Setup

1. Battery Installation

1. Locate the battery compartment door on the side of the camera.
2. Slide the latch to unlock and open the door.
3. Insert the Lithium-Ion battery into the compartment, ensuring the correct orientation as indicated by the diagram inside.
4. Close the compartment door firmly until it clicks and slide the latch to lock it securely.

2. Memory Card Installation

The camera supports SDHC memory cards up to 32GB.

1. With the battery compartment door open, locate the memory card slot.

2. Insert the memory card with the metal contacts facing the correct direction (usually towards the front of the camera) until it clicks into place.
3. Close and securely latch the compartment door.

3. Charging the Battery

1. Connect the small end of the USB cable to the camera's Micro USB port (located within the battery compartment).
2. Connect the larger end of the USB cable to the AC adaptor.
3. Plug the AC adaptor into a power outlet.
4. The charging indicator light on the camera will illuminate. It will turn off or change color when charging is complete.

Operating the Camera

Powering On/Off

- To power on, press and hold the Power button (usually located on the top of the camera) for a few seconds.
- To power off, press and hold the Power button again until the screen turns off.

Taking Photos

1. Turn on the camera.
2. Frame your shot using the rear LCD screen.
3. Press the Shutter button halfway down to allow the camera to focus.
4. Press the Shutter button fully down to capture the photo.

Recording Videos

1. Turn on the camera.
2. Press the Mode button to select video recording mode (indicated by a video camera icon).
3. Press the Shutter button to start recording. A timer will appear on the screen.
4. Press the Shutter button again to stop recording.

Using Dual Screens

The MN60WP features a 2.7-inch rear screen and a 1.8-inch front selfie screen.

- To switch between the front and rear screens, locate the dedicated screen switch button (refer to Figure 2 for button layout).
- The front screen is ideal for self-portraits or group photos where you want to see yourself in the frame.

Zoom Function

The camera features 16X digital zoom.

- Use the zoom lever (often integrated with the shutter button or as separate buttons) to zoom in or out.
- Push the lever towards 'T' (Telephoto) to zoom in on distant subjects.
- Push the lever towards 'W' (Wide) to zoom out and capture a wider scene.

Playback Mode

- Press the Playback button (often indicated by a play icon) to review your captured photos and videos.
- Use the navigation buttons to scroll through your media.

- Press the Playback button again or the Shutter button to exit playback mode.

Advanced Features

Shooting Modes

The MN60WP offers various shooting modes for creative control:

- **Slow Motion:** Captures video at a higher frame rate for slow-motion playback.
- **Time-Lapse:** Captures a series of photos over time to create a sped-up video.
- **Burst Mode:** Takes multiple photos in quick succession, ideal for capturing fast-moving subjects.
- **Underwater Mode:** Optimizes color balance and exposure for underwater photography.

To select a mode, press the Mode button and navigate through the options using the directional buttons, then confirm your selection.

Connectivity

- **Wi-Fi:** The camera supports Wi-Fi connectivity for transferring photos and videos to compatible devices. Refer to the camera's on-screen menu for Wi-Fi setup instructions.
- **Micro USB:** Use the provided USB cable to connect the camera to a computer for file transfer or to the AC adaptor for charging.

Maintenance

Waterproof Care



Figure 3: The Minolta MN60WP camera partially submerged in water, illustrating its waterproof design.

- Always ensure the battery/memory card compartment door is completely sealed before submerging the camera.
- After use in saltwater, rinse the camera thoroughly with fresh water to prevent salt buildup and corrosion.
- Do not open the compartment door when the camera is wet. Dry the camera completely before opening.
- Avoid dropping the camera, especially on hard surfaces, as this can compromise its waterproof seal.

Cleaning

- Use a soft, lint-free cloth to clean the camera body and screens.
- For stubborn smudges, slightly dampen the cloth with water. Avoid harsh chemicals.
- Use a lens cleaning brush or air blower to remove dust from the lens. Do not touch the lens surface with your fingers.

Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the battery.

Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is drained or not inserted correctly.	Charge the battery. Ensure the battery is inserted with correct polarity.
Cannot take photos/videos.	Memory card is full, not inserted, or corrupted.	Delete unnecessary files, insert memory card, or format the card (this will erase all data).
Images are blurry.	Lens is dirty, camera shake, or subject is too close/far.	Clean the lens. Hold the camera steady. Ensure subject is within focus range. Use Anti-Shake feature.
Water inside camera.	Battery/memory card compartment door not sealed.	Immediately power off the camera, remove battery and memory card, and allow to dry completely. Contact customer support if damage persists.
Slow response/lag.	Memory card speed is too low or camera memory is full.	Use a faster memory card (Class 10, U3 or higher). Delete unnecessary files.

Specifications

Feature	Detail
Model Name	MN60WP
Effective Still Resolution	48 MP
Video Resolution	4K Ultra HD (2160p)
Water Resistance Level	Waterproof up to 16 feet (5 meters)
Digital Zoom	16X
Rear Screen Size	2.7 Inches LCD
Front Screen Size	1.8 Inches LCD
Image Stabilization	Digital
Memory Card Type	SDHC (up to 32GB included)

Feature	Detail
Battery Type	Lithium Ion
Connectivity	Wi-Fi, Micro USB
Supported File Format	JPEG (Photos), MP4 (Video)

Warranty and Support

Warranty Information

The Minolta MN60WP Digital Camera comes with a Limited 1 Year Manufacturer Warranty. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or failure to follow the instructions in this manual.

Customer Support

For technical assistance, warranty claims, or product inquiries, please visit the official Minolta support website or contact their customer service. Refer to the packaging or the official Minolta website for the most current contact information.
For more information, you can visit the Minolta Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFW2D3V1

More documents and user manuals: **https://manuals.plus/**