LEXiBOOK JCR10i2

LEXiBOOK JCR10i2 Bilingual Interactive Card Reader Instruction Manual

Model: JCR10i2

Introduction

This manual provides essential information for the safe and effective use of your LEXiBOOK JCR10i2 Bilingual Interactive Card Reader. Please read these instructions carefully before operating the device and retain them for future reference. The LEXiBOOK JCR10i2 is designed to facilitate bilingual learning in Spanish and English through interactive quiz and vocabulary cards. It offers an engaging way for users to explore various subjects and expand their language skills.

Safety Information

- **Age Recommendation:** This product is recommended for ages 3 years and up.
- **Battery Safety:** The device requires 3 AAA batteries (not included). Ensure batteries are inserted with correct polarity (+/-). Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly. Do not recharge non-rechargeable batteries. Rechargeable batteries should only be charged under adult supervision.
- **Choking Hazard:** The device contains small parts (batteries, cards) that could pose a choking hazard for young children. Adult supervision is recommended.
- **Cleaning:** Clean the device with a soft, dry cloth. Do not immerse in water or use abrasive cleaners.
- **Storage:** Store the device and cards in a cool, dry place away from direct sunlight and extreme temperatures.

What's in the Box



Image: The LEXiBOOK JCR10i2 Bilingual Interactive Card Reader packaging, displaying the device and cards.

Upon opening the package, please ensure all the following items are present:

- 1 x LEXiBOOK JCR10i2 Card Reader
- 150 x Double-Sided Cards (97 quiz cards, 53 vocabulary cards)
- 1 x User Manual (this document)

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the card reader.
2. Using a small screwdriver, unscrew the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

2. Powering On/Off

Press and hold the power button (usually located on the front or side of the device) for a few seconds to turn the device

on. Repeat this action to turn it off.

Operating Instructions



Image: Front view of the card reader with its screen and control buttons.

1. Inserting a Card



Image: A card inserted into the top slot of the card reader, showing an animal vocabulary card.

Gently slide one of the double-sided cards into the slot at the top of the device. Ensure the card is fully inserted for proper recognition. The device will automatically detect the card and display its content.

2. Language Selection

The device supports both Spanish and English. The language typically switches automatically based on the card inserted or can be toggled using a dedicated language button if available (refer to device markings for specific button functions).

3. Vocabulary Mode

When a vocabulary card is inserted, the device will pronounce the word or phrase displayed on the card in the selected language. You can often press a repeat button to hear the pronunciation again.

4. Quiz Mode

When a quiz card is inserted, the device will present a question or challenge related to the image or text on the card. Users typically respond by pressing one of the answer buttons (e.g., A, B, C, or specific icon buttons). The device provides immediate audio feedback for correct or incorrect answers.

5. Volume Control

Adjust the volume using the designated volume buttons, usually marked with speaker icons, located on the front of the device.



Image: Children engaging with the card reader, demonstrating typical use.

Maintenance

Cleaning the Device

To clean the card reader, gently wipe the surface with a soft, dry, lint-free cloth. Do not use liquid cleaners, sprays, or solvents, as these can damage the electronic components.

Cleaning the Cards

The cards can be wiped with a slightly damp cloth if necessary, then dried thoroughly before reinserting into the device. Avoid bending or creasing the cards to ensure proper function.

Storage

When not in use, store the card reader and cards in their original packaging or a protective container to prevent dust accumulation and damage. Keep them away from direct sunlight, high temperatures, and humidity.

Troubleshooting

- **Device not turning on:**
  - Check if the batteries are inserted correctly with the right polarity.
  - Replace old or exhausted batteries with new ones.
  - Ensure the power button is pressed and held for a sufficient duration.
- **No sound or low volume:**
  - Adjust the volume using the volume control buttons.
  - Ensure batteries are not low, as this can affect sound output.
- **Cards not recognized or incorrect response:**
  - Ensure the card is fully and correctly inserted into the slot.
  - Check if the card is damaged, bent, or dirty. Try a different card.
  - Restart the device by turning it off and then on again.
- **Device freezes or becomes unresponsive:**
  - Turn the device off and then on again. If it remains unresponsive, remove and reinsert the batteries.

Specifications

Feature	Detail
Model Number	JCR10i2
Age Range (Recommended)	3 years and up
Number of Cards	150 (97 quiz, 53 vocabulary)
Languages	Spanish, English
Product Dimensions	3.7 x 0.98 x 4.41 inches
Item Weight	14.8 ounces
Batteries Required	3 x AAA (not included)
UPC	841874025528
Manufacturer	Lexibook

Warranty Information

For detailed warranty information regarding your LEXiBOOK JCR10i2 Bilingual Interactive Card Reader, please refer to the warranty card included with your purchase or visit the official LEXiBOOK website. Warranty terms and conditions may vary by region and retailer.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact LEXiBOOK customer support. You can typically find contact information on the official LEXiBOOK website or through the retailer where the product was purchased.
For more information, visit the LEXiBOOK Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question