Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Power Cord (Compatible with Fisher FBX820)

PKPOWER 5ft AC Power Cord User Manual

Model: AC Power Cord (Compatible with Fisher FBX820)

Overview Setup Operation Maintenance Troubleshooting Specifications Support

1. Product Overview

This manual provides essential information for the safe and effective use of the PKPOWER 5ft AC Power Cord. This 2-prong wire lead is designed to provide power to compatible devices, specifically the Fisher FBX820 Wireless PA Speaker. It ensures a reliable power connection for optimal device performance.



Figure 1: The PKPOWER 5ft AC Power Cord, shown coiled. This cable features a standard 2-prong North American plug on one end and a figure-8 (C7) connector on the other, designed for various electronic devices.

2. Setup and Connection

Before connecting the power cord, ensure that the device you intend to power is compatible with a 2-prong AC power input and the specified voltage and current requirements. This cable is specifically designed for the Fisher FBX820 Wireless PA Speaker.

1. **Identify the Power Input:** Locate the power input port on your device (e.g., Fisher FBX820 Wireless PA Speaker). It should be a 2-pin, figure-8 (C7) type connector.
2. **Connect to Device:** Carefully insert the figure-8 connector end of the PKPOWER cord into the device's power input port. Ensure it is fully seated and secure.
3. **Connect to Power Outlet:** Insert the 2-prong plug end of the power cord into a standard North American (Type A) wall outlet or surge protector. Ensure the outlet provides the correct voltage (100-240V AC).
4. **Verify Connection:** Confirm that both ends of the cable are securely connected. The device should now be ready to receive power.



Figure 2: A detailed view of the two distinct ends of the PKPOWER AC Power Cord. On the left is the standard 2-prong plug for wall outlets, and on the right is the figure-8 (C7) connector designed to plug into compatible electronic devices.

3. Operation

Once the PKPOWER AC Power Cord is correctly connected to both your device and a power outlet, the device will receive electrical power. Follow the specific operating instructions for your device (e.g., Fisher FBX820 Wireless PA Speaker) to power it on and use its functions. This power cord acts solely as a conduit for electrical current.

- Ensure the power cord is not kinked, twisted, or placed under heavy objects.
- Do not use the power cord if it appears damaged or frayed.
- Always grasp the plug firmly when inserting or removing it from an outlet; do not pull by the cord itself.

4. Care and Maintenance

Proper care of your PKPOWER AC Power Cord will ensure its longevity and safe operation.

- **Cleaning:** Disconnect the power cord from both the device and the wall outlet before cleaning. Wipe the cord and plugs with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or bending, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the entire length of the cord, including the plugs, for any signs of damage such as cuts, fraying, exposed wires, or discoloration. If any damage is observed, discontinue use immediately and replace the cord.
- **Environmental Conditions:** Avoid exposing the power cord to moisture, excessive heat, or corrosive substances.

5. Troubleshooting

If you experience issues with your device not receiving power, consider the following troubleshooting steps related to the power cord:

- **No Power to Device:**
  - Ensure both ends of the power cord are fully and securely plugged into the device and the wall outlet.
  - Check if the wall outlet is functional by plugging in another known working appliance.
  - Verify that the power cord itself is not damaged (no cuts, fraying, or bent pins). If damaged, replace it.
  - Confirm that the device's power switch is in the "On" position.
- **Loose Connection:**
  - If the cord feels loose in the device or outlet, gently re-insert it. If it consistently remains loose, the cord or the port may be worn and require replacement.
- **Overheating:**
  - If the power cord feels unusually warm to the touch, immediately disconnect it from the power source and the device. This could indicate an overload or internal damage. Do not use the cord again.

If troubleshooting steps do not resolve the issue, please refer to the "Support and Warranty" section for assistance.

6. Product Specifications

Feature	Detail
Input Voltage	100-240V AC
Frequency	50-60Hz
Protection Features	OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), SCP (Short Circuit Output Protection)
Certifications	CE / FCC / RoHS certified

Feature	Detail
Product Dimensions	4 x 2 x 0.5 inches (approximate, for packaging)
Item Weight	3 ounces
Connector Type (Device End)	2-Pin (Figure-8 / C7)
Connector Type (Wall End)	Type A - 2 pin (North American)
Compatible Devices	Speakers (specifically Fisher FBX820 Wireless PA Speaker)
Color	Black
Power Source	AC

7. Support and Warranty

PKPOWER is committed to providing reliable products and excellent customer service. If you encounter any issues or have questions regarding your AC Power Cord, please contact us directly.

Contacting Customer Service:

You can contact PKPOWER customer service through your purchase platform. For Amazon orders, locate your order in "Your Account" and click the "Problem with this order?" button. Then, select the "Contact Seller" button to send an email message. Our customer service team aims to respond within 24 hours to assist with any problems or replacement requests.

Warranty Information:

PKPOWER products are tested by the manufacturer to match and/or exceed OEM specifications. For specific warranty terms and conditions, please refer to the product listing at the time of purchase or contact customer service directly. Our friendly and reliable customer service is available to assist you.

© 2023 PKPOWER. All rights reserved.
For more information, visit PKPOWER Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CG62GTPQ

More documents and user manuals: **https://manuals.plus/**