Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lexibook DMWTW1SP

Lexibook Spider-Man Watch Walkie-Talkies DMWTW1SP

User Instruction Manual

Introduction

Thank you for choosing the Lexibook Spider-Man Watch Walkie-Talkies. This 2-in-1 device combines a digital watch with a walkie-talkie function, offering an exciting way for children to communicate and explore. This manual provides essential information for safe and optimal use of your device.

Important Safety Information

- **WARNING!** Not suitable for children under 3 years of age.
- **CHOKING HAZARD:** Contains small parts that could be swallowed.
- **WARNING!** This toy produces flashes that may trigger epilepsy in sensitive individuals.
- Always supervise children during use.
- Do not expose the device to extreme temperatures or direct sunlight for prolonged periods.
- Do not immerse the device in water.

Package Contents

Please check that all items are present in the package:

- 2 x Lexibook Spider-Man Watch Walkie-Talkies (one red, one blue)
- 1 x USB Charging Cable (for both watches)
- 1 x Instruction Manual


MARVEL
SPIDER-MAN
MONTRES TALKIE-WALKIES
WALKIE TALKIE WATCHES
LEXIBOOK
6+
TALKIE- WALKIES : JUSQU'À 200M ! WALKIE TALKIES: UP TO 200M!
AFFICHAGE NUMÉRIQUE
DIGITAL DISPLAY
AFFICHAGE DE L'HEURE ET DE LA DATE
HOUR AND DATE DISPLAY
RECHARGEABLE
MONTRES TALKIE-WALKIES WALKIE TALKIE WATCHES

Image: The product packaging, displaying both the red and blue Spider-Man watch walkie-talkies.

Product Overview

Each watch walkie-talkie features a digital time display, a built-in flashlight, and an imitation compass. The durable plastic construction ensures longevity.





Image: A pair of Lexibook Spider-Man Watch Walkie-Talkies, one red and one blue, showing the digital display and wrist straps.

Key Components:

- **Digital Display:** Shows time and other indicators.
- **Antenna:** For walkie-talkie communication.
- **Talk Button:** Press and hold to transmit your voice.
- **Flashlight Button:** Activates the built-in flashlight.
- **Mode/Set Buttons:** For adjusting time and other settings.
- **Microphone:** Captures your voice for transmission.
- **Speaker:** For receiving audio.
- **USB Charging Port:** For recharging the internal battery.

Setup

1. Charging the Devices

1. Locate the USB charging port on each watch.
2. Connect the provided USB charging cable to the watch and to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator (if present) will show the charging status. Allow approximately 2-3 hours for a full charge.
4. Disconnect the cable once fully charged.

2. Powering On/Off

- To power on, press and hold the Power button (refer to product diagram for exact location) until the display lights up.
- To power off, press and hold the Power button again until the display turns off.

3. Wearing the Watch

Adjust the strap to fit comfortably on the user's wrist. Ensure the antenna is not obstructed for optimal walkie-talkie performance.







Image: A young boy wearing the blue Spider-Man watch walkie-talkie on his left wrist.

Operating Instructions

1. Using the Walkie-Talkie Function

- Ensure both watch walkie-talkies are powered on and within range (up to 200 meters in open areas).
- To **transmit**: Press and hold the Talk button. Speak clearly into the microphone. Release the button when you finish speaking.
- To **receive**: Ensure the Talk button is not pressed. The intelligent ambient sound reducer helps ensure clear conversations.
- For best performance, keep the antenna extended and avoid obstructions between the two devices.

2. Setting the Digital Time

1. Press the Mode button to cycle through display modes until the time setting mode is activated (consult the specific button layout on your device).
2. Use the Set button to adjust hours, minutes, and other time-related settings.
3. Press the Mode button again to confirm and exit the time setting mode.

3. Using the Flashlight

- Press the Flashlight button to turn the light on.
- Press the Flashlight button again to turn the light off.

4. Imitation Compass

The integrated compass is an *imitation toy* designed to inspire exploration and develop a sense of direction. It is not a functional navigation tool and should not be relied upon for accurate directional guidance.

Maintenance

Cleaning

- Wipe the device with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.

Battery Care

- Recharge the battery regularly to maintain its lifespan.
- Avoid fully discharging the battery frequently.
- If the device will not be used for an extended period, charge it partially before storage and recharge every few months.

Storage

- Store the watch walkie-talkies in a cool, dry place away from direct sunlight.
- Keep out of reach of small children when not in use.

Troubleshooting

Problem	Possible Solution
Device does not power on.	Ensure the battery is charged. Connect to a USB power source and try again.
Cannot communicate between watches.	Check if both devices are powered on. Ensure they are within the 200m range and there are no major obstructions. Verify the Talk button is being pressed correctly during transmission.
Poor sound quality.	Move closer to the other device. Ensure the antenna is fully extended. Avoid noisy environments.
Flashlight not working.	Check battery level. Ensure the Flashlight button is pressed firmly.

Specifications

- **Model Number:** DMWTW1SP
- **Brand:** Lexibook
- **Color:** Blue/Red
- **Communication Range:** Up to 200 meters (in optimal conditions)
- **Special Features:** Rechargeable, Digital Time Display, Flashlight, Imitation Compass, Intelligent Ambient Sound Reducer
- **Power Source:** USB Rechargeable Battery (1 specific product battery required)
- **Material:** Durable Plastic
- **Country of Origin:** China

Warranty and Support

Manufacturer's Warranty

This product comes with a**2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Lexibook customer support. Refer to the Lexibook official website or product packaging for the most up-to-date contact information.

Note: Spare parts availability information is not available. Software updates are not applicable for this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CG8DRGTR

More documents and user manuals: **https://manuals.plus/**