DeerRun BA06

DeerRun Walking Pad 2 in 1 Under Desk Treadmill

Model: BA06 User Manual

Introduction Safety Information Product Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the DeerRun Walking Pad 2 in 1 Under Desk Treadmill, Model BA06. This manual provides essential information for the safe and efficient use, setup, operation, maintenance, and troubleshooting of your new walking pad. Please read this manual thoroughly before first use and keep it for future reference.

2. Safety Information

To ensure your safety and prolong the life of your treadmill, please adhere to the following precautions:

- Always place the treadmill on a flat, stable, and level surface.
- Ensure adequate clear space around the treadmill for safe operation and emergency stops.
- Keep children and pets away from the treadmill during operation.
- Do not use the treadmill if it is damaged or malfunctioning. Contact customer service immediately.
- Wear appropriate athletic footwear and clothing during use.
- Do not exceed the maximum weight capacity of 265 pounds (120 kg).
- Always unplug the treadmill from the power outlet before cleaning, maintenance, or moving.
- Consult a physician before starting any new exercise program.

3. Product Overview

The DeerRun Walking Pad BA06 is a versatile 2-in-1 treadmill designed for both walking and light jogging in home or office environments. Its compact and portable design allows for easy storage and use.

Key Features:

- **2-in-1 Design:** Functions as an under-desk walking pad or a standalone jogging machine.
- **Powerful & Quiet Motor:** Equipped with a 2.5HP motor, operating below 50 decibels, supporting speeds from 0.6 to 3.8 MPH.
- **Durable Running Belt:** Features a 5-layer shock-absorbing running belt for comfort and joint protection.
- **LED Digital Monitor:** Displays essential workout data such as speed, time, distance, and calories burned.
- **Remote Control:** Conveniently adjust speed and settings.
- **Compact & Portable:** Lightweight (41.8 lbs) with built-in wheels for easy movement and storage under desks, beds, or sofas. Dimensions: 44 x 20 x 4.5 inches.
- **PitPat App Integration:** Requires the PitPat app for activation and access to training programs, events, and social features.
- **Easy Lubrication:** Features an independent oil hole for simple maintenance.

Product Components:

- Treadmill Base
- Motor Housing
- Power Cord
- Remote Control
- User Manual (this document)

4. Setup

4.1 Unpacking and Placement

The DeerRun Walking Pad comes fully assembled. Simply remove it from the packaging and place it on a flat, stable, and level surface. Ensure there is sufficient space around the treadmill for safe operation.

The DeerRun Walking Pad is designed for easy storage under furniture like sofas or desks.

4.2 Power Connection

Connect the power cord to the treadmill and then plug it into a standard electrical outlet. Ensure the power switch on the treadmill is in the 'ON' position.

4.3 PitPat App Activation

The treadmill requires activation via the PitPat app. Download the PitPat app on your smartphone or tablet. Follow the in-app instructions to connect and activate your DeerRun Walking Pad. This unlocks training programs, events, and social features.

Video demonstrating the PitPat app integration and various usage modes of the DeerRun Walking Pad.

5. Operating Instructions

5.1 Turning On/Off

After connecting to power and activating via the PitPat app, press the power button on the remote control to turn on the treadmill. The LED display will illuminate. To turn off, press the power button again.

5.2 Speed Adjustment

Use the remote control to adjust the speed. The treadmill offers a speed range of 0.6 to 3.8 MPH.

- **Walking Mode:** Typically 1-4 KPH (approximately 0.6-2.5 MPH). Ideal for under-desk use or light walking.
- **Running Mode:** Typically 4-6 KPH (approximately 2.5-3.8 MPH). Suitable for jogging.

The LED digital monitor displays speed, time, distance, and calories, controlled by the remote.

5.3 Using the PitPat App

The PitPat app provides enhanced control and tracking features. Once connected, you can:

- Access various training programs.
- Participate in fitness events and challenges.
- Track your workout progress and statistics.
- Connect with a global community of users.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your DeerRun Walking Pad.

6.1 Lubrication

The treadmill belt requires periodic lubrication to ensure smooth operation. Locate the oil drip hole on the upper right corner of the treadmill. Apply a small amount of silicone lubricant as per the instructions provided with the lubricant or when the belt feels dry or sticky.

The independent oil hole simplifies the lubrication process for the running belt.

6.2 Belt Alignment

If the running belt shifts to one side during use, it needs to be realigned. Follow the steps in the video below to adjust the belt tension screws at the rear of the treadmill.

Video demonstrating how to fix treadmill belt alignment issues by adjusting the rear screws.

6.3 Cleaning

Wipe down the treadmill with a damp cloth after each use to remove sweat and dust. Do not use abrasive cleaners or solvents.

7. Troubleshooting

If you encounter any issues with your DeerRun Walking Pad, please refer to the solutions below. If the problem persists, contact customer service.

7.1 Remote Control Not Responding

If the remote control is unresponsive, it may not be paired correctly or have poor battery contact. Follow the steps in the video below to re-pair the remote or check the battery.

Video demonstrating how to pair the remote control or troubleshoot unresponsiveness.

7.2 Treadmill Not Turning On

- Ensure the power cord is securely plugged into both the treadmill and a working electrical outlet.
- Check if the power switch on the treadmill is in the 'ON' position.
- Verify that the PitPat app has successfully activated the treadmill.

8. Specifications

Feature	Detail
Model Number	BA06
Brand	DeerRun
Motor Horsepower	2.5 HP
Speed Range	0.6 - 3.8 MPH
Maximum Weight Capacity	265 Pounds (120 kg)
Noise Level	Below 50 dB
Product Dimensions (L x W x H)	118.5 x 51.24 x 10.6 cm (44 x 20 x 4.5 inches)
Item Weight	22.5 kg (41.8 lbs)
Running Belt Layers	5-Layer Shock-Absorbing
Display Type	LCD
Control Method	Remote Control, PitPat App
Power Source	Corded Electric
Material	Alloy Steel
Color	Gray
Included Components	Treadmill base, Motor housing, Power cord, User manual

9. Warranty & Support

The DeerRun Walking Pad treadmill comes with a 12-month warranty. For any issues before or after sales, please contact our

professional customer service team. We provide support via email and phone.

Customer Service Contact: Please refer to the contact information provided on your product packaging or the official DeerRun website.