Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eufy T29D1

eufy Official Replacement Side Brushes User Manual

Model: T29D1

Introduction

This manual provides instructions for the installation and maintenance of your eufy Official 4-Pack Replacement Side Brushes. These brushes are essential for maintaining the optimal cleaning performance of your compatible eufy robotic vacuum cleaner.

Product Compatibility

These replacement side brushes are compatible with the following eufy robotic vacuum cleaner models:

- Omni C20
- L60 Series (T2280, T2265, T2275, T2267)
- L50 Series (T2277, T2268, T2278)

Ensure your vacuum cleaner model is listed above to guarantee proper fit and function.

Installation and Replacement

Replacing the side brushes is a simple, tool-free process designed for user convenience. Regular replacement ensures your eufy vacuum maintains its cleaning efficiency.



Image: Four eufy replacement side brushes, each with three bristles, and four small screws. These are the components included in the 4-pack replacement kit.

1. **Power Off:** Before beginning, ensure your eufy robotic vacuum cleaner is powered off and disconnected from its charging base.
2. **Locate Brushes:** Turn the vacuum cleaner upside down to access the underside. The side brushes are typically located on the front corners of the device.
3. **Remove Old Brushes:** Gently pull the old side brushes upwards to detach them. Some models may require unscrewing a small screw in the center of the brush. If screws are present, use a small screwdriver to remove them.
4. **Install New Brushes:** Align the new side brush with the corresponding post on the vacuum cleaner. Press down firmly until it clicks into place. If your model uses screws, secure the new brush with the provided screws.
5. **Verify Installation:** Ensure both new side brushes are securely attached and can rotate freely.

This set includes four side brushes, providing replacements for at least six months of typical usage.

Maintenance and Replacement Frequency

To ensure optimal performance of your eufy robotic vacuum cleaner, regular maintenance of the side brushes is recommended.

- **Maintenance:** Inspect the side brushes once every two weeks for wear, tangles, or damage. Remove any hair or debris wrapped around the brushes or their base.
- **Replacement:** It is recommended to replace the side brushes every 3 to 6 months. The exact replacement frequency may vary depending on your usage frequency, the type of flooring, and the amount of debris collected. Replace brushes sooner if they appear visibly worn, bent, or are no longer effectively sweeping debris.

Authenticity and Quality

To ensure the longevity and optimal performance of your eufy robotic vacuum cleaner, it is crucial to use genuine official eufy accessories. Authentic accessories are designed to meet eufy's quality standards and ensure compatibility and durability.

Specifications

Attribute	Detail
Product Dimensions	6.02 x 6.02 x 1.65 inches
Item Weight	1.12 ounces
Manufacturer	eufy
Item Model Number	T29D1

Troubleshooting

If you encounter issues with your replacement side brushes, consider the following common solutions:

- **Brushes Not Spinning:**
  - Ensure the brushes are correctly installed and fully seated on their posts.
  - Check for any hair or debris tangled around the brush shaft or within the brush mechanism on the vacuum. Clean thoroughly if necessary.
  - Verify that the vacuum cleaner itself is functioning correctly and not in an error state.
- **Reduced Cleaning Performance:**
  - Inspect the brushes for excessive wear or bent bristles. If bristles are severely bent or missing, it's time for replacement.
  - Ensure the vacuum's main brush and filter are also clean and in good condition, as they contribute to overall cleaning performance.

If problems persist after following these steps, please contact eufy customer support for further assistance.

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the official eufy website or contact eufy customer service directly. Keep your purchase receipt for warranty claims.
eufy Customer Support: www.eufylife.com/support

© 2024 eufy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHM4C21Y

More documents and user manuals: **https://manuals.plus/**