Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TIMEMORE C2 Fold (TMUS10025-US)

TIMEMORE Chestnut C2 Fold Manual Coffee Grinder Instruction Manual

Model: C2 Fold (TMUS10025-US)

Introduction

Thank you for choosing the TIMEMORE Chestnut C2 Fold Manual Coffee Grinder. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new grinder. Designed for coffee enthusiasts, the C2 Fold offers precise and consistent grinding for various brewing methods, from espresso to French press. Its compact and durable design makes it ideal for both home use and travel.



Image: The TIMEMORE Chestnut C2 Fold Manual Coffee Grinder with coffee beans.

Product Features

- **Newly Upgraded Design:** The C2-Fold features a travel-friendly foldable handle and a modern twill line design, maintaining a lightweight and comfortable feel.
- **Internal Adjustable Grind Setting:** Easily rotate the internal dial to select your preferred grind size, suitable for espresso, pour over, and French press.
- **Efficient Stainless Steel Burrs:** Equipped with durable 38mm stainless steel conical burrs for consistent and precise grinding.
- **Practical Capacity:** With a capacity of 20-25 grams, it's perfect for preparing one to two cups of coffee for daily use.
- **Ergonomic Anti-Slip Body:** The unique anti-slip textured body ensures a secure and comfortable grip during grinding.



Image: A hand holding the grinder, highlighting its anti-slip textured body for better grip.

Components

Your TIMEMORE Chestnut C2 Fold Manual Coffee Grinder consists of the following main components:

- Grinder Body (upper section with burr assembly)
- Grounds Container (lower section)
- Foldable Crank Handle
- Stainless Steel Conical Burrs (internal)
- Cleaning Brush (included in package)



Image: The grinder disassembled into its main parts, including the body, grounds container, handle, and cleaning brush.

Setup

Follow these steps to set up your TIMEMORE Chestnut C2 Fold Manual Coffee Grinder:

1. Unpack all components from the packaging.
2. Ensure the grounds container is securely attached to the main grinder body by twisting it clockwise until snug.
3. Unfold the crank handle by extending the arm and locking the knob into place.
4. Insert the crank handle onto the top shaft of the grinder.

Your browser does not support the video tag.

Video: Official demonstration of the TIMEMORE C2 Fold Coffee Grinder, including assembly and usage.

Operating Instructions

Adjusting Grind Size

The TIMEMORE C2 Fold features an internal adjustment dial for precise grind size control. To adjust:

1. Remove the grounds container and the crank handle.
2. Locate the adjustment dial at the bottom of the burr assembly.
3. Turn the dial clockwise for a finer grind and counter-clockwise for a coarser grind. Each 'click' represents a step in grind size.
4. Refer to the table below for recommended starting points for common brewing methods.



Image: A detailed view of the internal adjustment dial, showing markings for fine and coarse settings.

Recommended Grind Settings (Approximate Clicks from Zero Point)

Brewing Method	Recommended Clicks
Espresso	10-14 clicks

Brewing Method	Recommended Clicks
Pour Over Coffee	18-24 clicks
French Press	25-27 clicks

Note: These are starting recommendations. Optimal grind size may vary based on bean type, roast level, and personal preference.

Grinding Coffee

1. Open the top lid of the grinder.
2. Add your desired amount of whole coffee beans into the hopper (capacity: 20-25g).
3. Place the crank handle back onto the shaft.
4. Hold the grinder firmly with one hand and rotate the crank handle clockwise with the other until all beans are ground.
5. Once grinding is complete, remove the grounds container and pour out your freshly ground coffee.

Maintenance

Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder. It is recommended to clean the burrs after every few uses, or when changing coffee bean types.

1. Disassemble the grounds container and the crank handle.
2. Use the included cleaning brush to gently brush away any residual coffee grounds from the burrs and internal components.
3. Wipe the exterior of the grinder with a soft, dry cloth.

Important: DO NOT wash the grinder with water or immerse it in water. Water can damage the internal mechanisms and burrs, leading to rust and malfunction. Only use the cleaning brush and a dry cloth.

Storage

Store your grinder in a cool, dry place away from direct sunlight and moisture. The foldable handle design allows for compact storage, making it convenient for travel.

Troubleshooting

If you encounter any issues with your TIMEMORE Chestnut C2 Fold grinder, please refer to the common problems and solutions below:

- **Grinder feels stiff or hard to turn:**This may indicate that the grind setting is too fine for the beans, or there are too many beans in the hopper. Try adjusting to a coarser setting or reducing the amount of beans. Ensure no foreign objects are present.
- **Inconsistent grind:** Check if the internal burr assembly is securely tightened. Loose components can lead to uneven grinding. Also, ensure the burrs are clean and free of old coffee residue.
- **Grinder not producing grounds:** Verify that the burrs are not completely jammed. Disassemble and clean thoroughly. If the handle spins freely without grinding, the burr may be detached or damaged.
- **Handle is loose:** Ensure the crank handle is properly seated on the shaft and the folding mechanism is locked into place.

If the issue persists after attempting these solutions, please contact TIMEMORE customer support for further assistance.

Specifications

Attribute	Detail
Brand	TIMEMORE
Model Number	TMUS10025-US
Color	Black Grey
Material	Stainless Steel, Aluminum, Plastic
Product Dimensions	5.63 x 2.2 x 7.52 inches
Item Weight	6.3 ounces
Recommended Uses	Coffee Preparation
Country of Origin	China

Warranty and Support

TIMEMORE products are manufactured with high-quality materials and undergo strict quality control. For warranty information and support, please refer to the warranty card included with your product or visit the official TIMEMORE website.
You can also visit the TIMEMORE Store on Amazon for additional product information and customer service.

© 2024 TIMEMORE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHVYMJQT

More documents and user manuals: **https://manuals.plus/**