Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXIBOOK SD50MI

LEXIBOOK Miraculous Ladybug Chat Noir Electronic Interactive Diary SD50MI User Manual

Model: SD50MI

Introduction

Welcome to your new LEXIBOOK Miraculous Ladybug Chat Noir Electronic Interactive Diary! This manual provides essential information for setting up, operating, and maintaining your diary to ensure a fun and secure experience. Keep your secrets safe with its personalized 4-digit code, enjoy captivating melodies, and record your voice.

Important Safety Information

WARNING: Not suitable for children under 3 years. Choking hazard due to small parts.

What's in the Box

- 1 Electronic Interactive Diary
- 1 Stylus Pen
- 1 User Manual
- 1 Notebook



Image: The electronic diary, notebook, and stylus pen as included in the package.

Setup

1. Battery Installation

The diary requires 3 AA batteries (not included). To install:

1. Locate the battery compartment on the back of the diary.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 3 new AA batteries, ensuring correct polarity (+/-).
4. Replace the cover and secure it with the screw.

2. Setting Your Personal 4-Digit Code

Upon first use or after battery replacement, you will need to set your secret code:

1. Open the diary.
2. Press and hold the **SET** button (usually marked with a lock icon) until you hear a confirmation sound.
3. Enter your desired 4-digit code using the numeric keypad.
4. Press the **SET** button again to confirm. You will hear another confirmation sound.
5. *Important:* Remember your code. If you forget it, you may need to reset the diary, which will erase any recorded messages.



Image: The electronic diary opened, revealing the internal compartment designed to hold the notebook, along with the numeric keypad and control buttons for its electronic functions.

Operating Instructions

1. Opening Your Diary

To open the diary, enter your 4-digit secret code on the keypad. The diary will unlock with a sound effect.

2. Voice Recording and Playback

The diary allows you to record and play back secret messages:

1. Press the **RECORD** button (often marked with a microphone icon).
2. Speak clearly into the microphone.
3. Press the **STOP** button to end the recording.
4. To listen to your recording, press the**PLAY** button.
5. Some models may include a voice changer function. Refer to the specific instructions on the device for activation.

3. Musical Melodies and Sound Effects

Your diary features 10 captivating melodies and enchanting sound effects:

- Press the **MUSIC** button (often marked with a musical note icon) to cycle through the melodies.
- Sound effects will play automatically when the diary is opened or certain actions are performed.

4. Writing and Personalization

Use the included notebook and stylus pen to write your thoughts and secrets. The diary also features a photo frame for personalization.



Image: A child happily writing in the included notebook, placed within the electronic diary.

Maintenance

- Keep the diary clean by wiping it with a soft, dry cloth.
- Avoid exposing the diary to direct sunlight, moisture, or extreme temperatures.
- Remove batteries if the diary will not be used for an extended period to prevent leakage.
- Replace the notebook when pages are full. Compatible replacement notebooks can be purchased separately.

Troubleshooting

Problem	Solution
Diary does not turn on.	Check if batteries are installed correctly and are not depleted. Replace with new AA batteries if necessary.
Cannot open the diary.	Ensure you are entering the correct 4-digit code. If forgotten, you may need to perform a factory reset (refer to specific device instructions or contact support).
Voice recording is unclear or not working.	Speak closer to the microphone. Ensure there is no background noise. Check battery level.
Sound effects or music are not playing.	Check battery level. Ensure the volume is not set to minimum.

Specifications

- **Model Number:** SD50MI
- **Dimensions:** 17.8 x 20.3 x 4 cm
- **Weight:** 410 g
- **Material:** Plastic
- **Power:** 3 x AA batteries (not included)
- **Recommended Age:** 3 years and up
- **Educational Value:** Fosters creative writing and imaginative play through secret journaling.

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official LEXIBOOK website. You can also contact LEXIBOOK customer service for assistance.
Official LEXIBOOK Store: Visit the LEXIBOOK Store

© 2023 LEXIBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJ29Q55H

More documents and user manuals: **https://manuals.plus/**