**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Belleur CLPT001M_B

# Belleur 7-in-1 Foldable Wooden Pikler Triangle Set User Manual

Model: CLPT001M_B
Brand: Belleur

## 1. Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Belleur 7-in-1 Foldable Wooden Pikler Triangle Set. This versatile indoor climbing toy is designed to support the physical development and imaginative play of toddlers.

## 2. Safety Information

**WARNING: Adult supervision is required at all times when children are using this product.**

- **Recommended Age:** This product is suitable for children aged 12 months to 6 years.
- **Weight Limit:** Ensure the combined weight of children on the structure does not exceed safe limits. Refer to product specifications for details.
- **Placement:** Place the climbing set on a flat, stable surface. Ensure adequate clear space around the structure to prevent collisions.
- **Inspection:** Before each use, inspect all components for damage, loose connections, or wear. Do not use if any part is compromised.
- **Materials:** The set is crafted from premium natural wood with smooth edges and non-toxic finishes.
- **Folding Mechanism:** Exercise caution when folding or unfolding the set to prevent pinching. Ensure the locking mechanism is fully engaged before use.

## 3. Package Contents

Verify that all components are present before beginning assembly:

- 1 x Pikler Triangle (Foldable Frame)
- 1 x Slide & Climb Board (Reversible)
- 1 x Rock Arch (Curved Frame)

- Necessary hardware (screws, connectors, tools if provided)

Refer to the image below for a visual representation of the main components.




Figure 3.1: Main components of the Belleur Pikler Triangle Set.

## 4. Assembly Instructions

Assembly typically requires two adults. Follow the included step-by-step guide provided in the product packaging for detailed instructions. Ensure all connections are secure and tight.

- Unpack all components and verify against the package contents list.
- Assemble the Pikler Triangle frame, ensuring all bolts are tightened for stability. The design features deep and secure connections for enhanced safety.
- Attach the Rock Arch, ensuring it is securely fastened.
- The Slide & Climb Board can be attached to either the Pikler Triangle or the Rock Arch. Ensure the attachment

points are fully engaged.

- Confirm all parts are correctly aligned and stable before allowing children to use the product.




Figure 4.1: Examples of secure connections and solid wood construction.

## 5. Operating Instructions

The Belleur 7-in-1 Pikler Triangle Set offers multiple configurations for varied play experiences:

- **Climbing Triangle:** Use the main triangular frame for climbing.
- **Climbing Arch:** The curved frame can be used independently for climbing or rocking.
- **Ramp/Slide:** The reversible board functions as a smooth slide on one side and a climbing ramp with holds on the other. Attach it to the Pikler Triangle or Arch at various heights.
- **Rocking Arch:** Invert the arch to create a rocking structure.
- **Combined Structures:** Connect the Pikler Triangle, Arch, and Ramp/Slide in various ways to create tunnels,

bridges, and more complex climbing structures.

The set features a foldable design for convenient storage. To fold, locate the side knobs, loosen them, and carefully collapse the frame. Ensure the knobs are tightened again to secure the folded position.




Figure 5.1: Foldable design for easy storage.




Figure 5.2: Various play configurations of the 7-in-1 set.

## 6. Maintenance

Regular maintenance ensures the longevity and safety of your climbing set.

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Dry immediately.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight. Retighten as necessary.
- **Storage:** When not in use, store the foldable set in a dry, indoor environment away from direct sunlight or extreme temperatures to prevent wood warping or damage.
- **Wood Care:** The product is made from high-quality solid wood with a smooth surface. Avoid prolonged exposure to moisture.

## 7. Troubleshooting

If you encounter any issues with your Belleur Pikler Triangle Set, consider the following:

- **Instability:** Ensure all connections are fully tightened. Verify the set is placed on a level surface.
- **Difficulty Folding/Unfolding:** Check for any obstructions in the folding mechanism. Ensure the side knobs are sufficiently loosened before attempting to fold.
- **Damaged Parts:** If any part appears damaged or broken, discontinue use immediately. Do not attempt to repair with non-original parts. Contact customer support for assistance.

## 8. Specifications

| Feature | Detail |
| --- | --- |
| Product Dimensions (L x W x H) | 39.37 x 19.69 x 23.03 inches |
| Item Weight | 33 pounds |
| Model Number | CLPT001M_B |
| Recommended Age | 12 months - 6 years |
| Material | Natural Wood |




Figure 8.1: Product dimensions.

## 9. Warranty and Support

Belleur is committed to providing quality products and customer satisfaction. For any questions, concerns, or assistance with your Belleur 7-in-1 Foldable Wooden Pikler Triangle Set, please contact our customer support team. We offer exceptional after-sales support to ensure peace of mind.

Please refer to your purchase documentation for specific warranty details and contact information.

© 2025 Belleur. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CJBSH7BT**

More documents and user manuals: **https://manuals.plus/**