Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER JDS-6000

PKPOWER 6ft AC Power Cord Cable User Manual

For Joha JDS-6000 Party Speaker

1. Introduction

This manual provides essential information for the proper use, setup, and maintenance of your PKPOWER 6ft AC Power Cord Cable. This cable is designed to provide reliable power connectivity for compatible devices, including the Joha JDS-6000 Party Speaker. Please read this manual thoroughly before use to ensure optimal performance and safety.

2. Safety Information

WARNING: This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

- Ensure the power cord is fully inserted into both the device and the power outlet.
- Do not use the power cord if it is damaged, frayed, or has exposed wires.
- Avoid placing the cord in high-traffic areas where it could be tripped over or damaged.
- Do not overload electrical outlets.
- Keep the power cord away from water and excessive heat.

3. Product Overview

The PKPOWER 6ft AC Power Cord Cable is a durable and reliable power solution. It features a standard US 2-prong plug (NEMA 1-15P) on one end and a figure-8 connector (IEC C7) on the other, designed for a wide range of electronic devices.



An image of the PKPOWER 6ft AC Power Cord Cable, neatly coiled and secured, showcasing its compact form factor.

Key Features:

- **Input:** 100-240V 50-60Hz, ensuring broad compatibility with international power standards.
- **Certifications:** CE / FCC / RoHS certified, meeting high safety and environmental standards.
- **Protection:** Equipped with OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) for enhanced device safety.
- **Compatibility:** Specifically designed for Joha JDS-6000 Party Speaker and other devices requiring a NEMA 1-15P to IEC C7 power cord.

4. Setup

Setting up your PKPOWER AC Power Cord Cable is straightforward. Follow these steps to connect your device:

1. Identify the power input port on your device (e.g., Joha JDS-6000 Party Speaker). This port typically matches the figure-8 (IEC C7) connector of the power cord.
2. Insert the figure-8 (IEC C7) connector firmly into the device's power input port.
3. Locate a standard AC power outlet (100-240V, 50-60Hz).
4. Insert the 2-prong (NEMA 1-15P) plug of the power cord into the AC power outlet.
5. Ensure both ends of the cable are securely connected before powering on your device.



A straight-on view of the PKPOWER AC Power Cord Cable, highlighting both the standard US 2-prong plug (NEMA 1-15P) and the figure-8 connector (IEC C7) for clear identification of connection points.

5. Operating

Once the PKPOWER AC Power Cord Cable is correctly connected to your device and a power outlet, your device should receive power. The cable operates passively, transmitting electrical current. There are no user-operable controls on the cable itself.

- Always ensure the cable is not kinked or bent sharply, which can damage internal wiring.
- Do not pull the cable by the cord itself to disconnect; always grasp the plug firmly.

6. Maintenance

Proper maintenance will extend the lifespan of your power cord:

- **Cleaning:** Disconnect the cord from all power sources and devices before cleaning. Wipe the cord and connectors with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the cable loosely. Avoid tight coiling or wrapping around sharp objects, which can stress the cable. Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the entire length of the cord for any signs of damage, such as cuts, fraying,

or discoloration. Check the plugs for bent prongs or cracks. If any damage is found, discontinue use immediately and replace the cable.

7. Troubleshooting

If you encounter issues with your power cord, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Cable not fully connected.	Ensure both ends of the cable are securely plugged into the device and the wall outlet.
Device not powering on.	Power outlet is not active.	Test the outlet with another known working device or try a different outlet. Check circuit breaker.
Device not powering on.	Cable is damaged.	Inspect the cable for visible damage (cuts, fraying). If damaged, replace the cable immediately.
Cable feels warm.	Normal operation (slight warmth).	A slight warmth is normal. If the cable is excessively hot or emits a burning smell, disconnect immediately and replace.

8. Specifications

Feature	Detail
Product Type	AC Power Cord Cable
Length	6 feet
Input Voltage	100-240V AC, 50-60Hz
Connectors	NEMA 1-15P (US 2-prong) to IEC C7 (Figure-8)
Color	Black
Product Dimensions (Packaged)	6 x 4 x 2 inches
Item Weight	3 ounces
Manufacturer	Shenzhen Sunshine Technological Co., Ltd
Compatible Devices	Joha JDS-6000 Party Speaker and other compatible devices
Certifications	CE / FCC / RoHS
Protection Features	OVP, OCP, SCP Protection

9. Warranty and Support

PKPOWER products are designed for reliability and performance. For any questions, concerns, or support needs regarding your AC Power Cord Cable, please contact our customer service team.

How to Contact Us:

You can contact us directly from your Amazon account. Locate your order for this product and click the "Problem with this order?" button. Then, select the "Contact Seller" button to send an e-mail message. Our friendly and reliable customer service team aims to respond and assist you within 24 hours.

Your satisfaction and patience are greatly appreciated.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJXCWK95

More documents and user manuals: **https://manuals.plus/**