Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER SP35876

PKPOWER 6ft AC Power Cord Cable Lead User Manual

Model: SP35876

Introduction

This manual provides essential information for the safe and effective use of your PKPOWER 6ft AC Power Cord Cable Lead. Please read this manual thoroughly before use and retain it for future reference. This power cord is designed to provide reliable power connection for compatible devices, including the goplus Electric Folding Treadmill (SP35876).

Safety Information

Always observe the following safety precautions to prevent injury or damage to the product and connected devices:

- Ensure the power cord is compatible with your device's voltage and current requirements.
- Do not use the power cord if it is damaged, frayed, or has exposed wires.
- Avoid placing the cord in high-traffic areas where it could be tripped over or damaged.
- Do not overload electrical outlets.
- Keep the power cord away from water, heat sources, and sharp objects.
- Always grasp the plug, not the cord, when disconnecting from an outlet.
- This product is for indoor use only.

Product Overview

The PKPOWER 6ft AC Power Cord Cable Lead features a standard NEMA 5-15P (Type B) male plug on one end and an IEC C13 female connector on the other, commonly used for computers, monitors, printers, and various household appliances.



Figure 1: The PKPOWER 6ft AC Power Cord, coiled, displaying both the male plug and female connector, along with an illustration of the C13 connector type.



Figure 2: An angled view of the power cord, highlighting the robust construction of both the NEMA 5-15P plug and the IEC C13 connector.



Figure 3: A detailed close-up of the NEMA 5-15P male plug and the IEC C13 female connector, showing their design and pin configuration.



Figure 4: The power cord laid out straight, illustrating its 6-foot length and the connection points at each end.



Figure 5: The power cord shown alongside examples of compatible devices, including a monitor, desktop computer, electric kettle, and projector, demonstrating its versatility.

Specifications

Feature	Detail
Product Dimensions	6 x 4 x 2 inches
Item Weight	3 ounces
ASIN	B0CJY23WDP
Date First Available	September 27, 2023
Manufacturer	Shenzhen Sunshine Technological Co., Ltd

Country of Origin	China
Brand	PKPOWER
Connectivity Technology	Ethernet *(Note: This refers to the cable's general category, not its function as an Ethernet cable)*
Connector Type	NEMA 5-15P (Male) to IEC C13 (Female)
Compatible Devices	Devices requiring a C13 power input, such as goplus Electric Folding Treadmill (SP35876), PCs, monitors, printers, projectors, and other household appliances.
Color	Black
Input Voltage	5 Volts (AC) *(Note: This is likely a generic value from the source, actual power cords typically handle 125V AC for US standard)*
Power Source	Corded Electric

Setup

Follow these steps to properly connect your power cord:

1. **Inspect the Cord:** Before connecting, visually inspect the entire length of the power cord for any signs of damage, cuts, or fraying. Do not use if damaged.
2. **Identify Connectors:** Locate the NEMA 5-15P (standard 3-prong wall plug) and the IEC C13 (3-hole female connector) ends of the cable.
3. **Connect to Device:** Insert the IEC C13 female connector firmly into the corresponding power input port on your device (e.g., goplus Electric Folding Treadmill, PC, monitor). Ensure it is fully seated.
4. **Connect to Power Outlet:** Insert the NEMA 5-15P male plug into a standard, grounded 3-prong AC wall outlet. Ensure the outlet is easily accessible.
5. **Secure Placement:** Arrange the cord to avoid kinks, sharp bends, or being pinched by furniture. Keep it clear of walkways to prevent tripping hazards.

Operating

Once the power cord is securely connected to both your device and a power outlet, the device should receive power. Turn on your device using its own power switch, if applicable.

- Ensure the power cord is not under tension or stretched.
- Do not disconnect the power cord by pulling on the cable itself; always pull from the plug head.
- If the device is not in use for an extended period, it is recommended to unplug the power cord from the wall outlet.

Maintenance

Proper maintenance extends the life of your power cord:

- **Cleaning:** Disconnect the power cord from all power sources before cleaning. Wipe the cord and connectors with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or bending, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the cord for any signs of wear, such as cracks, cuts, or discolored insulation. If any damage is found, discontinue use immediately and replace the cord.

Troubleshooting

If you experience issues with your power cord, consider the following:

Problem	Possible Cause	Solution
Device not receiving power.	Cord not fully plugged in; Outlet is not live; Damaged cord; Device issue.	Ensure both ends of the cord are firmly connected. Test the outlet with another device. Inspect the cord for damage; replace if necessary. Check the device's power switch and internal components.
Cord feels hot.	Overload; Damaged cord; Poor connection.	Immediately unplug the cord. Ensure the device's power requirements do not exceed the cord's rating. Inspect for damage. Ensure connections are secure. If the problem persists, discontinue use and replace.
Visible damage to the cord.	Physical stress; Wear and tear.	Discontinue use immediately. Do not attempt to repair. Replace with a new, compatible power cord.

Warranty and Support

For warranty information or technical support, please contact PKPOWER directly. You can typically find contact details on the product packaging or by visiting the PKPOWER store on Amazon.
Contacting Seller: You can contact directly from Your Amazon Account. Locate the order and click the "Problem with this order?" button. Then select the "Contact Seller" button to send an e-mail message. PKPOWER aims to solve any problem or provide a replacement within 24 hours.
Your support to our business and your patience on the matter will be really appreciated.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJY23WDP

More documents and user manuals: **https://manuals.plus/**