Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy A-7CH2130-WT

Sweetcrispy 7 Drawer Chest Instruction Manual

Model: A-7CH2130-WT

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sweetcrispy 7 Drawer Chest. Designed for versatile storage in various settings, this mobile cabinet offers seven spacious drawers and convenient mobility.

Safety Information

Important Safety Precautions:

- Ensure the dresser is placed on a flat, even surface to maintain stability. Uneven surfaces may cause the unit to tip over.
- Do not overload the top surface with heavy objects to prevent accidents or damage to the dresser.
- It is highly recommended to secure the unit to a wall using an anti-tipping device (if included or available) to prevent accidental tipping, especially in households with children or pets.
- Keep small parts away from children during assembly to prevent choking hazards.

Package Contents

Before beginning assembly, verify that all components listed below are present.



Image: All components of the Sweetcrispy 7 Drawer Chest, including various wooden panels, metal drawer slides, bags of screws, dowels, and an instruction manual, laid out on a gray rug before assembly.

- Main cabinet panels (top, bottom, sides)
- Drawer panels (front, back, sides, bottom)
- Metal drawer slides
- Wheels (4, with 2 lockable)
- Assembly hardware (screws, dowels, cam locks, etc.)
- Screwdriver (basic tool)
- Instruction Manual

Setup and Assembly

Recommended: Two-Person Assembly.
For optimal speed and ease, two individuals are recommended for the assembly process. Review the entire user manual and watch the provided installation video before starting.

▶ **Watch video online**
This 7 Drawer Chest Was Worth Putting Together

Video: A detailed assembly guide for the Sweetcrispy 7 Drawer Chest, demonstrating each step of construction.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface. Match each part to the corresponding label in the instruction manual.
2. **Assemble the Main Frame:** Connect the side panels to the top and bottom panels using the provided hardware (dowels, cam locks, screws). Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the metal drawer slides to the inner sides of the main frame. Pay close attention to the orientation of the slides (left/right, front/back).
4. **Assemble Drawers:** For each of the seven drawers, connect the front, back, and side panels. Slide the drawer bottom into the designated grooves. Attach the remaining part of the metal drawer slides to the sides of each drawer.
5. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding position in the main frame.
6. **Attach Wheels:** Secure the four wheels to the bottom of the cabinet. Ensure the two lockable wheels are positioned at the front for easy access.
7. **Install Back Panel:** Secure the back panel to the main frame using small nails or screws.

8. **Final Checks:** Verify that all drawers open and close smoothly. Ensure the cabinet is stable and all connections are tight.

Note: Using an electric drill with appropriate bit sizes can expedite the assembly process, especially for screws that require pre-drilling or significant force. Avoid over-tightening screws to prevent damage to the wood.

Operating Instructions

Using the Drawers

The drawers feature a U-shaped cutout for easy access. Simply place your fingers into the cutout and pull to open. Push firmly to close.



Image: The Sweetcrispy 7 Drawer Chest with several drawers open, showcasing its storage capacity for various items.

Moving the Cabinet

The cabinet is equipped with four wheels for easy mobility. Two of these wheels include brakes for stability.

- To move the cabinet, ensure the brakes on the lockable wheels are disengaged.
- Gently push or pull the cabinet to its desired location.
- Once in position, engage the brakes on the lockable wheels to secure the cabinet and prevent unintended movement.



Image: A close-up view of one of the cabinet's wheels, highlighting the lockable brake feature.

Maintenance

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Drawer Slides:** Periodically check the drawer slides for smooth operation. If they become stiff, a small amount of silicone-based lubricant can be applied.
- **Hardware:** Occasionally check all screws and connections to ensure they remain tight. Re-tighten if necessary.

Troubleshooting

Drawers Not Closing Properly

- Ensure all drawer slides are correctly installed and aligned. Misaligned slides can prevent smooth closing.
- Check that all screws securing the drawer slides to both the cabinet frame and the drawers are fully tightened. Loose screws can cause misalignment.

- Verify that the drawer contents are not obstructing the closing mechanism or overflowing the drawer.

Cabinet Instability

- Confirm the cabinet is placed on a level surface.
- Ensure all wheels are properly attached and, if stationary, that the lockable wheels have their brakes engaged.
- Re-check all assembly hardware for tightness.

Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	7 Drawer Dresser
Product Dimensions	18.74"W x 15.75"D x 34.25"H
Number of Drawers	7
Material	Wood (MDF board)
Color	White
Item Weight	54.3 Pounds
Assembly Required	Yes
Mobility	4 Wheels (2 with brakes)



Image: A visual representation of the product dimensions (18.74"L x 15.75"W x 34.25"H) and total weight capacity (160 lbs).

Warranty and Support

This product comes with a **Limited Warranty**. For specific details regarding warranty coverage, please refer to the documentation included with your purchase or contact Sweetcrispy customer support.
For any questions, assistance with assembly, or to report missing/damaged parts, please contact Sweetcrispy Customer Support.
Visit the Sweetcrispy Store on Amazon

© 2024 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CK6HP2HY

More documents and user manuals: **https://manuals.plus/**