Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AGARO Sapphire

AGARO Sapphire Digital Air Fryer Instruction Manual

Model: Sapphire

1. Introduction

Thank you for choosing the AGARO Sapphire Digital Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods with little to no oil, utilizing 360° rapid hot air circulation technology. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep this manual for future reference.



The AGARO Sapphire Digital Air Fryer, a compact and efficient kitchen appliance.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

3. Product Overview

3.1 Components

The AGARO Sapphire Digital Air Fryer includes the following main components:

- Main unit
- Inner tray
- Pan with Handle

3.2 Key Features

The AGARO Sapphire Digital Air Fryer is equipped with features designed for convenience and efficient cooking:

- **7 Preset Programs:** French fries, Chicken leg, Shrimp, Cake, Steak, Fish, Ribs.
- **4.5L Non-Stick Frying Basket:** Ideal for small families and gatherings.
- **1400 Watts Power:** Ensures fast and healthy cooking.
- **360° Rapid Hot Air Circulation Technology:** Disperses heated air in all directions for even cooking with up to 90% less oil.
- **Digital Display and Touch Control:** Allows selection of functions, temperature control (80-200°C), and timer setting (up to 120 minutes).
- **Built-in Overheat Protection & Auto Shut-off Function:** Enhances safety during operation.



The intuitive digital display and touch controls for easy operation.



Seven convenient preset programs for various dishes.



The 360° air circulation technology ensures even cooking.



The 4.5L non-stick coated detachable basket for easy cleaning and cooking.

4. Setup

Before using your air fryer for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean:** Wash the frying basket and inner tray with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm of free space above the appliance.
4. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C to burn off any manufacturing residues. A slight odor may be present, which is normal. Ensure good ventilation during this process.

5. Operating Instructions

5.1 Basic Operation

1. **Plug In:** Connect the main plug to a grounded wall socket.
2. **Prepare Food:** Place the ingredients into the frying basket. Do not overfill.
3. **Insert Basket:** Slide the frying basket back into the air fryer.
4. **Power On:** Press the Power On/Off button to activate the display.
5. **Set Temperature and Time:** Use the temperature control buttons to set the desired temperature (80-200°C) and the timer control buttons to set the cooking time (up to 120 minutes).
6. **Start Cooking:** Press the Start button to begin the air frying process.
7. **Shaking (Optional):** Some recipes require shaking the ingredients halfway through the preparation time. Pull the basket out by the handle, shake it, and then slide it back into the air fryer. The air fryer will resume cooking automatically.
8. **Completion:** When the set cooking time has elapsed, the air fryer will beep. Carefully pull out the basket and remove the cooked food.

5.2 Using Preset Programs

The AGARO Sapphire Air Fryer comes with 7 convenient preset programs for common dishes:

- French Fries
- Chicken Leg
- Shrimp
- Cake
- Steak
- Fish
- Ribs

To use a preset program:

1. Place food in the basket and insert it into the air fryer.
2. Press the Power On/Off button.
3. Press the 'Functions' (M) button repeatedly to cycle through the preset programs until the desired icon is highlighted. The air fryer will automatically set the optimal temperature and time for that program.
4. Press the Start button to begin cooking. You can manually adjust the temperature and time even after selecting a preset if needed.

5.3 Cooking Tips

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes before adding food.
- **Oil Usage:** While the air fryer requires significantly less oil, a light spray or toss with a small amount of oil can enhance crispiness for some foods.
- **Batch Cooking:** For larger quantities, cook in smaller batches to ensure even cooking and crispiness.
- **Food Placement:** Arrange food in a single layer in the basket to allow hot air to circulate effectively.



The air fryer supports a wide variety of cooking options.

6. Cleaning and Maintenance

Clean the appliance after every use.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Basket and Tray:** The non-stick frying basket and inner tray can be washed with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water for about 10 minutes.
3. **Interior:** Wipe the inside of the appliance with a damp cloth and mild detergent. Do not use abrasive cleaners or steel wool.
4. **Exterior:** Clean the exterior of the air fryer with a damp cloth.
5. **Heating Element:** Use a cleaning brush to remove any food residue from the heating element.
6. **Storage:** Ensure all parts are thoroughly dry before storing the appliance in a cool, dry place.

7. Troubleshooting

If you encounter issues with your AGARO Sapphire Digital Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet not working.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overloaded. Food not shaken.	Cook in smaller batches. Shake the basket halfway through cooking. Ensure food is in a single layer.
White smoke coming from the appliance.	Grease residue from previous use. Fatty ingredients.	Clean the basket and inner tray thoroughly after each use. For fatty foods, place a piece of aluminum foil at the bottom of the basket to catch excess oil.
Food is not crispy.	Not enough oil. Temperature too low. Cooking time too short.	Lightly coat food with oil. Increase temperature or cooking time.

8. Specifications

Key technical specifications for the AGARO Sapphire Digital Air Fryer:

Feature	Specification
Model Name	Sapphire
Capacity	4.5 litres
Output Wattage	1400 Watts
Temperature Control	80-200°C
Timer	Up to 120 minutes
Control Method	Touch
Material	Stainless Steel
Product Dimensions	31D x 27.7W x 31H Centimeters
Item Weight	3.7 kg
Color	Black

9. Warranty and Support

The AGARO Sapphire Digital Air Fryer comes with a**2 Years Warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or any product-related inquiries, please contact AGARO customer service.

Keep your purchase receipt as proof of purchase for warranty validation.

For further assistance, please visit the official AGARO website or contact their customer support channels.

© 2024 AGARO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKHSL2RW

More documents and user manuals: **https://manuals.plus/**