Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AGARO Prima

AGARO Prima Digital Air Fryer User Manual

Model: Prima

Introduction

Welcome to the AGARO Prima Digital Air Fryer user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and retain it for future reference.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- **Read all instructions:** Familiarize yourself with the appliance and its functions before operation.
- **Electrical Safety:** Ensure the voltage rating on the appliance matches your local power supply. Do not immerse the cord, plug, or appliance in water or other liquid.
- **Hot Surfaces:** The appliance surfaces become hot during use. Use oven mitts or gloves when handling hot components. Do not touch hot surfaces directly.
- **Proper Ventilation:** Ensure adequate air circulation around the appliance during operation. Do not block any ventilation openings.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Unplug When Not in Use:** Always unplug the air fryer from the outlet when not in use and before cleaning. Allow it to cool down completely before handling.
- **Overheat Protection:** This air fryer is equipped with an overheat protection feature and an auto shut-off function for safety.

Product Components and Accessories

Your AGARO Prima Digital Air Fryer comes with a variety of accessories to enhance your cooking experience. Please ensure all components are present upon unboxing.



Image: The AGARO Prima Digital Air Fryer, a black, rectangular appliance with a digital display and a transparent door, showing food cooking inside. A fully roasted chicken is displayed on a platter next to the air fryer, demonstrating its cooking capabilities.



Image: A visual representation highlighting the 7-in-1 versatility of the AGARO Prima Air Fryer, including Air Fry, Toaster, OTG (Oven Toaster Grill), Dehydrate, Thaw Box, Rotisserie, and Pizza Grill functions.

Included Accessories:

- Main Unit
- Mesh Basket: For air frying smaller items like fries or nuggets.
- Mesh Trays (x2): For multi-level cooking and dehydrating.
- Skewer Rack: Holds skewers for kebabs.
- Crisper Trays (x2): For crisping food.
- Rotisserie Shaft: For roasting whole chickens or larger cuts of meat.
- Drip Tray: Collects excess oil and food particles for easy cleaning.
- Fetch Tool: For safely removing hot accessories.
- Skewers (x8): For preparing various skewered dishes.

Setup Guide

Follow these steps for the initial setup of your air fryer:

1. **Unpack:** Carefully remove all packaging materials and accessories from the box.
2. **Clean:** Wipe the exterior of the air fryer with a damp cloth. Wash all removable accessories (mesh basket, trays, etc.) with warm, soapy water. Rinse thoroughly and dry completely.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls and other appliances, ensuring at least 15 cm (6 inches) of clear space on all sides for proper ventilation.
4. **First Use (Burn-in):** Before cooking food, run the air fryer empty for about 10-15 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor may be present, which is normal. Ensure the area is well-ventilated.

Operating Instructions

Control Panel Overview



Image: A close-up of the AGARO Prima Air Fryer's digital touch control panel, displaying temperature and time settings, along with icons for 9 preset menu functions and various cooking controls.

The AGARO Prima Air Fryer features a digital touch display for easy control of functions, temperature, and timer.

Basic Operation

1. **Power On:** Plug the air fryer into a grounded electrical outlet. The display will light up.
2. **Temperature Setting:** Use the temperature control buttons (usually '+' and '-') to adjust the cooking temperature from 80°C to 200°C.
3. **Timer Setting:** Use the timer control buttons (usually '+' and '-') to set the cooking time, up to 120 minutes.
4. **Start/Pause:** Press the Start/Pause button to begin or temporarily stop the cooking process.

Preset Programs

The air fryer includes 9 preset programs for common dishes, simplifying your cooking:

- French Fries
- Steaks
- Fish
- Shrimp
- Pizza
- Chicken
- Baking
- Rotisserie
- Dehydrator

To use a preset program, simply select the corresponding icon on the digital touch display. The air fryer will automatically set the recommended temperature and time, which can be adjusted manually if needed.

Specific Cooking Functions



Image: A collage showcasing various delicious dishes prepared using the AGARO Prima Air Fryer, such as crispy French fries, roasted chicken, pizza, baked goods, and dehydrated fruit slices, demonstrating the appliance's versatility.

The 360° rapid hot air circulation technology ensures even cooking with up to 90% less oil, preserving the crispy exterior texture.

- **Air Frying:** Ideal for achieving crispy results with minimal oil. Use the mesh basket or crisper trays.
- **Baking:** Suitable for cakes, muffins, and other baked goods. Use appropriate bakeware.
- **Roasting:** Perfect for meats and vegetables. The rotisserie function allows for even roasting of whole chickens.
- **Dehydrating:** Use the mesh trays for dehydrating fruits, vegetables, or making jerky.

Care and Maintenance

Regular cleaning and proper maintenance will extend the life of your AGARO Prima Digital Air Fryer.

Cleaning

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.

2. **Accessories:** Wash all removable accessories (mesh basket, trays, rotisserie shaft, drip tray, etc.) with warm, soapy water. They are generally dishwasher-safe, but hand-washing is recommended for longevity.
3. **Interior:** Wipe the interior with a damp cloth and mild detergent. For stubborn food residue, soak a cloth in warm, soapy water and gently scrub. Avoid abrasive cleaners or metal scouring pads.
4. **Exterior:** Clean the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Drip Tray:** Empty and clean the drip tray after each use to prevent smoke and odors.

Storage

Store the air fryer in a cool, dry place. Ensure all components are clean and dry before storage. Do not wrap the power cord tightly around the appliance.

Troubleshooting Guide

If you encounter any issues with your AGARO Prima Digital Air Fryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; Power outlet malfunction; Appliance not properly assembled.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Ensure all removable parts are correctly inserted.
Food is not cooked evenly.	Overcrowding the basket; Incorrect temperature/time; Food not shaken/flipped.	Cook in smaller batches. Adjust temperature and time as per recipe. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; High-fat food cooking.	Clean the drip tray and interior thoroughly. For high-fat foods, drain excess fat during cooking.
Appliance smells during first use.	Manufacturing residues burning off.	This is normal. Run the air fryer empty for 10-15 minutes in a well-ventilated area before first use.
Temperature setting automatically switched from Celsius to Fahrenheit.	Accidental button press or specific model feature.	Refer to the control panel section of this manual or contact customer support for specific instructions on switching temperature units.
Basket/Rotisserie rod slips out.	Improper installation of accessories; Manufacturing defect.	Ensure accessories are securely locked into place. If the issue persists, contact customer support.
Food is not crispy.	Too much moisture in food; Not enough oil (for some recipes); Overcrowding.	Pat food dry before cooking. A light spray of oil can help. Do not overcrowd the basket.

Technical Specifications

Detailed specifications for the AGARO Prima Digital Air Fryer:

Specification	Detail
Model Name	Prima
Capacity	12 Litres
Output Wattage	1800 Watts
Voltage	240 Volts
Control Method	Touch Control
Temperature Range	80-200°C
Timer Range	Up to 120 minutes
Product Dimensions (D x W x H)	38D x 36W x 38H Centimeters
Item Weight	7.15 kg (7150 Grams)
Material	Stainless Steel
Inner Material	Stainless Steel
Air Frying Technology	Air Circulation Technology (360° rapid hot air circulation)
Special Features	Temperature Control, Overheat Protection, Auto Shut-off, Built-in Light, Look-through Window

Warranty and Support

The AGARO Prima Digital Air Fryer comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For warranty claims, technical assistance, or any product-related inquiries, please contact AGARO customer support. Keep your purchase receipt as proof of purchase.

For the most up-to-date support information, please visit the official AGARO website or refer to the contact details provided with your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKHTRX1L

More documents and user manuals: **https://manuals.plus/**