Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO THSL-001

TRESKO Infrared Heater 2500W - Instruction Manual

Model: THSL-001

Important Safety Instructions

Please read this manual carefully before using the TRESKO Infrared Heater. Keep these instructions for future reference.

- Ensure the heater is placed on a stable, level surface when using the stand.
- Maintain a safe distance from flammable materials (e.g., curtains, furniture).
- Do not cover the heater during operation.
- Do not operate the heater with a damaged cord or plug.
- Keep children and pets away from the heater.
- The heater is rated IP34 for indoor and outdoor use, meaning it is protected against splashing water. However, avoid direct exposure to heavy rain or submersion.
- Always unplug the heater before cleaning or maintenance.
- Do not touch the heating element when the heater is on or immediately after turning it off, as it will be extremely hot.

Product Overview

The TRESKO Infrared Heater 2500W provides efficient and instant radiant heat for various indoor and outdoor settings. It features adjustable power levels, a timer function, and can be used with a height-adjustable stand or wall-mounted.



Figure 1: TRESKO Infrared Heater with stand, remote, and protective cover.



Figure 2: Heater features including control panel, remote, and power settings.

Package Contents

Please check that all items are present in the package:

- TRESKO Infrared Heater Unit
- Height-Adjustable Tripod Stand
- Remote Control
- Protective Cover (IP34 waterproof)
- Wall Mounting Bracket
- Instruction Manual

Setup and Installation

1. Stand Assembly

Follow these steps to assemble the tripod stand and attach the heater unit:

1. Unfold the tripod legs and ensure they are securely locked in place.
2. Extend the telescopic pole to the desired height (110 cm to 180 cm) and secure it with the locking mechanism.
3. Attach the heater unit to the top of the stand using the provided screws and brackets. Ensure it is firmly secured.
4. Adjust the heater's angle and rotation (up to 360°) as needed.



Figure 3: Details of the adjustable and stable tripod stand.

2. Wall Mounting (Optional)

If you prefer to mount the heater on a wall, use the supplied wall mounting bracket:

1. Choose a suitable location on a sturdy wall, ensuring adequate clearance from ceilings and adjacent walls.
2. Mark the drilling points for the wall mounting bracket.
3. Drill holes and insert appropriate wall plugs (if necessary, depending on wall material).
4. Secure the wall mounting bracket to the wall.
5. Attach the heater unit to the wall mounting bracket, ensuring it is securely fastened.



Figure 4: Heater shown in a wall-mounted configuration.

Operating Instructions

1. Powering On/Off

- Plug the heater into a suitable electrical outlet.
- Press the 'Open/Close' button on the control panel or the power button on the remote control to turn the heater on.
- Press the 'Open/Close' or power button again to turn the heater off.

2. Adjusting Heat Levels

The heater offers three power levels:

- **Level 1:** 850 W
- **Level 2:** 1650 W
- **Level 3:** 2500 W

Use the 'Power' buttons on the remote control to cycle through the heat settings. The current level will be displayed on the heater's digital screen.

3. Using the Remote Control

The remote control allows convenient operation from a distance. Ensure there are no obstructions between the remote and the heater's receiver.

- **Power Button:** Turns the heater on or off.
- **Power Level Buttons:** Adjusts the heating power (850W, 1650W, 2500W).
- **Timer Button:** Activates and sets the timer function.

4. Timer Function

The timer allows you to set the heater to operate for a specific duration (1 to 24 hours).

1. With the heater on, press the 'Timer' button on the remote control.
2. Each press of the 'Timer' button will increase the operating time by one hour.
3. The selected time will be displayed on the heater's screen. The heater will automatically turn off after the set time has elapsed.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Before cleaning, always unplug the heater and allow it to cool completely. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, especially during off-season, store the heater in a cool, dry place. Use the provided IP34 waterproof protective cover to shield it from dust and moisture.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.



Figure 5: Heater with its protective cover for storage and weather protection.

Troubleshooting

If you encounter any issues with your heater, please refer to the following table before contacting support:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Power button not pressed.	Check if the power cord is securely plugged in. Ensure the wall outlet is functional. Press the power button on the unit or remote.
No heat output.	Low power setting. Heating element failure.	Increase the power level using the remote control. If still no heat, contact customer support.
Remote control not working.	Dead batteries. Obstruction between remote and heater.	Replace batteries in the remote control. Ensure a clear line of sight to the heater's receiver.

Problem	Possible Cause	Solution
Heater turns off unexpectedly.	Timer function activated. Overheating protection.	Check if the timer is set. Unplug the heater, let it cool down, and ensure proper ventilation.

SPECIFICATIONS

Feature	Detail
Brand	TRESKO
Model Number	THSL-001
Power Output	850 W / 1650 W / 2500 W
Power Source	Electric (Mains Powered)
Heating Method	Radiant (Quartz Tube)
Material	Aluminum Casing, Stainless Steel Protective Grille
Color	Black
Protection Rating	IP34 (Waterproof)
Indoor/Outdoor Use	Yes
Timer Function	1 - 24 Hours
Stand Height Adjustment	110 cm - 180 cm
Rotation Angle	360°
Mounting Type	Floor Mount (Pedestal) / Wall Mount
Product Dimensions (L x W x H)	87 cm x 70 cm x 175 cm (approximate, with stand)
Cable Length	2.0 m



Figure 6: Product dimensions.

Warranty and Support

For warranty information or technical support, please refer to the retailer where you purchased the product or contact the manufacturer directly. Specific warranty terms may vary by region and retailer.

Manufacturer: DWD-Company GmbH & Co. KG

Please have your model number (THSL-001) and purchase details ready when contacting support.

© 2023 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKLSML26

More documents and user manuals: **https://manuals.plus/**