Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS 2193-BN-1018sun

DUMOS Armless Home Office Chair Instruction Manual

Model: 2193-BN-1018sun

1. Safety Information

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Ensure the product is used on a hard, stable, and level surface to prevent tipping.
- The maximum weight capacity for this chair is **250 pounds (113 kg)**. Do not exceed this limit.
- Keep hands and fingers clear of moving parts, especially during height adjustment.
- Regularly check all bolts and screws to ensure they are tight. Re-tighten if necessary.
- Do not stand on the chair or use it as a step stool.
- This chair is designed for indoor use only.

2. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact DUMOS customer support.

All necessary accessories and tools for assembly are included in the package.

3. Assembly Instructions

Assembly is designed to be straightforward and typically takes approximately 10 minutes. Follow these 6 steps for proper installation.

1. Attach the five caster wheels to the chair base by pushing them firmly into the holes until they click into place.
2. Insert the gas lift cylinder into the center hole of the chair base.
3. Place the seat plate onto the top of the gas lift cylinder.
4. Secure the backrest support frame to the underside of the seat using the provided screws and hex tool.
5. Attach the backrest cushion to the backrest support frame using the remaining screws.
6. Ensure all screws are tightened securely before using the chair.



Figure 3.1: Key components of the DUMOS Armless Home Office Chair, including the gas lift cylinder, metal base, and swivel wheels, highlighting their durability and function.

4. Operating Instructions

4.1. Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever upwards to lower the seat. To raise the seat, stand up and pull the lever upwards. Release the lever at the desired height to lock it in place. The adjustable height range is approximately 3.74 inches.

4.2. Swivel Function

The chair features a 360-degree swivel mechanism, allowing for easy rotation without moving the base. This facilitates access to different areas of your workspace.

4.3. Mobility

The chair is equipped with 360-degree swivel wheels for smooth movement across hard floor surfaces. This allows for effortless repositioning around your workspace.

4.4. Space-Saving Design

The armless design allows the chair to be easily pushed under most desks when not in use, optimizing space in smaller environments.



Figure 4.1: The armless design allows the chair to be conveniently stored under a desk, maximizing room space.

5. Maintenance and Care

To ensure the longevity and appearance of your DUMOS office chair, follow these care instructions:

- **Cleaning:** Wipe clean with a damp cloth. For tougher stains on the PU leather, use a mild soap solution and then wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all fasteners (screws, bolts) and re-tighten them as needed to maintain stability and safety.
- **Casters:** Keep the wheels free of hair and debris to ensure smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.



Figure 5.1: The PU leather upholstery is designed for easy cleaning and is waterproof, simplifying maintenance.

6. Troubleshooting

If you encounter any issues with your DUMOS office chair, refer to the following common solutions:

- **Chair feels wobbly:** Check all assembly screws and bolts to ensure they are fully tightened. Ensure the chair is on a flat, even surface.
- **Height adjustment not working:** Verify that the gas lift cylinder is correctly inserted into the base and seat mechanism. Ensure the lever is fully engaged when attempting to adjust.
- **Wheels not rolling smoothly:** Inspect casters for any trapped debris (hair, dust, carpet fibers) and clean them thoroughly. Ensure the chair is used on an appropriate surface (hard floor recommended).
- **Squeaking noises:** Apply a small amount of silicone lubricant to moving parts or connection points if persistent squeaking occurs after checking all fasteners.

If problems persist, please contact DUMOS customer support for further assistance.

7. Specifications

Detailed specifications for the DUMOS Armless Home Office Chair, Model 2193-BN-1018sun:

Feature	Specification
Brand	DUMOS
Model Name	Small Armless Home Office Chair
Model Number	2193-BN-1018sun
Color	Brown
Product Dimensions (D x W x H)	18.11" x 22.83" x 34.25"
Adjustable Height Range	3.74 inches
Seat Height	17.12 inches (minimum)
Seat Depth	17.12 inches
Backrest Width	21.45 inches
Backrest Interior Height	17.12 inches
Maximum Weight Recommendation	250 Pounds (113 kg)
Material	PU Leather, Sponge (fill), Metal (frame/base)
Special Features	Adjustable Height, Ergonomic Lumbar Support, Rolling, 360° Swivel
Item Weight	19.18 pounds (8.7 kg)
Certifications	BIFMA Certified, SGS-certified cylinders



Figure 7.1: Detailed product dimensions and adjustable height range of the chair.



Figure 7.2: Illustration of the ergonomic lumbar support design for enhanced comfort.

8. Warranty and Support

For warranty information or technical support, please refer to the DUMOS official website or contact their customer service department directly. Please have your model number (2193-BN-1018sun) and purchase date available when contacting support.

You can also visit the DUMOS Store on Amazon for additional product information and contact options.

© 2025 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CL4PJ2G7

More documents and user manuals: **https://manuals.plus/**