Manuals+
Q & A | Deep Search | Upload

AW-D01 Compatible Remote Control

Replacement Remote Control User Manual

For Aiwa AW-D01 and Compatible Smart TV Models

Introduction

This manual provides instructions for the replacement remote control compatible with various Aiwa Smart TV models. This remote is designed to offer essential control functions for your television. Please note that this is a replacement unit, and while it provides core functionality, some advanced or specific features of your original remote may not be supported.

Product Overview

The replacement remote control is an ergonomic device crafted from high-quality ABS plastic, ensuring durability and comfortable handling. It is designed to be compatible with a range of Aiwa Smart TVs.

Image: Front and back view of the replacement remote control. The front shows various buttons including number pad, navigation, volume, channel, and dedicated app buttons. The back is plain black with 'MADE IN CHINA' text.

Key Features:

- **Compatibility:** Designed for Aiwa AW-D01, AWA650US, AWA550US, AWA500US, AWA400S, AW-LED43G7S, AW-LED50X8FL, AW-LED55X8FL, AW-LED65X8FL Smart TVs.
- **Ergonomic Design:** Comfortable to hold and use.
- **Durable Material:** Constructed from ABS plastic.
- **Color:** Available in black or white (color sent randomly).

Package Contents:

- 1 x Replacement Remote Control (batteries not included)

Setup

To begin using your new remote control, follow these simple steps for battery installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align

correctly with the markings inside the compartment.

4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Your remote control is now ready for use. No programming is typically required for this replacement remote.

Operating Instructions

This remote control provides intuitive access to your TV's primary functions. Familiarize yourself with the button layout to enhance your viewing experience.

Image: Front view of the replacement remote control, showing the layout of all buttons including power, number pad, navigation, volume, channel, and dedicated app buttons for Netflix, YouTube, and Prime Video.

Common Button Functions:

- **Power Button (Red):** Turns the TV on or off.
- **Number Pad (0-9):** Directly input channel numbers.
- **Volume Up/Down (+/-):** Adjusts the audio volume.
- **Channel Up/Down (P+/P-):** Changes the TV channel.
- **Navigation Buttons (Arrows & OK):** Navigate through menus and confirm selections.

- **Back/Return:** Returns to the previous screen or menu.
- **Home:** Accesses the TV's main smart hub or home screen.
- **Netflix, YouTube, Prime Video:** Dedicated buttons for quick access to these streaming applications.
- **Mute:** Silences the TV audio.
- **Input/Source:** Changes the input source (HDMI, AV, etc.).

Maintenance

Proper care will extend the life of your remote control:

- **Cleaning:** Use a soft, dry cloth to clean the remote. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

Troubleshooting

If you encounter issues with your remote control, consider the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Ensure you are within the effective range of the TV's sensor.
- **Some Functions Not Working:**
  - As a replacement remote, some specific or advanced functions of your original TV remote may not be supported. This is normal for universal or replacement remotes.
  - Verify that the function you are trying to use is a standard TV control function.
- **Intermittent Operation:**
  - This could indicate low battery power. Replace the batteries.
  - Ensure there is no interference from other electronic devices.

If problems persist, or if you have specific questions regarding compatibility with your TV model, it is recommended to provide your original remote's part number or your TV unit's model number to the seller for further assistance.

Specifications

Feature	Detail
Model Compatibility	Aiwa AW-D01, AWA650US, AWA550US, AWA500US, AWA400S, AW-LED43G7S, AW-LED50X8FL, AW-LED55X8FL, AW-LED65X8FL Smart TVs
Material	ABS Plastic

Feature	Detail
Special Feature	Ergonomic Design
Color	Black / White (Randomly Sent)
Power Source	2 x AAA Batteries (Not Included)
Max Number of Supported Devices	5 (Set Top Box, Television, Stereo System, DVD/Blu-ray Player, Home Theater)
Manufacturer	Generic
ASIN	B0CL9J983W

Warranty and Support

This product is a replacement remote control. While specific warranty details are not provided, the remote is tested for functionality prior to delivery to ensure it is in working condition upon arrival.
For any questions, compatibility concerns, or troubleshooting beyond the scope of this manual, please contact the seller or manufacturer directly. Providing your original remote's part number or your TV's model number can help expedite support.

© 2023 Generic. All rights reserved.