Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

USARMT BN59-01358A

USARMT BN59-01358A Universal Remote Control for Samsung TVs User Manual

Model: BN59-01358A

1. Introduction

This manual provides instructions for the setup, operation, and troubleshooting of the USARMT BN59-01358A Universal Remote Control. This remote is designed to be compatible with a wide range of Samsung LED, OLED, and QLED Smart TVs, offering a direct replacement for many original Samsung remote models without requiring complex programming.

2. Product Overview

The USARMT BN59-01358A is a universal replacement remote control for Samsung televisions. It features dedicated buttons for popular streaming services and essential TV functions. The remote is pre-programmed for immediate use with compatible Samsung TVs.



Figure 2.1: Front view of the USARMT BN59-01358A Universal Remote Control. This image displays the remote's layout, including the power button, number pad, directional controls, volume and channel rockers, and dedicated buttons for Netflix, Prime Video, and Samsung TV Plus.

Key Features:

- **Universal Compatibility:** Works with various Samsung LED, OLED, and QLED Smart TV models.
- **Pre-programmed:** No setup or programming required for most models.
- **Quick Access Buttons:** Dedicated buttons for Netflix, Prime Video, and Samsung TV Plus.
- **Ergonomic Design:** Comfortable to hold and use.

3. Setup

3.1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the cover back into place until it clicks securely.





Figure 3.1: Back view of the remote control. This image shows the rear of the remote, highlighting the battery compartment cover, which can be slid open to insert batteries.

3.2. Initial Use

Once batteries are installed, the remote control is pre-programmed and ready for use with most compatible Samsung TVs. Point the remote at your TV and attempt to operate it.

4. Operating Instructions

This section details the functions of the primary buttons on your USARMT BN59-01358A remote control.



Figure 4.1: Angled view of the remote control. This image provides a clear perspective of the button layout, including the power button, numerical input, navigation pad, and dedicated streaming service buttons.

- **Power Button:** Turns the TV on or off.
- **123 Button:** Accesses the on-screen number pad for direct channel input.
- **Directional Pad (Up/Down/Left/Right):** Navigates menus and selects options.
- **Enter/OK Button:** Confirms selections.
- **Return Button:** Goes back to the previous screen or menu.
- **Home Button:** Accesses the Smart Hub or main menu of the TV.
- **Play/Pause Button:** Controls media playback.
- **Volume Rocker (+/-):** Adjusts the volume level.
- **Channel Rocker (Up/Down):** Changes TV channels.
- **Netflix Button:** Launches the Netflix application directly.
- **Prime Video Button:** Launches the Amazon Prime Video application directly.
- **Samsung TV Plus Button:** Launches the Samsung TV Plus service directly.

5. Compatibility

The USARMT BN59-01358A remote control is compatible with a wide range of Samsung TV models. It replaces several original Samsung remote control models, including but not limited to:

- BN59-01385A
- BN59-01363A

- BN59-01266A
- BN59-01312A
- BN59-01259B
- BN59-01259E
- BN59-01260A
- BN59-01199F
- BN59-01315A
- BN59-01315J
- BN59-00666A
- BN59-01301A
- BN59-00741A
- BN59-00786A
- BN59-0602
- BN59-00638A
- BN59-00581A
- BN59-00582A
- BN59-01310
- BN59-01329
- BN59-01330
- BN59-00594A

It is also compatible with many Samsung LED, OLED, and QLED Smart TV models, including those from the QN, GU, and UE series. Examples include:

- QN75Q60RAFX, QN43Q60RAFX, QN49Q60RAFX, QN49Q70RAFX, QN55Q60RAFX, QN55Q70RAFX, QN55Q80RAFX, QN65Q60RAFX, QN65Q70RAFX, QN65Q80RAFX, QN65Q90RAFX, QN75Q70RAFX, QN75Q80RAFX, QN75Q90RAFX, QN82Q60RAFX, QN82Q70RAFX, QN82Q80RAFX, QN82Q90RAFX
- QN55Q900RBFX, QN65Q900RBFX, QN75Q900RBFX, QN82Q900RBFX, QN85Q900RBFX, QN98Q900RBFX
- GU43AU7179, GU43AU7199, GU50AU7179, GU50AU7199, GU55AU7179, GU55AU7179U, GU55AU7179UXZG, GU55AU7199, GU60AU7179, GU60AU7199, GU65AU7179, GU65AU7199, GU70AU7199U
- UE43AU7105, UE43AU7175, UE43AU7175UXXC, UE43AU7175UXZT, UE43AU7190, UE50AU7105, UE50AU7105KXXC, UE50AU7175, UE50AU7190, UE55AU7105

Note: This remote does not support voice control functionality.

6. Troubleshooting

6.1. Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity and are not depleted. Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the TV's infrared receiver. Obstructions can block the signal.
- **Distance:** Operate the remote within a reasonable distance from the TV.

6.2. Pairing Procedure (If Remote Does Not Work Immediately)

Although the remote is pre-programmed, some Samsung TV models may require a simple pairing step if it does not respond immediately after battery installation. Follow these steps:

1. Ensure your TV is powered on.
2. Press and hold both the "**Return**" button and the "**Play/Pause**" button simultaneously for approximately 5 seconds.
3. Release both buttons. The remote should now be paired with your TV.
4. Test the remote's functionality.

7. Specifications

Feature	Detail
Model Number	BN59-01358A
Brand	USARMT
Compatibility	Samsung LED, OLED, QLED Smart TVs
Power Source	2 x AAA Batteries (not included)
Color	Black
Dimensions	6 x 1.5 x 0.3 inches
Weight	2 ounces
Special Feature	Ergonomic design, Quick access buttons
Voice Control	Not supported

8. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

9. Warranty and Support

Specific warranty information for this product is typically provided at the point of purchase or within the product packaging. For technical support or further assistance, please refer to the contact information provided by your retailer or the manufacturer, USARMT.
Please note that batteries and a user manual are generally not included with the product. This digital manual serves as a comprehensive guide.

© 2023 USARMT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLK126XB

More documents and user manuals: **https://manuals.plus/**