Manuals+
Q & A | Deep Search | Upload

Fairywill 5020E

Fairywill Oral Care Combo 5020E Water Flosser and Electric Toothbrush User Manual

Model: 5020E

Introduction

This manual provides comprehensive instructions for the safe and effective use of your Fairywill Oral Care Combo 5020E, which includes a water flosser and an electric toothbrush. Please read this manual thoroughly before first use and retain it for future reference.

What's in the Box:

- 1 x Water Flosser
- 1 x Electric Toothbrush
- 4 x Water Nozzles
- 4 x Replacement Brush Heads
- 2 x Charging Cables
- 2 x User Guides

Image: All components of the Fairywill Oral Care Combo 5020E, including the water flosser, electric toothbrush, various nozzles, brush heads, and charging cables, neatly arranged.

Setup

Water Flosser Setup:

1. **Charge the Device:** Before first use, fully charge the water flosser. Connect the charging cable to the device and a suitable power source. The indicator light will show charging status.
2. **Fill the Water Tank:** Open the water tank cover and fill the 300ml tank with lukewarm water. Ensure the tank is securely closed after filling.
3. **Attach a Nozzle:** Insert your desired nozzle into the hole on the top of the water flosser until it clicks into place.

Image: A close-up view of the Fairywill Water Flosser, highlighting the detachable water tank and the nozzle attachment point.

Electric Toothbrush Setup:

1. **Charge the Device:** Before first use, fully charge the electric toothbrush. Connect the charging cable to the device and a suitable power source.
2. **Attach a Brush Head:** Align the brush head with the metal shaft of the toothbrush handle and push it down until it is firmly in place.

Image: A detailed view of the Fairywill Electric Toothbrush, showing a blue-bristled brush head securely attached to the handle.

Operating Instructions

Water Flosser Operation:

1. **Power On/Off:** Press the 'ON/OFF' button to turn the device on or off.
2. **Select Mode:** Press the 'Mode' button to cycle through the available cleaning modes:
   - **Clean:** For daily plaque removal.
   - **Soft:** Gentle cleaning for sensitive gums.
   - **Massage:** For gum stimulation.
3. **Flossing Technique:** Direct the water stream at a 90-degree angle to your gumline. Move the nozzle along your gumline, pausing briefly between teeth. The 360-degree rotatable nozzle allows for easy access to all areas of the mouth.

Electric Toothbrush Operation:

1. **Power On/Off:** Press the power button to turn the device on or off.
2. **Select Mode:** Press the power button repeatedly to cycle through the 5 high-performance brushing modes:
   - **White:** For surface stain removal.
   - **Clean:** Standard daily cleaning.
   - **Sensitive:** Gentle cleaning for sensitive teeth and gums.
   - **Polish:** For brightening and polishing teeth.
   - **Massage:** For gentle gum stimulation.
3. **Brushing Technique:** Apply a small amount of toothpaste to the brush head. Place the brush at a 45-degree angle to your gumline. The toothbrush features a built-in 2-minute timer with 30-second interval reminders to ensure thorough cleaning of all quadrants of your mouth.

Image: The Fairywill Water Flosser and Electric Toothbrush displayed together, showing their respective control panels and mode indicators.

Charging

Both the water flosser and the electric toothbrush are equipped with powerful rechargeable lithium batteries.

To charge, connect the provided charging cable to the device and a standard USB power adapter (not included).

- A full charge takes approximately 4 hours.
- Once fully charged, each device can provide up to 30 days of regular use.

Maintenance

Cleaning:

- **Water Flosser:** After each use, empty any remaining water from the tank. It is recommended to rinse the tank with clean water. The device is IPX7 waterproof, allowing for safe rinsing under running water.
- **Electric Toothbrush:** After each use, rinse the brush head thoroughly under running water. The toothbrush handle is IPX7 waterproof, allowing for safe rinsing.

Replacement:

- **Brush Heads:** For optimal oral hygiene, replace the electric toothbrush brush heads every 3 months, or sooner if the bristles become frayed.
- **Water Flosser Nozzles:** Replace water flosser nozzles every 3 to 6 months, or as needed.

Troubleshooting

- **Device not turning on:** Ensure the device is fully charged.
- **Weak water pressure (Water Flosser):** Check if the water tank is sufficiently filled and the nozzle is securely attached. Clean the nozzle if it appears clogged.
- **Reduced brushing effectiveness (Electric Toothbrush):** Replace the brush head if bristles are worn. Ensure the brush head is properly attached.
- **Charging issues:** Verify that the charging cable is properly connected to both the device and the power source. Try a different USB power adapter.

If you encounter persistent issues not covered here, please refer to the support section.

Specifications

Feature	Specification
Brand	Fairywill (Manufacturer) / Generic (Brand Name)
Model	5020E
Water Flosser Tank Capacity	300 ml
Electric Toothbrush Micro-brushes	40,000 per minute
Battery Capacity	1400 mAh (Lithium)
Charge Time	Approx. 4 hours

Feature	Specification
Usage Time per Charge	Up to 30 days
Waterproof Rating	IPX7
Product Dimensions	13.5 x 6.8 x 24.6 cm
Item Weight	760 g

Warranty and Support

Specific warranty details are not provided within the product description. For information regarding warranty coverage, please refer to the documentation included with your purchase or contact the manufacturer directly.

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact Fairywill customer service through their official website or the contact information provided in your product packaging.

© 2023 Fairywill. All rights reserved.