Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHiQ FBM317NEI4D

CHiQ FBM317NEI4D No Frost Refrigerator User Manual

Model: FBM317NEI4D | Brand: CHiQ

Introduction

Thank you for choosing the CHiQ FBM317NEI4D No Frost Refrigerator. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.

1. Setup

1.1 Unpacking

Carefully remove all packaging materials. Ensure no parts are missing or damaged. Keep packaging materials out of reach of children.

1.2 Placement

Place the refrigerator on a flat, stable surface away from direct sunlight, heat sources (like ovens or radiators), and moisture. Ensure adequate ventilation around the appliance. Allow at least 10 cm of space at the back and sides for proper air circulation.





Figure 1: Front view of the CHiQ FBM317NEI4D Refrigerator.



Figure 2: Refrigerator dimensions (Height: 1855mm, Width: 595mm, Depth: 635mm).

1.3 First Use

After placement, wait at least 2-4 hours before plugging in the appliance to allow the refrigerant to settle. Clean the interior with a damp cloth and mild detergent. Set the temperature controls to the recommended settings (usually 4°C for the fridge and -18°C for the freezer) and allow the refrigerator to cool for several hours before loading food.

2. Operating

2.1 Electronic Touch Control Panel

The refrigerator features an intuitive electronic touch control panel for precise temperature management and function selection. The panel displays current temperatures for both the refrigerator and freezer compartments.



Figure 3: Electronic touch control panel for temperature and function settings.

2.2 No Frost Technology

This refrigerator is equipped with total No Frost technology, which prevents ice build-up in both the freezer and refrigerator compartments. This eliminates the need for manual defrosting and ensures consistent cooling performance.



Figure 4: No Frost technology ensures no ice formation, maintaining maximum freshness.

2.3 Storage Capacity and Organization

The refrigerator offers a total capacity of 322 liters, with 226 liters for the refrigerator compartment and 96 liters for the freezer. It features multiple compartments, including a spacious vegetable drawer, to accommodate various food storage needs.





Model: FBM317NEI4D		Brand: CHiQ	
Capacidad	322L totalmente	Dimensiones (W*D*H)	595x635x1855mm
Tipo	Frigorífico-congelador	Instalación	Independiente
Potencia	220-240V/50Hz	Control de temperatura	7 Gears
Temperatura	-24°C-8°C	Tipo de clima	ST,N,SN,T
Peso Neto	62kg	Certificado	CE；Rosh

Figure 5: Interior view showing 226L refrigerator capacity and 96L freezer capacity.



Figure 6: Partitioned storage design for efficient organization of food items.





Figure 7: Comprehensive view of the refrigerator's interior, highlighting ample storage space.

2.4 Fast Freezing Function

Activate the fast freezing mode to rapidly lower the freezer temperature to -32°C, ideal for quickly freezing fresh food and preserving its nutrients and texture.

2.5 Humidity Control

The vegetable drawer includes a humidity control feature, allowing you to adjust the moisture level to keep fruits and vegetables fresh for longer and minimize nutrient loss.

2.6 LED Lighting

The interior is illuminated with bright and energy-efficient LED lights, providing clear visibility of all contents.



Figure 8: Interior features including bright LED lighting and convenient pull-out shelves.

2.7 Product Video

Watch the official product video for a visual guide on the features and operation of your CHiQ FBM317NEI4D Refrigerator.

▶ **Watch video online**

Video 1: Official CHiQ RF FBM317NEI4D product overview, showcasing design, capacity, No Frost technology, electronic control panel, fast freezing, and LED lighting.

3. Maintenance

3.1 Cleaning and Care

- **Interior Cleaning:** Clean the interior regularly with a solution of warm water and mild detergent. Wipe dry thoroughly to prevent odors and mold.
- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. For stainless steel finishes, use a

specialized stainless steel cleaner.

- **Door Seals:** Keep door seals clean to ensure a tight seal and efficient operation.
- **Power Off:** Always unplug the refrigerator before cleaning or performing any maintenance.

4. Troubleshooting

4.1 Common Issues and Solutions

Problem	Possible Cause	Solution
Refrigerator not cooling	Power supply issue, temperature setting too high, door not closed properly.	Check power connection, adjust temperature, ensure door is sealed.
Unusual noise	Appliance not level, items touching the back wall, compressor operation.	Level the refrigerator, rearrange items, normal compressor noise is expected.
Water on floor/inside	Drain hole blocked, door left open.	Clear the drain hole, ensure door is closed tightly.
Food freezing in fridge	Temperature set too low, food placed too close to air vents.	Increase fridge temperature, reposition food items.

If the problem persists after attempting these solutions, please contact CHiQ customer support.

5. Specifications

5.1 Technical Specifications

Feature	Detail
Model Number	FBM317NEI4D
Brand	CHiQ
Total Capacity	322 Liters
Refrigerator Capacity	226 Liters
Freezer Capacity	96 Liters
Dimensions (W x D x H)	59.5 x 63.5 x 185.5 cm
Weight	62 kg
Defrost System	No Frost
Installation Type	Freestanding
Number of Doors	2
Special Features	Inverter Compressor, Touch Screen Input, 3D Air Supply System, Fast Freezing Function, Smart Control

Feature	Detail
Climate Class	ST, N, SN, T
Noise Level	35 dB



Figure 9: Detailed specifications for the CHiQ FBM317NEI4D Refrigerator.

6. Warranty and Support

6.1 Compressor Warranty

The CHiQ FBM317NEI4D Refrigerator comes with a**12-year warranty for the compressor**, ensuring long-term reliability and peace of mind.

6.2 Customer Support

For any inquiries, technical assistance, or warranty claims, please contact CHiQ customer support. Refer to your

purchase documentation for specific contact details or visit the official CHiQ website.

© 2024 CHiQ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMTV3K5P

More documents and user manuals: **https://manuals.plus/**