Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHIQ CBM250NEBD

CHIQ CBM250NEBD Refrigerator with Freezer Instruction Manual

Model: CBM250NEBD

Brand: CHIQ

1. Important Safety Information

Please read this manual carefully before using your new CHIQ refrigerator. Keep it for future reference.

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments.
- Unplug the appliance before cleaning or maintenance.
- Keep ventilation openings clear of obstruction.
- This appliance is intended for household use only.

2. Product Overview

The CHIQ CBM250NEBD is a freestanding refrigerator with a freezer compartment, designed for efficient food preservation and quiet operation.





Figure 2.1: Interior view of the CHIQ CBM250NEBD refrigerator, showing shelves, crisper boxes, and freezer drawers.


CHiQ
Water Dispenser
No frost
250L



Figure 2.2: Front view of the CHIQ CBM250NEBD refrigerator, highlighting the integrated water dispenser.

Key Features:

- Electronic control with 5 temperature modes.
- Quick cooling function.
- Low-frost design for flexible storage.
- Energy-saving LED interior lighting.
- Quiet operation at 39 dB.
- Reversible door hinge.
- Integrated water dispenser.

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any damage during transit. Report any damage to your retailer immediately.

3.2 Placement

Choose a location that is dry, well-ventilated, and away from direct sunlight or heat sources (e.g., oven, radiator). Ensure sufficient space around the appliance for proper ventilation.



Figure 3.1: Product dimensions for placement consideration. Height: 1810mm, Width: 540mm.

3.3 Leveling

Adjust the leveling feet at the bottom of the appliance to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.

3.4 Electrical Connection

Connect the appliance to a properly grounded electrical outlet. Ensure the voltage and frequency match the specifications on the rating label.

Warning: Do not use extension cords or adapters with this appliance.

4. Operating Instructions

4.1 Initial Start-up

After connecting to power, allow the refrigerator to stand for at least 2-4 hours before loading food. This allows the refrigerant to settle.

4.2 Temperature Control

The refrigerator features electronic temperature control. Use the control panel to select one of the 5 available temperature modes.



Figure 4.1: Overview of key features including electronic control, water dispenser, and quiet operation.

4.3 Quick Cooling Function

Activate the quick cooling function for rapid chilling of beverages or newly added items. Refer to the control panel for activation details.

4.4 Water Dispenser Usage

To use the water dispenser, fill the internal water tank with potable water. Place a glass under the dispenser nozzle and

press the lever.



Figure 4.2: Close-up of the water dispenser providing chilled water.

4.5 Storage Compartments

Utilize the crisper boxes for fruits and vegetables to maintain freshness. The freezer drawers offer flexible storage for frozen goods.



Figure 4.3: Interior layout highlighting the 180L refrigerator compartment, 70L freezer compartment, and crisper boxes.

5. Maintenance and Cleaning

5.1 Cleaning the Interior

Before cleaning, unplug the appliance. Clean the interior with a soft cloth and a mild detergent solution. Rinse with clean water and dry thoroughly.

5.2 Defrosting (Low-Frost System)

The low-frost design significantly reduces ice build-up in the freezer. Manual defrosting will be required less frequently compared to conventional freezers. When a layer of frost approximately 5mm thick forms, defrost the freezer compartment.





Model:CBM250NEBD		Marke: CHiQ	
Kapazität	250L	Dimensionen (W*D*H)	540x576x1810mm
Typ	Kühlschrank	Installation	Freistehend
Leistung Typ	220-240V/50Hz	Tempera tursteuerung	7 Gänge
Kühlschrank/ Gefrierschrank	2~8°C/-16~-24°C	Klima-Typ	ST,N,SN,T
Nettogewicht	53kg	Zertifiziert	CE； RoHS

Figure 5.1: Illustration of the low-frost technology, minimizing ice formation.

5.3 Cleaning the Water Dispenser

Regularly clean the water tank and dispenser nozzle to ensure hygiene. Use a mild cleaning solution and rinse thoroughly.

5.4 Door Reversal

The door hinge is reversible, allowing you to change the door opening direction to suit your kitchen layout. Refer to the detailed instructions in the full manual for this procedure.



Figure 5.2: Visual representation of the reversible door feature.

6. Troubleshooting

Problem	Possible Cause	Solution
Appliance not cooling	No power; Temperature setting too high; Door not closed properly.	Check power supply; Adjust temperature setting; Ensure door is fully closed.
Excessive noise	Appliance not level; Objects touching the back; Compressor noise (normal).	Level the appliance; Move objects away; Normal operation noise is 39 dB.

Problem	Possible Cause	Solution
Water dispenser dripping	Nozzle blockage; Tank overfilled; Faulty valve.	Clean nozzle; Do not overfill tank; Contact service if problem persists.
Door alarm sounding	Door left open too long.	Close the door.

For issues not listed here, please contact customer support.

7. Specifications

Specification	Value
Model Number	CBM250NEBD
Capacity (Total)	250 Liters
Refrigerator Capacity	180 Liters
Freezer Capacity	70 Liters
Dimensions (W x D x H)	54 x 57.6 x 181 cm
Weight	53 kg
Annual Energy Consumption	174 kWh/year
Noise Level	39 dB
Defrost System	Manual (Low-frost)
Door Hinge	Reversible
Color	Black





Figure 7.1: EU Energy Label for CHIQ CBM250NEBD, showing energy class D, 174 kWh/annum, 70L freezer, 180L refrigerator, and 39 dB noise level. More details available at EPREL Database.

8. Warranty and Support

8.1 Warranty Information

This CHIQ appliance comes with a standard 2-year warranty on all products (3 years for ES). Additionally, a 12-year warranty is provided for the compressor.

- **Standard Warranty:** 2 years (3 years for Spain).
- **Compressor Warranty:** 12 years.
- **Return Policy:** 30-day return without reason, return via Amazon.

8.2 Customer Support

For technical assistance, warranty claims, or any inquiries, please contact CHIQ customer service. An online hotline is available with professional staff during weekdays.
Refer to your purchase documentation or the CHIQ official website for specific contact details.

9. Product Videos

▶ **Watch video online**

Video 9.1: A customer-submitted video demonstrating the refrigerator's functionality and aesthetics. Note: This video is from a customer review and not an official seller video.

No official seller videos were found for this product that meet the embedding criteria (creator_type: Seller).

© 2024 CHIQ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMTWG93R

More documents and user manuals: **https://manuals.plus/**