Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hagen HA5525

Hagen HA5525 Compact Stainless Steel Electric Kettle User Manual

Model: HA5525

1. Introduction

Thank you for choosing the Hagen HA5525 Compact Stainless Steel Electric Kettle. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Scalding may occur if the lid is removed during the heating cycle.
- Ensure the lid is securely closed before operating.
- Do not fill above the maximum fill line to avoid boiling water overflowing.
- This appliance is for household use only.

3. Product Overview

Familiarize yourself with the components of your Hagen electric kettle.



Figure 1: Hagen HA5525 Compact Stainless Steel Electric Kettle. This image displays the full kettle unit, including the handle, spout, lid, and power base, in its purple finish.



Figure 2: Close-up of the kettle's spout and lid. This image highlights the design of the pouring spout and the top of the lid.



Figure 3: Detailed view of the kettle's pouring spout. This image provides a

closer look at the spout design, which includes an integrated filter.



Figure 4: Kettle with the lid open. This image shows the kettle's interior, indicating where water is filled and the position of the removable filter.

Components:

1. Kettle Body (Stainless Steel)
2. Lid (with release button)
3. Handle
4. Spout with Removable Filter
5. Water Level Indicator
6. On/Off Switch with Indicator Light
7. 360° Rotational Power Base with Cord Storage

4. Setup

Unpacking:

- Remove all packaging materials from the kettle and its base.
- Ensure all components are present and undamaged.

Before First Use:

1. Fill the kettle with clean water up to the maximum fill line.
2. Boil the water (refer to Operating Instructions).
3. Discard the boiled water.
4. Repeat this process 2-3 times to remove any manufacturing residues and ensure optimal taste.
5. Wipe the exterior of the kettle and the power base with a damp cloth.

Placement:

- Place the power base on a dry, flat, stable, and heat-resistant surface.
- Ensure the power cord is not dangling or in contact with hot surfaces.

5. Operating Instructions

1. **Fill the Kettle:** Press the lid release button to open the lid. Fill the kettle with the desired amount of fresh water. Do not fill below the minimum mark or above the maximum fill line (1.8L). Close the lid securely.
2. **Place on Base:** Place the kettle firmly onto the 360° rotational power base.
3. **Connect to Power:** Plug the power cord into a suitable wall outlet (240V).
4. **Switch On:** Press the On/Off switch located at the bottom of the handle. The indicator light will illuminate, signifying that the kettle is heating.
5. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
6. **Pouring:** Carefully lift the kettle from its base and pour the hot water. Exercise caution as the kettle body and steam can be very hot.
7. **Re-boiling:** If you need to re-boil water, wait a few moments for the automatic shut-off mechanism to reset before pressing the On/Off switch again.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle.

Exterior Cleaning:

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel finish.
- Never immerse the kettle body or power base in water or any other liquid.

Interior Cleaning and Descaling:

Mineral deposits from water can build up inside the kettle over time, affecting performance. Descale your kettle regularly (every 1-3 months, depending on water hardness).

1. Fill the kettle with a mixture of white vinegar and water (1:2 ratio) or a commercial descaling solution according to product instructions.
2. Boil the solution.
3. Let it stand for at least 30 minutes, or longer for heavy scale.
4. Pour out the solution and rinse the interior thoroughly with fresh water several times.
5. Boil fresh water 2-3 times and discard to remove any residual vinegar taste or smell.

Filter Cleaning:

- The filter located behind the spout can be removed for cleaning.
- Gently pull the filter upwards to detach it.
- Rinse it under running water and brush off any deposits with a soft brush.
- Reinsert the filter by aligning it with the grooves and pushing it down until it clicks into place.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Kettle does not heat up.	No power supply; Kettle not properly seated on base; On/Off switch not pressed.	Check power outlet; Ensure kettle is correctly placed on the base; Press the On/Off switch.
Water takes too long to boil.	Limescale buildup.	Descale the kettle as per Maintenance section.
Kettle switches off before boiling.	Too little water (boil-dry protection activated); Limescale buildup.	Ensure water level is above minimum mark; Descale the kettle.
Water has an unusual taste/smell.	New appliance residue; Limescale buildup.	Perform first-use cleaning (boil and discard water multiple times); Descale the kettle.
Steam escapes from around the lid.	Lid not closed properly.	Ensure the lid is securely closed.

8. Specifications

- **Brand:** Hagen
- **Model Number:** HA5525
- **Color:** Violet
- **Capacity:** 1.8 Liters
- **Power:** 1500 Watts
- **Voltage:** 240 Volts
- **Material:** Stainless Steel
- **Dimensions (L x W x H):** 25 x 19 x 22 cm
- **Weight:** 840 grams
- **Special Features:** Automatic Shut-off, Low Water Sensor, Water Level Indicator, Overheat Protection, Cordless Operation

9. Warranty and Support

Hagen is committed to providing high-quality products. While specific warranty details are not provided in this manual, we offer a 100% satisfaction guarantee. If you encounter any issues or require assistance with your Hagen HA5525 electric kettle, please do not hesitate to contact our customer support. We are dedicated to providing excellent service and will be happy to assist you.
For support, please refer to the contact information provided with your purchase or visit the official Hagen website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMXFL11F

More documents and user manuals: **https://manuals.plus/**