LEXiBOOK NLJ035PA

LEXiBOOK Paw Patrol Nightlight Projector with Speaker

Model: NLJ035PA - User Manual

Introduction

This manual provides essential information for the safe and effective use of your LEXiBOOK Paw Patrol Nightlight Projector with Speaker, model NLJ035PA. Please read these instructions thoroughly before operating the device and retain them for future reference.

Safety Information

- Keep the device away from water and moisture.
- Do not expose to direct sunlight or extreme temperatures.
- Use only the provided USB-C cable for charging.
- This product is not a toy. Adult supervision is recommended for young children.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support for assistance.
- Ensure proper ventilation during use.

Package Contents

Verify that all items are present in the package:

- 1 x LEXiBOOK Paw Patrol Nightlight Projector with Speaker
- 1 x USB-C Charging Cable
- 1 x Instruction Manual (this document)



Image: The product packaging, illustrating the nightlight projector and its key features.

Product Overview

Familiarize yourself with the main components of your nightlight projector:

1. **Projection Dome:** Emits light for projections.
2. **Projection Film:** Contains Paw Patrol character images.
3. **Speaker Grille:** For audio output.
4. **Control Buttons:** Power, mode, volume, timer.
5. **USB-C Charging Port:** For power input.
6. **AUX-in Port:** For connecting external audio sources.



Image: Front view of the nightlight projector, showing the projection dome and speaker grille.



Image: Rear view of the nightlight projector, highlighting the control buttons, USB-C charging port, and AUX-in port.

Setup

1. **Charging the Device:** Connect the provided USB-C cable to the charging port on the device and the other end to a compatible USB power adapter (not included). The charging indicator will illuminate. A full charge takes approximately [Insert Charging Time if known, otherwise omit]. The internal 500 mAh battery provides portable use.
2. **Placement:** Place the nightlight projector on a flat, stable surface in the desired room. For optimal projection clarity, ensure the room is dark and the projector is positioned to cast images onto a clear wall or ceiling.

Operating Instructions

1. **Power On/Off:** Press and hold the Power button to turn the projector on or off.
2. **Projection Modes:** Short press the Mode button to cycle through different projection effects. This includes Paw Patrol character projections and kaleidoscopic light patterns.
3. **Music Playback:**
    - **Built-in Melodies:** The device features soothing built-in melodies. Use the Volume buttons to adjust the sound level.
    - **AUX-in:** Connect an external audio device (e.g., smartphone, MP3 player) to the AUX-in port using a 3.5mm audio cable (not included) to play your own music or stories.
4. **Timer Function:** Press the Timer button to activate the automatic shut-off function. Options typically include 15 or 30 minutes, allowing the device to turn off after your child falls asleep.



Image: The nightlight projector in operation, casting Paw Patrol characters onto a wall.



Image: A child sleeping, with the nightlight projector providing a calming visual and auditory environment.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no power.	Charge the device using the USB-C cable. Ensure the power button is pressed and held.
Projections are dim or unclear.	Room is too bright; projector is too far from surface.	Ensure the room is dark. Move the projector closer to the projection surface.
No sound from speaker.	Volume too low; AUX cable not connected properly.	Increase volume. Check AUX cable connection or try built-in melodies.
Timer function not working.	Timer not activated or set incorrectly.	Press the Timer button to cycle through available timer settings (15/30 minutes).

Specifications

Feature	Detail
Model Name	NLJ035PA
Brand	LEXiBOOK
Power Source	Corded Electric (USB-C)

Feature	Detail
Battery	500 mAh (Rechargeable)
Voltage	3.7 Volts
Light Source Type	LED
Material	Plastic
Product Dimensions	5.18"D x 5.18"W x 5.47"H
Item Weight	8.2 ounces
Special Feature	Portable, Built-in Speaker, AUX-in, Timer
UPC	841874027539

Warranty

This LEXiBOOK product is covered by a **2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and does not cover damage caused by misuse, accidents, or unauthorized modifications.

Support

For further assistance, technical support, or warranty inquiries, please visit the official LEXiBOOK website or contact their customer service department. You may also find additional resources and videos on the official product page or by scanning the QR code on the product packaging.

For product videos and demonstrations, please visit: https://www.lexibook.com/videos/NLJ035PA

© 2024 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question