Celebrat W26

Celebrat W26 TWS Wireless Stereo Hi-Fi Gaming Earbuds User Manual

Model: W26

Introduction

Thank you for choosing the Celebrat W26 TWS Wireless Stereo Hi-Fi Gaming Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

Product Overview

The Celebrat W26 TWS earbuds are designed for an immersive audio experience, featuring Hi-Fi stereo sound and a dedicated gaming mode. They offer wireless convenience with Bluetooth V5.3 connectivity.

Package Contents

- Celebrat W26 TWS Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple sizes of Eartips
- User Manual (this document)

Earbuds and Charging Case Diagram



Image: The Celebrat W26 TWS earbuds are shown resting in their charging case, which features a blue LED light strip at the front. The earbuds are white with a subtle blue indicator light.



Image: A close-up view of the white Celebrat W26 TWS earbuds, highlighting their in-ear design and the "Celebrat" branding on the stem.





Image: The retail packaging for the Celebrat W26 TWS earbuds, along with the charging case, a USB charging cable, and two pairs of silicone eartips.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and to a power source (e.g., USB wall adapter, computer USB port).
3. The indicator lights on the case and earbuds will show charging status. Once fully charged, the lights will typically turn off or change color.



Image: The Celebrat W26 TWS charging case is shown open, with both earbuds securely placed inside. The interior of the case displays product information including the model number W26 and charging specifications.

2. Bluetooth Pairing

To connect your earbuds to a device (smartphone, tablet, etc.):

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and an indicator light on the earbuds will flash (e.g., blue/red).
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select "Celebrat W26" (or similar name) from the list.
5. Once connected, the earbud indicator lights will typically turn off or show a steady blue light.
6. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

Operating Instructions

The Celebrat W26 earbuds feature touch controls for various functions.

Basic Functions

- **Power On:** Open the charging case, or long-press the touch area on both earbuds for a few seconds if they are out of the case and off.
- **Power Off:** Place earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds for a few seconds.
- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Long-press the touch area on either earbud during an incoming call.

Voice Assistant / Game Mode

- **Activate Voice Assistant:** Long-press the touch area on either earbud (when not on a call).
- **Switch Music/Game Mode:** The product packaging indicates "One click to switch Music/Game Mode". This typically involves a specific tap sequence (e.g., quad-tap or long-press a specific earbud). Refer to the quick start guide included in your package for the exact gesture.

Maintenance

Proper maintenance ensures the longevity and performance of your Celebrat W26 earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials. Gently clean the charging contacts on both the earbuds and the case.

- **Eartips:** Remove eartips periodically and clean them with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Water Resistance:** These earbuds are not water-resistant. Avoid exposure to water, sweat, and high humidity.

Troubleshooting

If you encounter issues with your Celebrat W26 earbuds, try the following solutions:

Problem	Solution
Earbuds not pairing/connecting	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "Celebrat W26" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in the case, close the lid, wait a few seconds, then open to re-enter pairing mode.
No sound from one or both earbuds	◦ Check device volume and earbud volume. ◦ Ensure earbuds are properly paired. ◦ Try resetting the earbuds (refer to specific reset instructions if available in the quick start guide, or try placing them in the case and holding the touch area for 10 seconds).
Earbuds not charging	◦ Ensure the charging cable is securely connected. ◦ Try a different USB port or power adapter. ◦ Clean the charging contacts on both earbuds and the case.
Poor audio quality	◦ Ensure earbuds are clean and free of debris. ◦ Move closer to your connected device to avoid interference. ◦ Try different eartip sizes for a better seal in your ear.

Specifications

Feature	Detail

Feature	Detail
Model	W26
Wireless Version	V5.3
Operating Frequency	2.402~2.480 MHz
Transmission Distance	≥10 meters
Optimal Working Distance	< 6 meters
Driver Unit	Ø10mm
Impedance	32 Ohm
Sensitivity	106 dB ± 3 dB
Frequency Response	20 Hz ~ 20 KHz
Earbud Battery Capacity	40 mAh (with Seiko protection board)
Music Playback Time	Approx. 5.5 hours (at 70% volume)
Control Type	Touch Control, Voice Control
Connectivity Technology	Wireless (Bluetooth)
Form Factor	In-Ear
Material	Plastic
Weight	130 grams
Water Resistance Level	Not Water Resistant
Recommended Use	Gaming, Mobile Phones

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer where you purchased the Celebrat W26 TWS earbuds. Manufacturer contact details may also be available on the product packaging or the official Celebrat website.

© 2023 Celebrat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question