Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BN59-00855A

ZdalaMit BN59-00855A Replacement Remote Control User Manual

For Samsung LCD LED Televisions

1. Product Overview

The ZdalaMit BN59-00855A is a direct replacement remote control designed for various Samsung LCD and LED television models. This remote offers full functionality without the need for any programming or setup. Simply insert batteries, and it is ready for use.





Figure 1: Front view of the ZdalaMit BN59-00855A Replacement Remote Control, showing all buttons.

2. Setup and Battery Installation

This remote control requires two (2) AAA size alkaline batteries for operation. No programming or pairing is necessary; the remote is pre-configured for compatible Samsung TV models.

1. **Locate the Battery Compartment:** Turn the remote control over to its back. The battery compartment cover is typically located on the lower half.
2. **Open the Cover:** Gently slide the battery compartment cover downwards or press the latch and lift to open.
3. **Insert Batteries:** Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. **Close the Cover:** Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with your compatible Samsung TV.



Figure 2: Angled view of the remote control, illustrating its ergonomic design and potential battery compartment location on the rear.

3. Operating Instructions

The ZdalaMit BN59-00855A remote control functions identically to the original Samsung remote it replaces. Point the remote directly at your television's infrared receiver for optimal performance.

Key Functions:

- **POWER:** Turns the television on or off.
- **TV:** Selects the TV input source.
- **Number Buttons (0-9):** Directly select channels.
- **PRE-CH:** Returns to the previous channel.
- **VOL (+/-):** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the television audio.
- **SOURCE:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **CH (up/down):** Changes channels sequentially.
- **CH LIST:** Displays the channel list.
- **MENU:** Opens the television's main menu.
- **FAV.CH:** Accesses favorite channels.

- **TOOLS:** Opens a quick menu with common functions.
- **RETURN:** Returns to the previous screen or menu.
- **INFO:** Displays information about the current program or input.
- **EXIT:** Closes the current menu or function.
- **Directional Pad (Up/Down/Left/Right) & ENTER:** Navigates menus and confirms selections.
- **MEDIA.P:** Accesses media playback functions.
- **P.MODE:** Changes picture modes.
- **MTS:** Selects Multi-channel Television Sound options.
- **CC:** Activates or deactivates Closed Captions.
- **Color Buttons (Red, Green, Yellow, Blue):** Access specific functions within menus or interactive services.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop):** Controls media playback.

4. Maintenance

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both AAA batteries simultaneously with new alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or excessive moisture, as these can damage the remote's electronics or finish.

5. Troubleshooting

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Ensure you are pointing the remote directly at the TV.
- **Intermittent Functionality:**
  - This may indicate low battery power. Replace batteries.
  - Verify there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the remote's signal.
- **Remote Does Not Control TV:**
  - Confirm your TV model is listed as compatible with the BN59-00855A remote control.
  - If the issue persists after checking batteries and line of sight, the remote may be faulty.

6. Specifications

Feature	Detail
Model Number	BN59-00855A

Brand	ZdalaMit
Compatible Devices	Samsung LCD LED Televisions (e.g., LN52B540P8FXZA, PN50B540S3FXZA, PN58B540S3FXZA, LN46B540, PN50B540S3F, LN52B540P8F, LN52B540, PN50B540, PN58B540, LN46B540P8F, LN40B540, PN58B540S3F, LN40B540P8F)
Battery Type	2 x AAA Alkaline Batteries (not included)
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	2 ounces
Special Feature	Ergonomic Design
Color	Black

7. Support

For any questions, concerns, or assistance regarding your ZdalaMit BN59-00855A replacement remote control, please do not hesitate to contact the seller or manufacturer. Refer to your purchase documentation for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN68YB9P

More documents and user manuals: **https://manuals.plus/**