Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eufy T29G2111

eufy Official Replacement Roller Brush User Manual

Model: T29G2111

Introduction

This manual provides essential information for the installation, maintenance, and troubleshooting of your eufy Official Replacement Roller Brush. Designed specifically for eufy L60 and L60 Hybrid robotic vacuums, this genuine accessory ensures optimal cleaning performance and extends the lifespan of your device.

Compatibility

The eufy Official Replacement Roller Brush (Model: T29G2111) is fully compatible with the following eufy robotic vacuum cleaner models:

- eufy L60 Robotic Vacuum
- eufy L60 Hybrid Robotic Vacuum

Using genuine eufy accessories is recommended to maintain product warranty and ensure peak performance.

Installation

Replacing the roller brush is a simple, tool-free process. Follow these steps to install your new roller brush:

1. **Power Off:** Ensure your eufy L60 or L60 Hybrid robotic vacuum is powered off and disconnected from its charging base before beginning any maintenance.
2. **Access the Brush Guard:** Flip the robotic vacuum over. Locate the brush guard, which is typically secured by two tabs or clips.
3. **Remove the Brush Guard:** Press the tabs or lift the clips to release the brush guard. Carefully remove the guard.
4. **Remove the Old Roller Brush:** Grasp the old roller brush and lift it out of its compartment. Note its orientation for easier installation of the new brush.
5. **Clean the Compartment:** Remove any hair, debris, or dust accumulated in the roller brush compartment and around the brush bearings. A cleaning tool (often included with your vacuum) can be helpful.
6. **Install the New Roller Brush:** Align the ends of the new eufy Official Replacement Roller Brush with the slots in the vacuum's brush compartment. Ensure it clicks securely into place.
7. **Reattach the Brush Guard:** Place the brush guard back into position and press down firmly until the tabs or clips

lock it securely.

8. **Verify Installation:** Gently spin the roller brush by hand to ensure it rotates freely without obstruction.



Image: The eufy Official Replacement Roller Brush, ready for installation.

Maintenance

Regular maintenance of your roller brush is crucial for optimal cleaning performance and to prevent issues. It is recommended to clean the roller brush at least once a week, or more frequently if you have pets or high usage.

- **Remove Hair and Debris:** After removing the roller brush (as per installation steps 1-4), use the cleaning tool or scissors to cut and remove any tangled hair or fibers from the brush bristles and ends.
- **Clean Bearings:** Check the brush bearings (the rotating parts at the ends of the brush) for any trapped debris and clean them thoroughly.
- **Wipe Down:** Use a dry cloth to wipe down the roller brush to remove any dust. Do not wash the roller brush with water.
- **Reinstall:** Reinstall the cleaned roller brush and brush guard.

Recommended Replacement Frequency: For best performance, it is suggested to replace the roller brush every 3-6 months, depending on your usage frequency and the amount of debris collected.

Troubleshooting

If you encounter issues related to the roller brush, consider the following common problems and solutions:

Problem	Possible Cause	Solution
"Roller brush stuck" error message	Hair or debris tangled around the brush or bearings; brush not installed correctly; worn-out brush.	1. Power off the vacuum. 2. Remove and thoroughly clean the roller brush and its compartment, removing all tangled hair and debris. 3. Ensure the brush is correctly reinstalled and spins freely. 4. If the issue persists after cleaning and reinstallation, the brush may be worn and require replacement.
Decreased cleaning performance	Worn bristles on the roller brush; brush not cleaned regularly.	1. Clean the roller brush as per the maintenance section. 2. If bristles are visibly worn or damaged, replace the roller brush with a new official eufy accessory.

Specifications

Feature	Detail
Product Name	Official Replacement Roller Brush
Brand	eufy
Model Number	T29G2111
Compatible Models	eufy L60, eufy L60 Hybrid
Dimensions (L x W x H)	7.48" x 1.77" x 1.77"
Color	Black
UPC	194644183691

Warranty and Support

This eufy Official Replacement Roller Brush is designed to meet the high-quality standards of eufy products. For information regarding warranty, returns, or technical support for your eufy robotic vacuum or its accessories, please refer to the official eufy website or contact eufy customer service directly.

eufy Customer Support:

- Visit the official eufy support page:www.eufylife.com/support
- Check your original eufy L60/L60 Hybrid vacuum cleaner manual for specific warranty details.

© 2025 eufy. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN9634Z7

More documents and user manuals: **https://manuals.plus/**