Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 5808

Braun Replacement Charge Cord for Type 5808 Trimmers - Instruction Manual

Model: 5808 | Brand: Braun

1. Introduction

This instruction manual provides essential information for the safe and effective use of your Braun Replacement Charge Cord, specifically designed for Braun trimmers of type 5808. Please read this manual thoroughly before first use and retain it for future reference. This cord ensures your trimmer receives the correct power for optimal performance and charging.

2. Setup and Connection

Follow these steps to properly set up and connect your Braun Replacement Charge Cord:

1. **Inspect the Cord:** Before connecting, visually inspect the charge cord for any signs of damage, such as frayed wires or bent pins. Do not use if damaged.
2. **Identify Trimmer Port:** Locate the charging port on your Braun trimmer. For type 5808 trimmers, this is typically a two-pin input.
3. **Connect to Trimmer:** Align the two-pin connector of the charge cord with the charging port on your trimmer. Gently push the connector firmly into the port until it is securely seated. Do not force the connection.
4. **Connect to Power Outlet:** Plug the standard two-prong wall plug of the charge cord into a functional electrical outlet (100-240V AC, 50/60Hz). Ensure the outlet is easily accessible.
5. **Verify Connection:** Once connected, your trimmer's charging indicator light (if applicable) should illuminate, indicating that it is receiving power and charging.



Figure 2.1: The Braun Replacement Charge Cord, showing the power adapter and coiled cord.



Figure 2.2: A close-up view of the two-pin connector designed to fit Braun trimmers.

3. Operating Instructions

The Braun Replacement Charge Cord is designed for straightforward operation:

- **Charging:** Once connected as described in Section 2, the cord will begin charging your trimmer. The charging time may vary depending on the trimmer model and its current battery level. Refer to your trimmer's original manual for specific charging times.
- **Indicator Lights:** Observe your trimmer's battery indicator lights. These lights typically show the charging status and when the battery is full.
- **Disconnecting:** Once charging is complete, first unplug the cord from the electrical outlet, then gently pull the connector from the trimmer's charging port. Avoid pulling the cord by the wire itself.

4. Maintenance and Care

Proper maintenance extends the life of your charge cord:

- **Cleaning:** Keep the cord and connectors clean and free from dust or debris. Use a dry, soft cloth to wipe the surfaces. Do not use liquid cleaners.
- **Storage:** When not in use, store the cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cord, which can damage internal wires.
- **Handling:** Always handle the cord by the plug and connector ends. Never yank or pull the cord from the outlet or trimmer by the wire.

5. Troubleshooting

If you encounter issues with your Braun Replacement Charge Cord, refer to the following common problems and solutions:

- **Trimmer Not Charging:**
  - Ensure the cord is securely plugged into both the trimmer and a working electrical outlet.
  - Check if the electrical outlet is functional by plugging in another device.
  - Inspect the cord and connectors for any visible damage. If damaged, replace the cord.
  - Verify that your Braun trimmer is indeed a type 5808. This cord is specifically designed for this model type.
- **Identifying Your Braun Trimmer Type Number:**
  It is crucial to identify the correct type number of your Braun shaver or trimmer to ensure compatibility with replacement parts, including this charge cord. The type number is a four-digit number, typically starting with '5', and is usually found in a discreet location on the device. Refer to the video below for detailed instructions on how to locate this number on various Braun shaver models.

▶ **Watch video online**
How to Identify Your Shaver TYPE Number

Video 5.1: How to Identify Your Shaver TYPE Number. This video demonstrates where to find the crucial 4-digit type number on various Braun shaver models, which is essential for ordering correct replacement parts.

6. Specifications

- **Product Type:** Replacement Charge Cord
- **Brand:** Braun
- **Compatible Trimmer Type:** 5808
- **Input Voltage:** 100-240V AC
- **Frequency:** 50/60Hz

7. Warranty and Support

For warranty information or product support, please contact the seller directly. This product is sold by Shaver Outlet, Inc. For general Braun product information, you may visit the official Braun Store online.

- **Seller:** Shaver Outlet, Inc.
- **Braun Store:** Visit the Braun Store on Amazon

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNBC6RHJ

More documents and user manuals: **https://manuals.plus/**