Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-PBF02

User Manual: Power Bank Joyroom JR-PBF02

Model: JR-PBF02 | Brand: JOYROOM

1. Introduction

Thank you for choosing the JOYROOM JR-PBF02 Power Bank. This high-capacity 20000mAh power bank with 30W fast charging capability is designed to provide reliable power for your mobile devices on the go. Please read this manual carefully before use to ensure optimal performance and safety.

2. Package Contents

- 1 x JOYROOM JR-PBF02 Power Bank
- 1 x User Manual

3. Product Overview

Familiarize yourself with the components of your power bank:



Figure 3.1: Front view of the JOYROOM JR-PBF02 Power Bank, highlighting its sleek black design and the prominent digital display indicating battery percentage.



Figure 3.2: Top view of the power bank, illustrating the two USB OUT ports (USB OUT1, USB OUT2), a Type-C IN/OUT port, and a built-in flashlight. The image also emphasizes the 30W fast charging capability.



Figure 3.3: A detailed view of the large smart digital display, which intuitively shows the battery percentage and a fast charging icon when active. The side of the power bank features the text "Make choice be simple".

The power bank features a large smart digital display for intuitive battery percentage and charging status. It includes multiple output ports for versatile device charging.

4. Setup

4.1 Initial Charge

Before first use, fully charge your JOYROOM JR-PBF02 Power Bank. This ensures optimal battery performance and longevity.

1. Connect the power bank to a wall charger (not included) using a USB-C cable (not included) via the Type-C IN/OUT port.
2. The digital display will show the charging progress, indicating the battery percentage.
3. Once the display shows "100%", the power bank is fully charged and ready for use.

5. Operating Instructions

5.1 Charging the Power Bank

To recharge the power bank:

- Use a compatible USB-C cable and connect it to the Type-C IN/OUT port on the power bank.
- Plug the other end of the cable into a USB wall adapter or a computer's USB port.
- The digital display will illuminate and show the current charge level, increasing as it charges.

5.2 Charging Your Devices

To charge your mobile devices:

- Connect your device's charging cable to one of the USB OUT ports (USB OUT1 or USB OUT2) or the Type-C IN/OUT port on the power bank.
- Connect the other end of the cable to your mobile device.
- The power bank will automatically begin charging your device. The digital display will show the remaining battery percentage of the power bank.
- To activate the built-in flashlight, press and hold the power button for a few seconds. Press again to turn it off.

6. Maintenance

Proper care will extend the life of your power bank:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Battery Care:** To maintain battery health, fully charge and discharge the power bank at least once every three months if not in regular use.

7. Troubleshooting

If you encounter issues with your power bank, refer to the following common solutions:

- **Power bank not charging:** Ensure the charging cable is securely connected to both the power bank and the power source. Try a different cable or wall adapter.
- **Device not charging from power bank:** Check if the power bank has sufficient charge. Ensure the charging cable is properly connected to both the power bank and your device. Try a different cable or port.
- **Slow charging:** Ensure you are using a fast-charging compatible cable and wall adapter for optimal charging speeds. Some devices may limit charging speed based on their battery status.
- **Digital display not working:** Try charging the power bank for a short period. If the issue persists, contact customer support.

8. Specifications

Feature	Detail
Model Number	JR-PBF02
Brand	JOYROOM
Battery Capacity	20000mAh
Output Power	30W (Max)

Voltage	5 Volts
Product Dimensions	10 x 5 x 1.27 cm
Item Weight	100 Grams
Color	Black

9. Safety Information

Please observe the following safety precautions:

- Do not expose the power bank to extreme temperatures (above 60°C/140°F) or direct sunlight.
- Do not immerse the power bank in water or other liquids.
- Do not disassemble, modify, or attempt to repair the power bank yourself. This will void the warranty and may cause harm.
- Keep out of reach of children.
- Avoid dropping or subjecting the power bank to strong impacts.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of it with household waste.

10. Warranty and Support

JOYROOM products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official JOYROOM website. You may also contact your retailer for assistance.

© 2024 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNH4LMKM

More documents and user manuals: **https://manuals.plus/**