Frigidaire 325804671

Frigidaire 24-inch Top Control Built-in Dishwasher User Manual

Model: 325804671

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new Frigidaire 24-inch Top Control Built-in Tall Tub Dishwasher. Please read all instructions carefully before using your appliance to ensure optimal performance and safety.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before operating this appliance.

- Always disconnect power to the dishwasher before servicing.
- Do not operate the dishwasher if it has a damaged power cord or plug.
- Use only detergents and rinse agents recommended for dishwashers.
- Keep children away from the dishwasher, especially when it is operating.
- Sharp items should be loaded with handles up to reduce the risk of cuts.
- Do not tamper with controls.

3. Setup and Installation

Proper installation is crucial for the performance and longevity of your dishwasher. It is highly recommended that installation be performed by a qualified installer.

3.1 Unpacking

Carefully remove all packaging materials. Inspect the dishwasher for any shipping damage. Report any damage immediately to your dealer.

3.2 Location Requirements

Ensure the installation area meets the required dimensions and has access to water supply, drain, and electrical

connections. The dishwasher must be level for proper operation.



Figure 3.1: Front view of the Frigidaire 24-inch Top Control Built-in Dishwasher. This image shows the appliance's clean white finish and the top-mounted control panel, which is not visible from the front when the door is closed.

3.3 Connecting Utilities

Connect the water inlet hose to a hot water supply (120°F/49°C recommended). Connect the drain hose to the sink drain or a separate air gap. Ensure all electrical connections comply with local codes and the dishwasher's specifications.



Figure 3.2: Angled front view of the Frigidaire 24-inch Top Control Built-in Dishwasher. This perspective highlights the sleek design and the integrated handle, blending seamlessly into kitchen cabinetry.

4. Operating Instructions

Familiarize yourself with the control panel and loading recommendations for optimal cleaning results.

4.1 Control Panel Overview

The top-mounted control panel features buttons for cycle selection, options, and start/cancel functions. Refer to the diagram below for specific button functions.



Figure 4.1: Interior view of the Frigidaire dishwasher with the door open. This image displays the empty upper and lower racks, the silverware basket, and the top-mounted control panel with various cycle and option buttons.

4.2 Loading the Dishwasher

Proper loading ensures effective cleaning. Place larger items in the lower rack and smaller items, glasses, and cups in the upper rack. Avoid overcrowding.



Figure 4.2: Interior view of the Frigidaire dishwasher with dishes loaded. The lower rack is shown filled with plates and a silverware basket, demonstrating typical loading capacity and arrangement.



Figure 4.3: Close-up view of the upper rack of the Frigidaire dishwasher. This image highlights the spacing and design of the rack, suitable for holding glasses and smaller bowls securely during a wash cycle.

4.3 Adding Detergent and Rinse Aid

Use automatic dishwasher detergent only. Fill the detergent dispenser according to the soil level of your dishes. Add rinse aid to the dispenser for improved drying performance and to prevent spotting.

4.4 Cycle Selection and Start

Select the desired wash cycle (e.g., Normal, Heavy, Light, Energy Saver) and any additional options (e.g., Heat Dry, Hi-Temp Wash). Close the dishwasher door firmly and press the START button to begin the cycle.

5. Maintenance and Care

Regular maintenance helps ensure your dishwasher operates efficiently and extends its lifespan.

5.1 Cleaning the Filter System

The dishwasher has a filter system that should be cleaned regularly to remove food particles and ensure optimal cleaning performance. Refer to the diagram for filter location and removal instructions.



Figure 5.1: Close-up view of the dishwasher's spray arm and filter area. This image shows the central spray arm and the removable filter assembly at the bottom of the tub, which requires periodic cleaning.

5.2 Cleaning the Interior and Exterior

Wipe the exterior with a damp cloth. Clean the interior periodically with a dishwasher cleaner or a mixture of vinegar and water to remove mineral deposits and odors.

5.3 Winterizing (for seasonal use)

If the dishwasher is in a location subject to freezing temperatures, it must be winterized. This involves disconnecting water lines, draining water, and adding RV antifreeze to prevent damage.

6. Troubleshooting

Before calling for service, review this section for common issues and their solutions.

Problem	Possible Cause	Solution
Dishwasher does not start	Door not latched; Power supply issue; Cycle not selected	Ensure door is fully closed; Check circuit breaker; Select a wash cycle
Dishes not clean	Improper loading; Clogged spray arms; Low water temperature; Clogged filter	Reload dishes correctly; Clean spray arm nozzles; Ensure hot water supply; Clean filter system
Water not draining	Clogged drain hose; Air gap clogged; Drain pump issue	Check and clear drain hose; Clean air gap; Contact service if pump is faulty
Excessive noise	Items hitting spray arm; Motor noise; Installation issue	Rearrange dishes; Normal operating sound; Check leveling and installation

7. Specifications

Product Dimensions: 25 x 24 x 33.5 inches; 62 Pounds

Item Model Number: 325804671

Manufacturer: Frigidaire

ASIN: B0CNL9FKV5

First Available: October 20, 2023

Included in Box: Dishwasher

8. Warranty and Support

Your Frigidaire dishwasher is covered by a limited warranty. Please refer to the warranty card included with your appliance for specific terms and conditions. For technical support, service, or to order parts, please visit the official Frigidaire website or contact their customer service line. Keep your proof of purchase for warranty claims.

For more information, visit the Frigidaire Store on Amazon.

© 2024 Frigidaire. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question