Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire GRMS2773AF

Frigidaire GRMS2773AF 36-Inch French Door Refrigerator User Manual

Model: GRMS2773AF

1. Important Safety Information

Read all instructions before using this appliance to prevent the risk of fire, electric shock, or injury to persons.

- Ensure proper grounding.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the refrigerator before cleaning or performing any maintenance.

2. Product Overview

The Frigidaire GRMS2773AF is a 36-inch freestanding French Door Refrigerator with a 26.3 cu. ft. total capacity. It features a 4-door design, including an innovative Custom-Flex Temp Drawer, TwinTech Cooling System, CrispSeal Crispers, and an external ice and water dispenser.



Figure 2.1: Front view of the Frigidaire GRMS2773AF French Door Refrigerator in stainless steel, showing the external ice and water dispenser on the left door.

Key Features:

- **TwinTech Cooling System:** Maintains consistent temperatures and humidity for fresher food.
- **Custom-Flex Temp Drawer:** Converts from refrigerator to freezer with five temperature options.
- **CrispSeal Crispers with Auto Humidity:** Blocks dry air to preserve fruits and vegetables longer.
- **External Water & Ice Dispenser:** Provides filtered water, cubed, or crushed ice on demand.
- **Fingerprint-Resistant Stainless Steel:** Smudge-proof finish for easy cleaning.
- **LED Multi-Level Lighting:** Bright, energy-efficient illumination throughout the interior.



Figure 2.2: Interior view of the refrigerator section with both French doors open, displaying various food items on adjustable shelves, gallon bins, and CrispSeal crispers.

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials, tape, and protective film from the refrigerator. Dispose of packaging responsibly.

3.2 Placement

This is a freestanding appliance. Ensure adequate clearance around the refrigerator for proper ventilation and door opening. Refer to the product dimensions for space requirements: 36.8 x 36 x 70.2 inches (Depth x Width x Height).

3.3 Leveling

Level the refrigerator using the adjustable leveling legs to ensure proper door alignment and operation.

3.4 Water Line Connection (for Ice & Water Dispenser)

Connect the refrigerator to a cold water supply line. It is recommended to use a qualified plumber for this installation to prevent leaks. Ensure the water filter is properly installed before first use.

3.5 Electrical Connection

Plug the refrigerator into a dedicated 120 Volt, 60 Hz, 15 Amp grounded electrical outlet. Do not use extension cords.

4. Operating Instructions

4.1 Initial Startup

After connecting power, allow the refrigerator to cool for several hours (at least 4-6 hours) before loading with food. The TwinTech Cooling System will work to reach optimal temperatures.

4.2 Temperature Control

The refrigerator features an external control panel for temperature adjustments. Set desired temperatures for the refrigerator and freezer compartments. The TwinTech Cooling System independently manages humidity and temperature in each section.

4.3 Custom-Flex Temp Drawer

This versatile drawer offers five temperature settings, allowing it to function as either a refrigerator or freezer compartment. Use the controls on the drawer to select the desired mode:

- Freezer
- Meat/Seafood
- Cold Drinks
- Deli/Snacks
- Chilled Wine



Figure 4.1: Detail of the Custom-Flex Temp Drawer control panel, showing options for Freezer, Meat/Seafood, Cold Drinks, Deli/Snacks, and Chilled Wine settings.



Figure 4.2: The Custom-Flex Temp Drawer pulled out, demonstrating its capacity for storing items like frozen pizzas and chilled beverages.

4.4 CrispSeal Crispers with Auto Humidity

These crisper drawers are designed to block dry air and maintain optimal humidity levels automatically, extending the freshness of fruits and vegetables. Store produce in these drawers for best results.

4.5 External Water & Ice Dispenser

The dispenser provides filtered water, cubed ice, or crushed ice. Use the control panel above the dispenser to select your preference. Replace the water filter regularly as indicated by the appliance or every 6 months.

4.6 LED Multi-Level Lighting

The interior LED lighting illuminates automatically when the doors are opened, providing clear visibility of contents.

5. Maintenance and Cleaning

5.1 Cleaning the Exterior

The fingerprint-resistant stainless steel finish can be cleaned with a soft cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive pads.

5.2 Cleaning the Interior

Clean the interior surfaces, shelves, and drawers with a solution of mild soap and warm water. Rinse and dry thoroughly. Remove shelves and bins for easier cleaning.

5.3 Water Filter Replacement

The water filter should be replaced approximately every 6 months, or when the filter indicator light illuminates. Refer to the specific instructions for filter replacement provided with your appliance.

5.4 Automatic Defrost

This refrigerator features an automatic defrost system, eliminating the need for manual defrosting of the freezer compartment.

6. Troubleshooting

Before contacting service, review the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power cord unplugged; temperature control set too warm; door left open; excessive food load.	Check power connection; adjust temperature setting; ensure doors are closed; reduce food load temporarily.
Water dispenser not working	Water supply turned off; water filter clogged; dispenser locked.	Check water supply valve; replace water filter; unlock dispenser.

Problem	Possible Cause	Solution
Unusual noises	Refrigerator not level; items vibrating inside; normal operating sounds (e.g., refrigerant flow).	Level the appliance; rearrange items; consult normal operating sound guide if available.
Ice maker not producing ice	Water supply turned off; ice maker switch off; clogged water filter.	Check water supply; ensure ice maker switch is on; replace water filter.

7. Specifications

Feature	Detail
Brand	Frigidaire
Model Number	GRMS2773AF
Total Capacity	26.3 Cubic Feet
Installation Type	Freestanding
Form Factor	French Door (4-Door)
Dimensions (D x W x H)	36.8 x 36 x 70.2 inches
Item Weight	335 Pounds
Color	Stainless Steel
Voltage	120 Volts
Defrost System	Automatic
Special Features	Fingerprint Resistant, LED Display, Custom-Flex Temp Drawer, TwinTech Cooling System, CrispSeal Crispers
Energy Rating	ENERGY STAR Certified

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Frigidaire website. You may also contact customer support via the link provided on the product's retail page.

Visit the Frigidaire Store for Support

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNL9RXL4

More documents and user manuals: **https://manuals.plus/**