Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vestel W7124

Vestel W7124 Front Load Washing Machine

User Instruction Manual

Model: W7124 | Brand: Vestel

1. Important Safety Instructions

Read all instructions before using the appliance. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury to persons.

- This appliance is intended for household use only.
- Do not install or store this appliance where it will be exposed to the weather or to temperatures below freezing.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to prevent children from getting trapped.
- Do not reach into the appliance if the tub or agitator is moving.
- Do not install or operate any appliance that is damaged. Contact authorized service personnel for repair.
- Always unplug the appliance from the power supply before cleaning, performing maintenance, or attempting any repairs.
- Ensure the electrical supply is properly grounded.

2. Unpacking and Installation (Setup)

Proper installation is crucial for the safe and efficient operation of your washing machine.

2.1 Unpacking

1. Remove all packaging materials, including the polystyrene base and any protective film.
2. Carefully remove the transit bolts from the rear of the machine. These bolts secure the drum during transport and must be removed before use. Keep them for future transport.
3. Inspect the machine for any damage. If damaged, do not install or operate it.

2.2 Location

- Place the washing machine on a firm, level floor. Uneven surfaces can cause vibration and noise.
- Ensure there is adequate space around the machine for ventilation and access.
- Avoid direct sunlight or extreme temperatures.

2.3 Water Connection

Connect the provided fill hose to the water inlet valve at the back of the machine and to a cold water tap. Ensure all connections are tight to prevent leaks.

2.4 Drain Connection

Securely place the drain hose into a standpipe or over the edge of a sink, ensuring it is properly secured to prevent it from dislodging during operation.

2.5 Electrical Connection

Plug the power cord into a grounded electrical outlet (220-240V, 50Hz). Do not use extension cords or adapters.

2.6 Leveling

Adjust the leveling feet at the bottom of the machine until it is perfectly level and stable. Use a spirit level to check.


VESTEL
W7124
7 Kg.|1200|A
OFF توقف
سريع Rapid 15'
يومي Daily 60'
قميص Shirts
خليط Mix
رياضة Sport
غسيل يدوي/ناعم Hand Wash Delicate
تجفيف Spin
قطن Cotton 90°C
غسيل تمهيدي Cotton 60°C
قطن Cotton
إقتصادي Eco 20°C
عناية سهلة Easy Care
صوف Wool
شطف Rinse
Allergy safe ضد الحساسية
Temp.
Spin
Delay
Pre Wash
Start / Pause

Figure 1: Front view of the Vestel W7124 Washing Machine. This image shows the main control panel, detergent dispenser drawer, and the front-loading door.

3. Operating Instructions

Follow these steps for effective and safe operation of your washing machine.

3.1 Preparing Laundry

- Sort laundry by fabric type, color, and degree of soiling.
- Check garment care labels for washing instructions.
- Empty pockets and close zippers and hooks to prevent damage.

3.2 Loading Laundry

Open the door and load items one by one, ensuring not to overload the machine. Leave enough space for clothes to tumble freely. The maximum capacity is 7 kg.

3.3 Adding Detergent and Additives

Pull out the detergent dispenser drawer. Add the appropriate amount of detergent to the main wash compartment. Add fabric softener or other additives to their designated compartments, if desired. Refer to detergent packaging for dosage recommendations.

3.4 Selecting a Program

Turn the program selection knob to choose the desired washing program. The machine offers 15 programs, including:

- **Normal:** For daily cotton and mixed fabrics.
- **Heavy Duty:** For heavily soiled, durable items.
- **Delicates:** For fragile items requiring gentle care.
- **Quick Wash:** For lightly soiled items needing a fast cycle.
- **Rinse:** An extra rinse cycle.

3.5 Starting the Wash Cycle

Press the Start/Pause button to begin the selected program. The machine will automatically fill with water and start the wash cycle.

3.6 Child Lock Feature

To activate the child lock, refer to your machine's control panel for the specific button combination (usually pressing and holding two buttons simultaneously for a few seconds). This prevents accidental changes to settings during operation.

4. Care and Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

4.1 Cleaning the Exterior

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

4.2 Cleaning the Detergent Dispenser

Periodically remove the detergent dispenser drawer and rinse it under running water to remove any detergent residue. Use a brush if necessary.

4.3 Cleaning the Drum

Run a maintenance wash (e.g., a hot wash cycle with no laundry and a small amount of detergent or a washing machine cleaner) every few months to clean the drum and remove any buildup.

4.4 Cleaning the Door Seal

Wipe the rubber door seal after each wash to prevent mold and mildew buildup. Leave the door slightly ajar when not in use to allow air circulation.

4.5 Cleaning the Drain Pump Filter

Locate the drain pump filter (usually at the bottom front of the machine). Open the cover, place a shallow container underneath to catch water, and carefully unscrew the filter. Clean any lint or debris and then reinsert it securely.

5. Troubleshooting

Before calling for service, check the following common issues and solutions:

- **Machine does not start:** Ensure the power cord is plugged in, the door is closed properly, and the Start/Pause button has been pressed. Check if the child lock is active.
- **No water filling:** Check if the water tap is open and the water supply hose is not kinked. Ensure household water pressure is adequate.
- **Water not draining:** Check if the drain hose is kinked or blocked. Clean the drain pump filter.
- **Excessive vibration or noise:** Ensure the machine is level and all four feet are firmly on the floor. Check that transit bolts were removed. Do not overload the machine.
- **Detergent residue in dispenser:** Ensure water pressure is sufficient. Clean the detergent dispenser drawer.
- **Error codes:** If an error code appears on the display, consult the specific error code section in the full manual (if available) or contact customer support.

6. Specifications

Feature	Specification
Brand	Vestel
Model	W7124
Product Dimensions (D x W x H)	52.7 cm x 59.7 cm x 84.5 cm
Capacity	7 kg
Access Location	Front Load
Color	White
Special Feature	Child Lock
Cycle Options	Normal, Heavy Duty, Delicates, Quick Wash, Rinse (15 programs total)
Control Type	Knob
Recommended Uses	Residential
Operating Mode	Semi-Automatic
Maximum Spin Speed	1200 RPM

Voltage	220 Volts
Noise Level	58 dB
Installation Type	Freestanding
Drum Material	Stainless Steel
Included Components	Drain Hose, Fill Hose
Manufacturer Country	Turkey

7. Warranty and Support

7.1 Warranty Information

This Vestel W7124 washing machine comes with a**2-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal household use. It does not cover damage caused by improper installation, misuse, neglect, or unauthorized repairs.

7.2 Customer Support

For technical assistance, service requests, or warranty claims, please contact your retailer or the authorized Vestel service center in your region. Have your model number (W7124) and serial number ready when contacting support.

© 2024 Vestel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNNB6VGH

More documents and user manuals: **https://manuals.plus/**